FOREWORD

This wiring diagram manual has been prepared to provide information on the electrical system of the 2004 COROLLA.

Applicable models: ZZE130 Series

For service specifications and repair procedures of the above models other than those listed in this manual, refer to the following manuals;

Manual Name	Pub. No.
▲2004 COROLLA Repair Manual	
Volume 1	RM1037U1
Volume 2	RM1037U2
▲2004 COROLLA New Car Features	
Supplement	NCF249U

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION

- NOTICE

When handling supplemental restraint system components (removal, installation or inspection, etc.), always follow the direction given in the repair manuals listed above to prevent accidents and supplemental restraint system malfunction.

2004 COROLLA ELECTRICAL WIRING DIAGRAM

	Section Code	Page
	A	2
HOW TO USE THIS MANUAL	в	3
TROUBLESHOOTING	C	12
ABBREVIATIONS	D	17
GLOSSARY OF TERMS AND SYMBOLS .	E	18
RELAY LOCATIONS	F	20
ELECTRICAL WIRING ROUTING	G	32
SYSTEM CIRCUITS	н	47
GROUND POINT		194
POWER SOURCE (Current Flow Chart)	J	198
CONNECTOR LIST	к	204
PART NUMBER OF CONNECTORS	L	210
OVERALL ELECTRICAL WIRING DIAGRA	М.М	214

A INTRODUCTION

This manual consists of the following 13 sections:

No.	Section	Description
_	INDEX	Index of the contents of this manual.
A	INTRODUCTION	Brief explanation of each section.
В	HOW TO USE THIS MANUAL	Instructions on how to use this manual.
с	TROUBLE- SHOOTING	Describes the basic inspection procedures for electrical circuits.
D	ABBREVIATIONS	Defines the abbreviations used in this manual.
E	GLOSSARY OF TERMS AND SYMBOLS	Defines the symbols and functions of major parts.
F	RELAY LOCATIONS	Shows position of the Electronic Control Unit, Relays, Relay Block, etc. This section is closely related to the system circuit.
G	ELECTRICAL WIRING ROUTING	Describes position of Parts Connectors, Splice points, Ground points, etc. This section is closely related to the system circuit.
	INDEX	Index of the system circuits.
н	SYSTEM CIRCUITS	Electrical circuits of each system are shown from the power supply through ground points. Wiring connections and their positions are shown and classified by code according to the connection method. (Refer to the section, "How to use this manual"). The "System Outline" and "Service Hints" useful for troubleshooting are also contained in this section.
I	GROUND POINT	Shows ground positions of all parts described in this manual.
J	POWER SOURCE (Current Flow Chart)	Describes power distribution from the power supply to various electrical loads.
к	CONNECTOR LIST	Describes the form of the connectors for the parts appeared in this book. This section is closely related to the system circuit.
L	PART NUMBER OF CONNECTORS	Indicates the part number of the connectors used in this manual.
М	OVERALL ELECTRICAL WIRING DIAGRAM	Provides circuit diagrams showing the circuit connections.

This manual provides information on the electrical circuits installed on vehicles by dividing them into a circuit for each system.

The actual wiring of each system circuit is shown from the point where the power source is received from the battery as far as each ground point. (All circuit diagrams are shown with the switches in the OFF position.)


When troubleshooting any problem, first understand the operation of the circuit where the problem was detected (see System Circuit section), the power source supplying power to that circuit (see Power Source section), and the ground points (see Ground Point section). See the System Outline to understand the circuit operation.

When the circuit operation is understood, begin troubleshooting of the problem circuit to isolate the cause. Use Relay Location and Electrical Wiring Routing sections to find each part, junction block and wiring harness connectors, wiring harness and wiring harness connectors, splice points, and ground points of each system circuit. Internal wiring for each junction block is also provided for better understanding of connection within a junction block.

Wiring related to each system is indicated in each system circuit by arrows (from___, to___). When overall connections are required, see the Overall Electrical Wiring Diagram at the end of this manual.

[A]






- [A] : System Title
- [B] : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B

Example: 1 Indicates Relay Block No.1

-) is used to indicate different wiring and [C] : (connector, etc. when the vehicle model, engine type, or specification is different.
- [D] : Indicates related system.
- [E] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (\ge).


Outside numerals are pin numbers.



The first letter of the code for each wiring harness and wiring harness connector(s) indicates the component's location, e.g, "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

When more than one code has the first and second letters in common, followed by numbers (e.g, IH1, IH2), this indicates the same type of wiring harness and wiring harness connector.

- [F] : Represents a part (all parts are shown in sky blue). The code is the same as the code used in parts position.
- [G] : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.




[H] : Indicates the wiring color.


Wire colors are indicated by an alphabetical code.

В	= Black	W	= White	BR = Brown
L	= Blue	V	= Violet	SB = Sky Blue
R	= Red	G	= Green	LG = Light Green
Ρ	= Pink	Υ	= Yellow	GR = Gray
0	= Orange			

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.



: Indicates a wiring Splice Point (Codes are "E" for the [1] Engine Room, "I" for the Instrument Panel, and "B" for the Body).




The Location of splice Point I 5 is indicated by the shaded section.

[J] : Indicates a shielded cable.



[K] : Indicates the pin number of the connector. The numbering system is different for female and male connectors.



[L] : Indicates a ground point.

The first letter of the code for each ground point(s) indicates the component's location, e.g, "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

[M] : Page No.

[N] _____ System Outline

Current is applied at all times through the STOP fuse to TERMINAL 2 of the stop light SW.

When the ignition SW is turned on, current flows from the GAUGE fuse to TERMINAL 8 of the light failure sensor, and also flows through the rear lights warning light to TERMINAL 4 of the light failure sensor.

Stop Light Disconnection Warning

When the ignition SW is turned on and the brake pedal is pressed (Stop light SW on), if the stop light circuit is open, the current flowing from TERMINAL 7 of the light failure sensor to TERMINALS 1, 2 changes, so the light failure sensor detects the disconnection and the warning circuit of the light failure sensor is activated.

As a result, the current flows from TERMINAL 4 of the light failure sensor to TERMINAL 11 to GROUND and turns the rear lights warning light on. By pressing the brake pedal, the current flowing to TERMINAL 8 of the light failure sensor keeps the warning circuit on and holds the warning light on until the ignition SW is turned off.

[O] _____ Service Hints

S6 Stop Light SW

2-1 : Closed with the brake pedal depressed

L4 Light Failure Sensor

- 1, 2, 7-Ground : Approx. 12 volts with the stop light SW on
 - 4, 8-Ground : Approx. 12 volts with the ignition SW at ON position
 - 11–Ground : Always continuity

[P] O : Parts Location

-	Code	See Page	Code	See Page	Code	See Page
	C7	34	L4	36	R7	37
	H17	36	R6	37	S6	35

[Q] C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	18	R/B No.1 (Instrument Panel Brace LH)

[R] : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IB	20	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
3C	22	Instrument Panel Wire and J/B No.3 (Instrument Panel Brace LH)

[S] : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IE1	42	Floor Wire and Instrument Panel Wire (Left Kick Panel)
BV1	50	Luggage Room Wire and Floor Wire (Luggage Room Left)

: Ground Points


Code	See Page	Ground Points Location
BL	50	Under the Left Center Pillar
BO	50	Back Panel Center

[U] : Splice Points

[T]

Γ	Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
	15	44	Cowl Wire	B18	50	Luggage Room Wire

- **[N]** : Explains the system outline.
- [O]: Indicates values or explains the function for reference during troubleshooting.
- [P] : Indicates the reference page showing the position on the vehicle of the parts in the system circuit.
 - Example : Part "L4" (Light Failure Sensor) is on page 36 of the manual.
 - * The letter in the code is from the first letter of the part, and the number indicates its order in parts starting with that letter.



- [Q]: Indicates the reference page showing the position on the vehicle of Relay Block Connectors in the system circuit.
 Example : Connector "1" is described on page 18 of this manual and is installed on the left side of the instrument panel.
- [R] : Indicates the reference page showing the position on the vehicle of J/B and Wire Harness in the system circuit. Example : Connector "3C" connects the Instrument Panel Wire and J/B No.3. It is described on page 22 of this manual, and is installed on the instrument panel left side.
- **[S]** : Indicates the reference page describing the wiring harness and wiring harness connector (the female wiring harness is shown first, followed by the male wiring harness).


Example : Connector "IE1" connects the floor wire (female) and Instrument panel wire (male). It is described on page 42 of this manual, and is installed on the left side kick panel.

- [T] : Indicates the reference page showing the position of the ground points on the vehicle.
 Example : Ground point "BO" is described on page 50 of this manual and is installed on the back panel center.
- [U] : Indicates the reference page showing the position of the splice points on the vehicle.Example : Splice point "I5" is on the Cowl Wire Harness and is described on page 44 of this manual.

B HOW TO USE THIS MANUAL

The ground points circuit diagram shows the connections from all major parts to the respective ground points. When troubleshooting a faulty ground point, checking the system circuits which use a common ground may help you identify the problem ground quickly. The relationship between ground points (∇e^{A} , ∇e^{B} and ∇e^{C} shown below) can also be checked this way.

I GROUND POINT




* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.

The "Current Flow Chart" section, describes which parts each power source (fuses, fusible links, and circuit breakers) transmits current to. In the Power Source circuit diagram, the conditions when battery power is supplied to each system are explained. Since all System Circuit diagrams start from the power source, the power source system must be fully understood.

J POWER SOURCE (Current Flow Chart)


The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other parts.




Engine Room R/B (See Page 20)

	Fuse	System	Page
		ABS	194
		ABS and Traction Control	187
20A	STOP	Cruise Control	180
		Electronically Controlled Transmission	166
		Multiplex Communication System	210
		Cigarette Lighter	214
		Combination Meter	230
		Headlight	112
10A	DOME	Interior Light	122
		Key Reminder and Seat Belt Warning	
		Light Auto Turn Off	
		the Deterrent and Door Levi	

Power Source




* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.



- [A] : Indicates connector to be connected to a part. (The numeral indicates the pin No.)
- **[B]** : Junction Connector

Indicates a connector which is connected to a short terminal.



Junction connector in this manual include a short terminal which is connected to a number of wire harnesses. Always perform inspection with the short terminal installed. (When installing the wire harnesses, the harnesses can be connected to any position within the short terminal grouping. Accordingly, in other vehicles, the same position in the short terminal may be connected to a wire harness from a different part.)

Wire harness sharing the same short terminal grouping have the same color.

[C] : Parts Code

The first letter of the code is taken from the first letter of part, and the numbers indicates its order in parts which start with the same letter.

[D] : Connector Color

Connectors not indicated are milky white in color.


Code	Part Name Part Number		Code	Part Name	Part Number	
A 1	A/C Ambient Temp. Sensor	90980–11070	D 4	Diode (Courtesy)	90980–11608	
A 2	A/C Condenser Fan Motor	90980–11237	D 5	Diode (Interior Light)	90980–10962	
A 3	A/C Condenser Fan Relay	90980–10940	D 6	Diode (Moon Roof)	90980–11608	
A 4	A/C Condenser Fan Resistor	90980–10928	D 7	Door Lock Control Relay	90980–10848	
A 5	A/C Magnetic Clutch	90980-11271	D 8	Door Lock Control SW LH	90980–11148	
A 6	A/T Oil Temp. Sensor	90980· ·11413	D 9	Door Lock Control SW RH		
[Å]	ABS Actual [B]	^{909;} [C] ¹⁵¹	D10	Door Courtesy SW LH	00000 44007	
A 8	ABS Actuator	90980–11009	D11	Door Courtesy SW RH	90980–11097	
A 9	ABS Speed Sensor Front LH	90980–10941	D12	Door Courtesy SW Front LH		
A10	ABS Speed Sensor Front RH	90980–11002	D13	Door Courtesy SW Front RH	00000 11150	
A11	Airbag Sensor Front LH	00000 11050		Door Courtesy SW Rear LH	90980–11156	
A12	Airbag Sensor Front RH	90980–11856	D15	Door Courtesy SW Rear RH		
A13	Airbon	90980–11194	D16	Dent - I - I - I - I - I - I - I - I - I -	00080 11170	
-		90980-110	-		90980-11170	


L PART NUMBER OF CONNECTORS


- [A] : Part Code
- [B] : Part Name
- [C] : Part Number Toyota Part Number are indicated.


Not all of the above part numbers of the connector are established for the supply.

C TROUBLESHOOTING









VOLTAGE CHECK

(a) Establish conditions in which voltage is present at the check point.

Example:

- [A] Ignition SW on
 [B] Ignition SW and SW 1 on
 [C] Ignition SW, SW 1 and Relay on (SW 2 off)
- (b) Using a voltmeter, connect the negative lead to a good ground point or negative battery terminal, and the positive lead to the connector or component terminal.

This check can be done with a test light instead of a voltmeter.

CONTINUITY AND RESISTANCE CHECK


- (a) Disconnect the battery terminal or wire so there is no voltage between the check points.
- (b) Contact the two leads of an ohmmeter to each of the check points.

If the circuit has diodes, reverse the two leads and check again.

When contacting the negative lead to the diode positive side and the positive lead to the negative side, there should be continuity.

When contacting the two leads in reverse, there should be no continuity.

(c) Use a volt/ohmmeter with high impedance (10 k Ω /V minimum) for troubleshooting of the electrical circuit.



FINDING A SHORT CIRCUIT

- (a) Remove the blown fuse and disconnect all loads of the fuse.
- (b) Connect a test light in place of the fuse.
- (c) Establish conditions in which the test light comes on. Example:
 - [A] Ignition SW on

 - Ignition SW on
 Ignition SW and SW 1 on
 Ignition SW, SW 1 and Relay on (Connect the Relay) and SW 2 off (or Disconnect SW 2) [В] [С]
- (d) Disconnect and reconnect the connectors while watching the test light.
 - The short lies between the connector where the test light stays lit and the connector where the light goes out.
- (e) Find the exact location of the short by lightly shaking the problem wire along the body.


CAUTION:

- (a) Do not open the cover or the case of the ECU unless absolutely necessary. (If the IC terminals are touched, the IC may be destroyed by static electricity.)
- (b) When replacing the internal mechanism (ECU part) of the digital meter, be careful that no part of your body or clothing comes in contact with the terminals of leads from the IC, etc. of the replacement part (spare part).


DISCONNECTION OF MALE AND FEMALE CONNECTORS


To pull apart the connectors, pull on the connector itself, not the wire harness.


HINT: Check to see what kind of connector you are disconnecting before pulling apart.




C TROUBLESHOOTING









HOW TO REPLACE TERMINAL (with terminal retainer or secondary locking device)

- 1. PREPARE THE SPECIAL TOOL
 - HINT : To remove the terminal from the connector, please construct and use the special tool or like object shown on the left.
- 2. DISCONNECT CONNECTOR
- 3. DISENGAGE THE SECONDARY LOCKING DEVICE OR TERMINAL RETAINER.
 - (a) Locking device must be disengaged before the terminal locking clip can be released and the terminal removed from the connector.
 - $(b) \ \mbox{Use a special tool or the terminal pick to unlock the secondary locking device or terminal retainer.}$

NOTICE:

Do not remove the terminal retainer from connector body.


- [A] For Non–Waterproof Type Connector
 - HINT : The needle insertion position varies according to the connector's shape (number of terminals etc.), so check the position before inserting it.


"Case 1"


Raise the terminal retainer up to the temporary lock position.


"Case 2"

Open the secondary locking device.









- [B] For Waterproof Type Connector
 - HINT: Terminal retainer color is different according to connector body.

Example: <u>Terminal Retainer</u> : <u>Connector Body</u> Black or White : Gray Black or White : Dark Gray Gray or White : Black

"Case 1"

Type where terminal retainer is pulled up to the temporary lock position (Pull Type).


Insert the special tool into the terminal retainer access hole (Mark) and pull the terminal retainer up to the temporary lock position.


HINT: The needle insertion position varies according to the connector's shape (Number of terminals etc.), so check the position before inserting it.


"Case 2"


Type which cannot be pulled as far as Power Lock insert the tool straight into the access hole of terminal retainer as shown.

C TROUBLESHOOTING









Push the terminal retainer down to the temporary lock position.

(c) Release the locking lug from terminal and pull the terminal out from rear.

4. INSTALL TERMINAL TO CONNECTOR

(a) Insert the terminal.

HINT:

- 1.
- Make sure the terminal is positioned correctly. Insert the terminal until the locking lug locks firmly. Insert the terminal with terminal retainer in the temporary lock 2. 3. position.
- (b) Push the secondary locking device or terminal retainer in to the full lock position.
- 5. CONNECT CONNECTOR


ABBREVIATIONS


The following abbreviations are used in this manual.

A/C	=	Air Conditioning
A/T	=	Automatic Transaxle
ABS	=	Anti–Lock Brake System
ECU	=	Electronic Control Unit
ESA	=	Electronic Spark Advance
EVAP	=	Evaporative Emission
IAC	=	Idle Air Control
IC	=	Integrated Circuit
J/B	=	Junction Block
LED	=	Light Emitting Diode
LH	=	Left-Hand
M/T	=	Manual Transaxle
O/D	=	Overdrive
R/B	=	Relay Block
RH	=	Right–Hand
SFI	=	Sequential Multiport Fuel Injection
SRS	=	Supplemental Restraint System
SW	=	Switch
	-	Switch
TEMP.	=	Temperature
TEMP. TVIP		Temperature
	=	Temperature
TVIP	=	Temperature TOYOTA Vehicle Intrusion Protection
TVIP VSV	=	Temperature TOYOTA Vehicle Intrusion Protection Vacuum Switching Valve Variable Valve Timing
TVIP VSV VVT	= = =	Temperature TOYOTA Vehicle Intrusion Protection Vacuum Switching Valve Variable Valve Timing


^{*} The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.

E GLOSSARY OF TERMS AND SYMBOLS







[Engine Compartment]




[Body]




[Instrument Panel]




F




O : Instrument Panel J/B Lower Finish Panel (See Page 21)







[Instrument Panel J/B Inner Circuit]




(Cont. Next Page)




③ : RH R/B	Right Side of the Instrument Panel Reinforcement
O:RHJ/B	(See Page 21)



[RH J/B Inner Circuit]






[Center J/B Inner Circuit]


	[ı
1 (4A)			11 (4A)
2(4A)	↓	•	12(4A)
3 (4A)			13 (4A)
4 (4A)			14 (4A)
5 (4A)			15 (4A)
6 (4A)			16 (4A)
7 (4A)			17 (4A)
8 4 A			18 (4A)
9 (4A)		Ĭ	19 4 A
10 (4A)			
			20 (4A)
1 (4B)			21 (A)
2 4 B			22 (A)
34B			11 (4B)
4 (4B)			12 (B)
54B			13 4 B
64B		•	14 (4B)
7 (4B)		•	15 (4B)
84B		•	16 4 B
9 4 B	•	•	17 4 B
10 4 B		•	18 4 B
1 (4C)		•	19 4 B
2 4 C	├ ─── ●	•	20 4 B
34C	├ ──── ●	•	21 (4B)
4 (4C)	├ ──── ●		22 4 B
54C			13 4 C
6 4 C		•	14 4 C
7 4 C	├ ─── ↑		15 4 C
84C	├ ─── ↑		16 4 C
9 4 C		•	17 4 C
10 4 C	<u> </u>	•	184C
11 (4C)	├ ──── ♦	•	19 4 C
12 4 C	 		20 4 C
			J

G ELECTRICAL WIRING ROUTING



- A 1 A/C Magnetic Clutch
- A 2 A/T Shift Lever Position SW Back–Up Light SW Park/Neutral Position SW
- A 3 ABS Speed Sensor Front LH
- A 4 ABS Speed Sensor Front RH
- A 5 Airbag Sensor Front LH
- A 6 Airbag Sensor Front RH
- A 7 Ambient Temp. Sensor
- B 1 Back–Up Light SW
- B 2 Brake Fluid Level Warning SW
- C 1 Camshaft Position Sensor
- C 2 Camshaft Timing Oil Control Valve (VVT)
- C 3 Crankshaft Position Sensor
- C 4 Cruise Control Actuator
- E 1 Electronically Controlled Transmission Solenoid
- E 2 Engine Coolant Temp. Sensor


- F 1 Front Fog Light LH
- F 2 Front Fog Light RH
- F 3 Front Parking Light LH Front Turn Signal Light LH
- F 4 Front Parking Light RH
 - Front Turn Signal Light RH
- F 5 Front Washer Motor
- F 6 Front Wiper Motor
- G 1 Generator
- G 2 Generator
- H 1 Headlight LH (High)
- H 2 Headlight LH (Low)
- H 3 Headlight RH (High)
- H 4 Headlight RH (Low)
- H 5 Heated Oxygen Sensor (Bank 1 Sensor 1)
- H 6 Horn



- I 1 Idle Air Control Valve
- I 2 Ignition Coil and Igniter No.1
- I 3 Ignition Coil and Igniter No.2
- I 4 Ignition Coil and Igniter No.3
- I 5 Ignition Coil and Igniter No.4
- I 6 Injector No.1
- I 7 Injector No.2
- I 8 Injector No.3
- I 9 Injector No.4
- J 1 Junction Connector
- K 1 Knock Sensor
- M 1 Mass Air Flow Meter
- N 1 Noise Filter (Ignition)
- O 1 Oil Pressure SW

- P 1 Power Steering Oil Pressure SW
- P 2 Pressure SW
- R 1 Radiator Fan Motor
- R 2 Radiator Fan Resistor
- S 1 Skid Control ECU with Actuator
- S 2 Starter
- S 3 Starter
- T 1 Throttle Position Sensor
- V 1 Vehicle Speed Sensor (Combination Meter)
- V 2 VSV (Canister Closed Valve)
- V 3 VSV (EVAP)
- W 1 Washer Level Sensor


G ELECTRICAL WIRING ROUTING



- A 8 A/C SW
 - Air Inlet Control SW
 - Defroster Mode Detection SW
- A10 A/T Shift Lever Illumination O/D Main SW
- A 11 Air Inlet Control Servo Motor
- A12 Airbag Sensor Assembly
- A13 Airbag Sensor Assembly
- A14 Airbag Sensor Assembly
- A15 Airbag Squib (Front Passenger Airbag Assembly)
- A16 Airbag Squib (Steering Wheel Pad)
- A17 Antenna Amplifier
- A18 Automatic Light Control Sensor
- B 3 Blower Motor
- B 4 Blower Resistor
- B 5 Blower SW
- B 6 Buckle SW LH
- Seat Position Sensor B 7 Buckle SW RH


Occupant Detection Sensor

- C 5 Cigarette Lighter
 - Power Outlet (Front)
- C 6 Cigarette Lighter Illumination
- C 7 Clock
- C 8 Clutch Start SW
- C 9 Combination Meter
- C10 Combination SW
- C11 Combination SW
- C12 Combination SW
- C13 Cruise Control Clutch SW
- C14 Cruise Control ECU
- D 1 Data Link Connector 3
- D 2 Daytime Running Light Relay
- E 3 Engine Control Module
- E 4 Engine Control Module
- E 5 Engine Control Module
- E 6 Engine Control Module




- F 7 Front Passenger Seat Belt Warning Light
- G 3 Glass Breakage Sensor ECU
- H 7 Hazard SW
- H 8 Heated Oxygen Sensor (Bank 1 Sensor 2)
- I 10 Ignition SW
- I 11 Integration Relay
- J 2 Junction Connector
- J 3 Junction Connector
- J 4 Junction Connector
- J 5 Junction Connector
- J 6 Junction Connector
- J 7 Junction Connector
- P 3 Parking Brake SW
- P 4 Power Outlet (Rear)

- R 3 Radio and Player
- R 4 Radio and Player
- R 5 Rear Window Defogger SW
- R 6 Remote Control Mirror SW
- R 7 Rheostat
- S 4 Security Indicator
- S 5 Shift Lock Control ECU
- S 6 Side Airbag Squib LH
- S 7 Side Airbag Squib RH
- S 8 Starter Cut Relay
- S 9 Stop Light SW
- T 2 Turn Signal Flasher Relay
- T 3 TVIP ECU
- U 1 Unlock Warning SW



- A19 ABS Speed Sensor Rear LH A20 ABS Speed Sensor Rear RH
- D 3 Door Control Receiver
- D 4 Door Courtesy SW Front LH
- D 5 Door Courtesy SW Front RH
- D 6 Door Courtesy SW Rear LH
- D 7 Door Courtesy SW Rear RH
- D 8 Door Key Lock and Unlock SW Front LH Door Lock Motor Front LH Door Unlock Detection SW Front LH
- D 9 Door Key Lock and Unlock SW Front RH
 Door Lock Motor Front RH
 Door Unlock Detection SW Front RH
- Door Unlock Detection SW Front RH
- D10 Door Lock Control SW Front LH D11 Door Lock Control SW Front LH Power Window Master SW
- D12 Door Lock Control SW Front RH
- D13 Door Lock Motor Rear LH
- D14 Door Lock Motor Rear RH


- F 8 Front Door Speaker LH
- F 9 Front Door Speaker RH
- F10 Fuel Pump Fuel Sender
- H 9 High Mounted Stop Light
- I 12 Inner Mirror
 - Personal Light
- I 13 Interior Light
- J 8 Junction Connector
- J 9 Junction Connector
- J 10 Junction Connector
- L 1 License Plate Light LH
- L 2 License Plate Light RH
- L 3 Luggage Compartment Light
- L 4 Luggage Compartment Light SW




- M 2 Moon Roof Control Relay and SW Personal Light
- M 3 Moon Roof Motor and Limit SW
- N 2 Noise Filter (Rear Window Defogger)
- P 5 Power Window Control SW Front RH
- P 6 Power Window Control SW Rear LH
- P 7 Power Window Control SW Rear RH
- P 8 Power Window Motor Front LH
- P 9 Power Window Motor Front RH
- P10 Power Window Motor Rear LH
- P 11 Power Window Motor Rear RH
- P12 Pretensioner LH
- P13 Pretensioner RH


- R 9 Rear Combination Light LH
- R10 Rear Combination Light LH
- R 11 Rear Combination Light RH
- R12 Rear Combination Light RH
- R13 Rear Speaker LH
- R14 Rear Speaker RH
- R15 Rear Window Defogger
- R16 Rear Window Defogger R17 Remote Control Mirror LH
- R18 Remote Control Mirror RH
- S10 Side Airbag Sensor LH
- S 11 Side Airbag Sensor RH
- T 4 Tweeter LH
- T 5 Tweeter RH
- V 4 Vapor Pressure Sensor
- V 5 VSV (Vapor Pressure Sensor)

\Box : Location of Connector Joining Wire Harness and Wire Harness ∇ : Location of Ground Points







Connector Joining Wire Harness and Wire Harness




Co	ode	Joining Wire Harness and Wire Harness (Connector Location)
E,	A1	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)




Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
IA1	
IA2	
IA4	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)
IA5	
IA6	
IB1	Engine Room Main Wire and Floor Wire (Cowl Side Panel LH)
IC1	
IC2	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IC3	




Connector Joining Wire Harness and Wire Harness






Code	Joining Wire Harness and Wire Harness (Connector Location)						
ID1	Instrument Panel Wire and Floor Wire (Left Kick Panel)						
ID2							
IE1	Instrument Panel Wire and Instrument Panel No.4 Wire (Behind the Combination Meter)						
IF1	Console Box Wire and Instrument Panel Wire (Under the Instrument Panel Center)						
IG1	Instrument Panel Wire and Instrument Panel No.3 Wire (Front Side of the Parking Brake Lever)						
IH1	Instrument Panel Wire and A/C Sub Wire (Left Upper Side of the Blower Unit)						
ll1	Engine Wire and Instrument Denal Wire (Disuar Linit DLI)						
ll2	Engine Wire and Instrument Panel Wire (Blower Unit RH)						
IJ1	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)						
IJ2							
IK1	Roof Wire and Instrument Panel Wire (Left Side of the Instrument Panel)						



2004 COROLLA (EWD533U)


Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
BA1	Rear Door LH Wire and Floor Wire (Left Center Pillar)
BB1	Rear Door RH Wire and Instrument Panel Wire (Right Center Pillar)
BC1	Skid Control Sensor Wire LH and Floor Wire (Quarter Wheel House LH)
BD1	Skid Control Sensor Wire RH and Floor Wire (Quarter Wheel House RH)
BE1	Speaker Tweeter LH Wire and Front Door LH Wire (Inside of the Front Door LH)
BF1	Speaker Tweeter RH Wire and Front Door RH Wire (Inside of the Front Door RH)

2004 COROLLA ELECTRICAL WIRING DIAGRAM SYSTEM CIRCUITS

ABS 154 Air Conditioning 188 Automatic Glare-Resistant EC Mirror with Compass 112 Back-Up Light 96 Charging 56 Cigarette Lighter 104 Clock 106 Combination Meter 180 Cruise Control 148 Door Lock Control 148 Electronically Controlled Transmission 142 Engine Control 53 Fog Light 76 Headlight 70 Heater 192 Horn 192 Illumination 52 Illumination 52 Illumination 86 Interior Light 90 Key Reminder Buzzer 168 Light Remider Buzzer 168 Moon Roof 140 Power Outlet 108 Power Window 114 Radia and Player 176 Readia and Player 176 Reat Window Defogger 174 Remote Control Mirror 110 Set Belt Warning		Page
Automatic Glare-Resistant EC Mirror with Compass 112 Back-Up Light 96 Charging 56 Cigarette Lighter 104 Clock 106 Combination Meter 180 Cruise Control 143 Door Lock Control 142 Engine Control 58 Fog Light 76 Headlight 70 Heater 192 Ignition 102 Ignition 52 Illumination 86 Interior Light 90 Key Reminder Buzzer 168 Moon Roof 144 Power Source 48 Power Window 114 Radia and Player 176 Rear Window Defogger 174 Remote Control Mirror 110 Set Belt Warning 172 Shift Lock 166 SRS 159 Starting 52 Starting 52 Starting 52 Starting 52 Starting	ABS	154
Back-Up Light 96 Charging 56 Cigarette Lighter 104 Clock 106 Combination Meter 180 Cruise Control 148 Door Lock Control 148 Electronically Controlled Transmission 142 Engine Control 58 Fog Light 70 Heater 192 Horn 102 Ignition 52 Illumination 86 Interior Light 90 Key Reminder Buzzer 168 Moon Roof 140 Power Outlet 108 Power Window 114 Radiator Fan 186 Radia or Player 176 Rear Window Defogger 174 Remote Control Mirror 110 Sat Belt Warning 172 Shift Lock 166 SRS 159 Starting 52 Stop Light 94 Tallight 94 Tallight 94 Turn Signal and Hazard Warn	Air Conditioning	188
Charging 56 Cigarette Lighter 104 Clock 106 Combination Meter 180 Cruise Control 148 Door Lock Control 118 Electronically Controlled Transmission 142 Engine Control 58 Fog Light 76 Headlight 70 Heater 192 Horn 102 Ignition 52 Illumination 86 Interior Light 90 Key Reminder Buzzer 168 Light Reminder Buzzer 168 Moon Roof 1440 Power Outlet 108 Power Window 114 Radio and Player 176 Rear Window Defogger 174 Remote Control Mirror 110 Seat Belt Warning 52 Starting <	Automatic Glare–Resistant EC Mirror with Compass	112
Cigarette Lighter 104 Clock 106 Combination Meter 180 Cruise Control 143 Door Lock Control 118 Electronically Controlled Transmission 142 Engine Control 58 Fog Light 76 Headlight 70 Heater 192 Horn 102 Ignition 52 Illumination 86 Interior Light 90 Key Reminder Buzzer 168 Light Reminder Buzzer 168 Light Reminder Buzzer 168 Power Outlet 108 Power Window 114 Radio and Player 176 Rear Window Defogger 174 Remote Control Mirror 110 Seat Belt Warning 159 Starting 52 Stop Light 94 Taillight 78 TvIP System 134 Wiper and Washer 98	Back–Up Light	96
Clock106Combination Meter180Cruise Control148Door Lock Control.118Electronically Controlled Transmission142Engine Control58Fog Light76Headlight70Heater192Horn102Ignition52Illumination86Interior Light90Key Reminder Buzzer168Light Reminder Buzzer168Dower Outlet108Power Source43Power Window114Radiator Fan186Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning52Stop Light94Taillight76Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Charging	56
Combination Meter180Cruise Control148Door Lock Control.118Electronically Controlled Transmission142Engine Control58Fog Light76Headlight70Heater192Horn102Ignition52Illumination86Interior Light90Key Reminder Buzzer168Light Reminder Buzzer168Moon Roof140Power Outlet108Power Window114Radiator Fan186Radiator Fan110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight62Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Cigarette Lighter	104
Cruise Control148Door Lock Control118Electronically Controlled Transmission142Engine Control58Fog Light76Headlight70Heater192Horn102Ignition52Illumination86Interior Light90Key Reminder Buzzer168Light Reminder Buzzer168Moon Roof140Power Outlet108Power Source48Power Window114Radiator Fan186Radio and Player176Rear Window Defogger174Rear Window Defogger172Shift Lock166SRS159Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Clock	106
Door Lock Control118Electronically Controlled Transmission142Engine Control58Fog Light76Headlight70Heater192Horn102Ignition52Illumination86Interior Light90Key Reminder Buzzer168Light Reminder Buzzer168Dower Outlet108Power Outlet108Power Window114Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight78TUrn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Combination Meter	180
Electronically Controlled Transmission142Engine Control58Fog Light76Headlight70Heater192Horn102Ignition52Illumination86Interior Light90Key Reminder Buzzer168Light Reminder Buzzer168Noon Roof140Power Outlet108Power Source48Power Window114Radia and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight78TVIP System134Wiper and Washer98	Cruise Control	148
Engine Control 58 Fog Light 76 Headlight 70 Heater 192 Horn 102 Ignition 52 Illumination 86 Interior Light 90 Key Reminder Buzzer 168 Light Reminder Buzzer 168 Moon Roof 140 Power Outlet 108 Power Source 48 Power Window 114 Radiator Fan 186 Radio and Player 176 Rear Window Defogger 174 Remote Control Mirror 110 Seat Belt Warning 172 Shift Lock 159 Starting 52 Stop Light 94 Taillight 78 Turn Signal and Hazard Warning Light 78 TVIP System 93	Door Lock Control	118
Fog Light 76 Headlight 70 Heater 192 Horn 102 Ignition 52 Illumination 86 Interior Light 90 Key Reminder Buzzer 168 Light Reminder Buzzer 168 Moon Roof 140 Power Outlet 103 Power Source 48 Power Window 114 Radiator Fan 186 Radio and Player 176 Rear Window Defogger 174 Remote Control Mirror 110 Seat Belt Warning 172 Shift Lock 159 Starting 52 Stop Light 94 Taillight 78 TUrn Signal and Hazard Warning Light 78 TVIP System 134 Wiper and Washer 98	Electronically Controlled Transmission	142
Headlight 70 Heater 192 Horn 102 Ignition 52 Illumination 86 Interior Light 90 Key Reminder Buzzer 168 Light Reminder Buzzer 168 Moon Roof 140 Power Outlet 108 Power Source 48 Power Window 114 Radiator Fan 186 Radia ond Player 176 Rear Window Defogger 174 Remote Control Mirror 110 Seat Belt Warning 172 Shift Lock 166 SRS 159 Starting 52 Stop Light 94 Taillight 78 TVIP System 134 Wiper and Washer 98	Engine Control	58
Heater 192 Horn 102 Ignition 52 Illumination 86 Interior Light 90 Key Reminder Buzzer 168 Light Reminder Buzzer 168 Moon Roof 140 Power Outlet 108 Power Outlet 108 Power Window 448 Power Window 114 Radiator Fan 186 Radio and Player 176 Rear Window Defogger 174 Remote Control Mirror 110 Seat Belt Warning 172 Shift Lock 166 SRS 159 Starting 52 Stop Light 78 Turn Signal and Hazard Warning Light 78 TVIP System 134 Wiper and Washer 98	Fog Light	76
Horn 102 Ignition 52 Illumination 86 Interior Light 90 Key Reminder Buzzer 168 Light Reminder Buzzer 168 Moon Roof 140 Power Outlet 108 Power Source 48 Power Window 114 Radio and Player 176 Rear Window Defogger 174 Remote Control Mirror 110 Seat Belt Warning 172 Shift Lock 166 SRS 159 Starting 52 Stop Light 78 Turn Signal and Hazard Warning Light 78 TVIP System 134	Headlight	70
Ignition52Illumination86Interior Light90Key Reminder Buzzer168Light Reminder Buzzer168Moon Roof140Power Outlet108Power Source48Power Window114Radiator Fan186Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight78TVIP System134Wiper and Washer98	Heater	192
Illumination86Interior Light90Key Reminder Buzzer168Light Reminder Buzzer168Moon Roof140Power Outlet108Power Source48Power Window114Radiator Fan186Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight78TVIP System134Wiper and Washer98	Horn	102
Interior Light90Key Reminder Buzzer168Light Reminder Buzzer168Moon Roof140Power Outlet108Power Source48Power Window114Radiator Fan186Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight78TVIP System134Wiper and Washer98	Ignition	52
Key Reminder Buzzer168Light Reminder Buzzer163Moon Roof140Power Outlet108Power Source48Power Window114Radiator Fan186Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight78TVIP System134Wiper and Washer98	Illumination	86
Light Reminder Buzzer168Moon Roof140Power Outlet108Power Source48Power Window114Radiator Fan186Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight78TVIP System134Wiper and Washer98	Interior Light	90
Moon Roof140Power Outlet108Power Source48Power Window114Radiator Fan186Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Key Reminder Buzzer	168
Power Outlet108Power Source48Power Window114Radiator Fan186Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight78TVIP System134Wiper and Washer98	Light Reminder Buzzer	168
Power Source48Power Window114Radiator Fan186Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Moon Roof	140
Power Window114Radiator Fan186Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Power Outlet	108
Radiator Fan186Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Power Source	48
Radio and Player176Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Power Window	114
Rear Window Defogger174Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Radiator Fan	186
Remote Control Mirror110Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Radio and Player	176
Seat Belt Warning172Shift Lock166SRS159Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Rear Window Defogger	174
Shift Lock166SRS159Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Remote Control Mirror	110
SRS159Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Seat Belt Warning	172
Starting52Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Shift Lock	166
Stop Light94Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	SRS	159
Taillight82Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Starting	52
Turn Signal and Hazard Warning Light78TVIP System134Wiper and Washer98	Stop Light	94
TVIP System 134 Wiper and Washer 98	Taillight	82
Wiper and Washer	Turn Signal and Hazard Warning Light	78
•	TVIP System	134
Wireless Door Lock Control	Wiper and Washer	98
	Wireless Door Lock Control	126





Power Source

- Service Hints

HEAD Relay

- 3-5 : Closed with the light control SW at Head position or the dimmer SW at Flash position
 - : Closed with the engine running and the parking brake lever is released (Parking brake SW off)

I10 Ignition SW

- 1-3 : Closed with the ignition SW at ACC or ON position
- 1-2 : Closed with the ignition SW at ON or ST position
- 5-6 : Closed with the ignition SW at ON or ST position
- 5-4 : Closed with the ignition SW at ST position

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
G2	32	J6	35		
l10	35	J7	35		

Relay Blocks

()

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

: Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)					
IA	25	Facine Dears Meis Wire and Instrument Deard I/D /I succe Finish Deard)					
IB	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)					
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)					
IH	20						
IM	24						
1A	22	Ensine Mine and Ensine Dears I/D (Ensine Comportment Laft)					
1B	22	Engine Wire and Engine Room J/B (Engine Compartment Left)					
1C		Earlier Dears Male Miles and Earlier Dears J/D /Earlier Operational Lafe					
1D	22	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)					


Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA4	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)

: Ground Points

Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter
IG	40	Right Kick Panel





Service Hints

I10 Ignition SW

5-4 : Closed with the ignition SW at ST position

5-6 : Closed with the ignition SW at ON or ST position

S2 (A), S3 (B) Starter

Points closed with the shift lever at P or N position and the ignition SW at ST position (A/T) Points closed with the clutch pedal depressed and the ignition SW at ST position (M/T)

O : Parts Location

Co	ode	See Page	Co	de	See Page	Code		See Page
A2		32	14		33	N	1	33
C	8	34	15		33	S2	А	33
E3	А	34	I1	0	35	S3	В	33
E4	В	34	J2	А	35	S	8	35
I	2	33	J3	В	35	Т	3	35
ļ	3	33	J	6	35			

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)				
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)				
IF	25					
IL		Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
IM	24					
1A	22	Engine Wire and Engine Room J/B (Engine Compartment Left)				

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	38	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
IA2		
IA4	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)
IA5		
ll1	40	Engine Wire and Instrument Danel Wire (Plause Linit DLI)
ll2	42	Engine Wire and Instrument Panel Wire (Blower Unit RH)


: Ground Points

•		
Code	See Page	Ground Points Location
EC	38	Left Side of the Cylinder Head
IE	40	Behind the Combination Meter

: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E2	20		17	40	Instrument Panel Wire
E3	38	Engine Wire	19	42	
12	42	Instrument Panel Wire			

Charging



Service Hints

G1 (A) Generator

- (A) 3–Ground : 13.2–14.0 volts with the engine running at 5000 rpm and 115 $^\circ\text{C}$ (239 $^\circ\text{F})$
- (A) 1-Ground : 0-4 volts with the ignition SW at ON position and the engine not running

O : Parts Location

Code			See Page		de	See Page	Code		See Page
	C9	3	34	G2	В	32	J4	А	35
G1	A	3	32	11	0	35	J5	В	35

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)


Sunction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)				
IG	25					
IK	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
IL						
IM	-					
1A	22	Engine Wire and Engine Room J/B (Engine Compartment Left)				
1B	<u> </u>					
3B	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)				

Conne : Conne


: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	38	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
IA4	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)
ll2	42	Engine Wire and Instrument Panel Wire (Blower Unit RH)







Engine Control




2004 COROLLA (EWD533U)



Engine Control






2004 COROLLA (EWD533U)

63

Engine Control



2004 COROLLA (EWD533U)

System Outline

The engine control system utilizes a microcomputer and maintains overall control of the engine, etc. An outline of engine control is given here.

1. Input Signals

(1) Engine coolant temp. signal system

The engine coolant temp. sensor detects the engine coolant temp. and has a built–in thermistor with a resistance which varies according to the engine coolant temp. Thus the engine coolant temp. is input as a control signal to TERMINAL THW of the engine control module.

- (2) Intake air temp. signal system The intake air temp. sensor is installed in the mass air flow meter and detects the intake air temp., which is input as a control signal to TERMINAL THA of the engine control module.
- (3) Power steering oil pressure signal system

Power steering oil pressure is detected by the power steering oil pressure SW and is input as a control signal to TERMINAL PSW of the engine control module.

(4) RPM signal system

Camshaft position and crankshaft position are detected by the camshaft position sensor and crankshaft position sensor. Camshaft position is input as a control signal to TERMINAL G2+ of the engine control module, and engine RPM is input into TERMINAL NE+.

(5) Throttle signal system

The throttle position sensor detects the throttle valve opening angle, which is input as a control signal to TERMINAL VTA of the engine control module.

(6) Vehicle speed signal system

The vehicle speed is detected by the ABS speed sensor and the signal is input to TERMINAL SPD of the engine control module via the comb. meter and the skid control ECU with actuator. (w/ ABS)

The vehicle speed is detected by the vehicle speed sensor installed in the transaxle and the signal is input to TERMINAL SPD of the engine control module via the comb. meter. (w/o ABS)

(7) NSW signal system (A/T)

The Park/Neutral position SW detects whether the shift position is in neutral or not, and inputs a control signal to TERMINAL NSW of the engine control module.

(8) A/C SW signal system

The operating voltage of the A/C SW is detected and is input as a control signal to TERMINAL A/CS of the engine control module.

(9) Battery signal system

Voltage is constantly applied to TERMINAL BATT of the engine control module. When the ignition SW is turned to on, voltage for engine control module operation is applied via the EFI relay to TERMINAL +B of the engine control module.

(10) Intake air volume signal system

Intake air volume is detected by the mass air flow meter, and is input as a control signal to TERMINAL VG of the engine control module.

(11) STA signal system

To confirm that the engine is cranking, the voltage applied to the starter motor during cranking is detected and is input as a control signal to TERMINAL STA of the engine control module.

(12) Oxygen sensor signal system

The oxygen density in the exhaust gases is detected and is input as a control signal into TERMINALS OX1A and OX1B of the engine control module. To maintain stable detection performance by the oxygen sensor, a heater is used for warming the sensor. The heater is also controlled by the engine control module (HT1A and HT1B).

(13) Engine knock signal system

Engine knocking is detected by the knock sensor and input as a control signal to TERMINAL KNK1 of the engine control module.

(14) Electrical load signal system

When systems which cause a high electrical load such as the rear window defogger, taillight are turned on, a signal is input to TERMINALS ELS and ELS2 as a control signal.

(15) Vapor pressure signal system

Vapor pressure is detected by the vapor pressure sensor and is input as a control signal to TERMINAL PTNK of the engine control module.

2. Control System

* SFI system

The SFI system monitors the engine conditions through the signals, which are input from each sensor to the engine control module. Based on this data and the program memorized in the engine control module, the most appropriate fuel injection timing is decided and current is output to TERMINALS #10, #20, #30 and #40 of the engine control module, operating the injectors (to inject fuel). This is the system which finely controls the fuel injection in response to the driving conditions, through the engine control module.

* ESA system

The ESA system monitors the engine conditions using the signals, which are input to the engine control module from each sensor. Based on this data and the program memorized in the engine control module, the most appropriate ignition timing is decided and current is output to TERMINALS IGT1, IGT2, IGT3 and IGT4 of the engine control module. This output controls the ignition coil and igniter No. 1, No. 2, No. 3 and No. 4 to produce the most appropriate ignition timing for the driving conditions.

* IAC system

The IAC system increases the RPM and provides idle stability for fast idle–up when the engine is cold, and when the idle speed has dropped due to electrical load and so on. The engine control module evaluates the signals from each sensor, and outputs current to TERMINAL RSO to control the idle air control valve.

* Knock control system

Knock control system controls the gate based on the engine rotation speed and detects knocking by the peak value of the knock sensor output during the gate open period, and then controls it to the most suitable ignition timing in proportion to the driving condition.

* Evapoparge control system

This system leads the vapor stuck to the canister to the serge tank in order not to agitate the air fuel by adjusting the fuel injection volume.

The signal at this time will be output from TERMINAL EVP of the engine control module to VSV (EVAP).

3. Diagnosis System

With the diagnosis system, when there is a malfunctioning in the engine control module signal system, the malfunction system is recorded in the memory. The malfunctioning system can be found by reading the display (Code) of the malfunction indicator lamp.

4. Fail–Safe System

When a malfunction occurs in any system, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail–safe system either controls the system by using the data (Standard values) recorded in the engine control module memory or else stops the engine.

Service Hints

C/OPN Relay 5-3: Closed with the starter running and the engine running **EFI Relav** 5-3 : Closed with the ignition SW at ON or ST position E2 Engine Coolant Temp. Sensor 1–2 : Approx. 15.04 kΩ (–20°C, –4°F) Approx. 5.74 kΩ (0°C, 32°F) Approx. 2.45 kΩ (20°C, 68°F) Approx. 0.318 kΩ (80°C, 176°F) E3 (A), E4 (B), E5 (C), E6 (D) Engine Control Module Voltage at engine control module wiring connectors +B-E1 : 9-14 volts (Ignition SW at ON position) VC-E1: 4.5-5.5 volts (Ignition SW at ON position) VTA-E1: 0.3-0.8 volts (Ignition SW on and throttle valve fully closed) : 3.2-4.9 volts (Ignition SW on and throttle valve fully open) EVG-E1: 3.3-3.9 volts (Ignition SW at ON position) THA-E1 : 0.5-3.4 volts (Engine idling and intake air temp. 0-80°C, 32-176°F) THW-E1: 0.2-1.0 volts (Engine idling and engine coolant temp. 60-120°C, 140-248°F) STA-E1 : 6-14 volts (Engine cranking) IGT1, IGT2, IGT3, IGT4-E1 : Pulse generation (Engine idling) IGF-E1 : Pulse generation (Engine idling) FC-E1 : 9-14 volts (Ignition SW on and engine stopping) 0-3 volts (Engine idling) W-E1: 9-14 volts (Engine idling and warning light off) A/CS-E1: 9-14 volts (Ignition SW on and A/C SW off) SPD-E1 : Pulse generation (Driving approx. 20 km/h) ELS-E1: 7.5-14 volts (Ignition SW on and taillight on) ELS2-E1: 7.5-14 volts (Ignition SW on and rear window defogger on) NSW-E1: 0-3 volts (Engine cranking) #10, #20, #30, #40-E1 : Pulse generation (Engine idling) NE+ -NE- : Pulse generation (Engine idling) RSO-E1 : Pulse generation (Engine idling) G2+ -NE- : Pulse generation (Engine idling) TBP-E1: 9.0-14.0 volts (Ignition SW on) PTNK-E1: 3.0-3.6 volts (Ignition SW at ON position and remove fuel cap) OX1A, OX1B-E1 : Pulse generation (Maintain engine speed at 2500 rpm for two minutes after warming up.) HT1A, HT1B-E1: 9.0-14.0 volts (Ignition SW at ON position) 0-3.0 volts (Engine idling) KNK1-E1 : Pulse generation (Engine idling) EVP-E1: 9.0-14.0 volts (Ignition SW at ON position) TACH-E1 : Pulse generation (Engine idling)

O : Parts Location

Co	de	See Page	Co	de	See Page	Co	de	See Page
A	2	32	F10 \$		36	J4	А	35
A	13	34	Н	5	32	J5	В	35
C	:1	32	Н	8	35	J	6	35
C	2	32	1	1	33	J	7	35
C	3	32	L	2	33	K	1	33
C	C8 34		13		33	M1		33
С	C9 34 I		4	33	P1		33	
C	12	34	15		33	S1		33
C	14	34	I	6	33	S9		35
D	1	34	ľ	7	33	T1 3		33
E	2	32	l.	8	33	V	1	33
E3	А	34	1	9	33	V	2	33
E4	В	34	1	0	35	V	3	33
E5	С	34	J2	А	35	V	4	37
E6	D	34	J3	В	35	V	5	37

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1 22 Engine Room R/B (Engine Compartment Left)		
3 28 RH R/B (Right Side of the Instrument Panel Reinforcement)		

Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)				
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)				
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)				
IG						
IH	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
Ш	- 25					
IJ						
IK						
IL	24					
IM						
1A	22	Engine Wire and Engine Room J/B (Engine Compartment Left)				
3B	20	Jactrument Depel Wire and DU J/D (Dight Side of the Jactrument Depel Deinfersement)				
3C	- 28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)				
4B	20	Instrument Depel Wire and Center I/P (Pehind the Combination Mater)				
4C	- 30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)				

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)				
EA1	38	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)				
IA2						
IA4		Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)				
IA5	40					
IA6						
ID2	42	Instrument Panel Wire and Floor Wire (Left Kick Panel)				
ll1	40	En elle Miller and Instrument Devisit Miller (Discuss Lis's DU)				
ll2	42	Engine Wire and Instrument Panel Wire (Blower Unit RH)				


Second Points


•		
Code	See Page	Ground Points Location
EB	- 38	Laft Side of the Oulinder Head
EC		Left Side of the Cylinder Head
ED	38	Front Left Suspension Tower
IE	40	Behind the Combination Meter
IG	40	Right Kick Panel
BH	44	Under the Left Quarter Pillar

Splice Points


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E2	38	Engine Wire	17	42	Instrument Panel Wire
E3			I10	42	Engine Wire
12	42	Instrument Panel Wire	I11		
14					

Headlight





Headlight



System Outline

The current is always flowing from the HEAD MAIN fuse to HEAD relay (Coil side) to TERMINAL 6 of the daytime running light relay, from ECU–B fuse to TERMINAL 3 of the daytime running light relay and from the TAIL fuse to TAIL relay (Coil side) to TERMINAL 14 of the daytime running light relay (USA).

When the ignition SW is turned on, the current flowing through the GAUGE fuse flows to TERMINAL 12 of the daytime running light relay.

1. Daytime Running Light Operation

When the engine is started, voltage generated at TERMINAL L of the generator is applied to TERMINAL 8 of the daytime running light relay. If the parking brake lever is pulled up (Parking brake SW on) at this time, the relay is not activated so the daytime running light system does not operate. If the parking brake lever is then released (Parking brake SW off), a signal is input to TERMINAL 11 of the relay.

This activates the daytime running light relay and the HEAD relay is turned to on, so the current flows from the HEAD MAIN fuse to the HEAD relay (Point side) to HEAD LH LWR, HEAD RH LWR fuses to TERMINAL 2 of the headlights to TERMINAL 1 to TERMINAL 1 of the daytime running light relay to TERMINAL 2 to GROUND, causing the headlights to light up (Headlights light up dimmer than normal brightness.). Once the daytime running light system operates and the headlights light up, the headlights remain on even if the parking brake lever is pulled up (Parking brake SW on).

If the engine stalls and the ignition SW remains on, the headlights remain light up even through current is no longer output from TERMINAL L of the generator. If the ignition SW is then turned off, the headlights go off.

If the engine is started with the parking brake lever released (Parking brake SW off), the daytime running light system operates and headlights light up when the engine starts.

2. Headlight Operation

When the light control SW is switched to Head position and the dimmer SW is set to Low position, causing the daytime running light relay and the HEAD relay to turn on, so the current flows from the HEAD MAIN fuse to HEAD relay (Coil side) to TERMINAL 6 of the daytime running light relay to TERMINAL 7 to TERMINAL 12 of the light control SW to TERMINAL 11 to GROUND. The current to HEAD relay (Point side) then flows to HEAD LH LWR, HEAD RH LWR fuses to TERMINAL 2 of the headlights (Low) to TERMINAL 1 to TERMINAL 1 of the daytime running light relay to TERMINAL 2 to GROUND, causing the headlights to light up at normal intensity.

When the light control SW is switched to Head position and the dimmer SW is set to High position, the signal from the dimmer SW is input to the daytime running light relay. This activates the daytime running light relay and the HEAD relay is turned on, so the current flows from the HEAD MAIN fuse to HEAD relay (Point side) to TERMINAL 1 of the DIMMER relay to TERMINAL 2 to TERMINAL 13 of the daytime running light relay, activating the DIMMER relay. This causes current to flow from TERMINAL 3 of the DIMMER relay to TERMINAL 5 to HEAD LH UPR, HEAD RH–UPR fuses to TERMINAL 2 of the headlights (High) to TERMINAL 1 to GROUND, causing the headlights to light up at high beam and the high beam indicator light to light up.

When the dimmer SW is switched to Flash position, the signal from the dimmer SW is input to the daytime running light relay. This activates the daytime running light relay and the HEAD relay is turned on, so the current flows from the HEAD MAIN fuse to HEAD relay (Point side) to TERMINAL 1 of the DIMMER relay to TERMINAL 2 to TERMINAL 13 of the daytime running light relay, activating the DIMMER relay, and also flows from the HEAD LH UPR, HEAD RH UPR fuses to TERMINAL 2 of the headlights to TERMINAL 1 to GROUND, causing the headlights to light up at high beam and the high beam indicator light to light up.

3. Automatic Light Control Operation (USA)

When the daytime running light is operating and the Automatic control sensor detects a decrease in the ambient light, the automatic light control operation starts. At the same time, daytime running light relay is activated, so current flows from the TAIL fuse to the TAIL relay (Coil side) to TERMINAL 14 of the daytime running light relay, and the HEAD MAIN fuse to the HEAD relay (Coil side) to TERMINAL 6 of the daytime running light relay, activating both the TAIL relay and the HEAD relay, so that the taillights and headlights light up.

When the automatic light control sensor detects an increase in the ambient light, the ignition SW is turned to off, the light control SW is turned to Head position, and the automatic light control operation stops.

Headlight

- Service Hints

HEAD Relay

1–2 : Closed with the light control SW at Head position or the dimmer SW at Flash position Closed with the engine running and the parking brake lever is released (Parking brake SW off)

D2 Daytime Running Light Relay

- 12-Ground : Approx. 12 volts with the ignition SW at ON position
- 7–Ground : Approx. 12 volts with the light control SW at Head position or the dimmer SW at Flash position
- 3, 6, 14–Ground : Always approx. 12 volts
 - 11-Ground : Continuity with the parking brake lever pulled up
 - 8–Ground : 13.2–14.0 volts with the engine running at 5000 rpm and 115°C (239°F)
 - 2-Ground : Always continuity
 - 16-Ground : Continuity with the dimmer SW at High or Flash position
 - 10-Ground : Continuity with the brake fluid level not enough or the parking brake lever pulled up

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
A18	34	G1	32	J1	33
B2	32	H1	32	J6	35
C9	34	H2	32	P3	35
C12	34	H3	32	S1	33
D2	34	H4	32		

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

: Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)	
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)	
IG	05		
IH	- 25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)	
IL	24		
3B	20	Instrument Denel Wire and DLL I/D (Dight Side of the Instrument Denel Deinfersoment)	
3C	- 28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)	
4B	20	Instrument Densel Wire and Center I/D /Dehind the Combination Mater	
4C	- 30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)	

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2		
IA4	40	Engine Deem Main Wite and Instrument Devel Wite // off Side of the Instrument Devel Deinforcement)
IA5		Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)
IA6		
IE1	42 Instrument Panel Wire and Instrument Panel No.4 Wire (Behind the Combination Meter)	
112	42	Engine Wire and Instrument Panel Wire (Blower Unit RH)

•		
Code	See Page	Ground Points Location
EA	38	Front Right Fender
ED	38	Front Left Suspension Tower
IE	40	Behind the Combination Meter

Splice Points					
Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E4	38	Engine Room Main Wire	13	42	Engine Room Main Wire



FOG Relay

 \bigcirc

3-5 : Closed with light control SW at Head position, dimmer SW at Low position and fog light SW at On position

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
C12	34	F1	32	J6	35
D2	34	F2	32		

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)


: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)		
IG	25	Instrument Denal Wire and Instrument Denal I/D (Leuver Finish Denal)		
IH	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)		
3B	20	-		
3C	20	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)		


Connector Joining Wire Harness and Wire Harness

Code See Page Joining Wire Harness and Wire Harness (Connector Location)		Joining Wire Harness and Wire Harness (Connector Location)
IA5	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)

Code	See Page	Ground Points Location
EA	38	Front Right Fender
ED	38	Front Left Suspension Tower
IE	40	Behind the Combination Meter



* 1 : w/ Wireless Door Lock * 2 : w/o Wireless Door Lock



T2 Turn Signal Flasher Relay

1-Ground : Approx. 12 volts with the ignition SW at ON position

7–Ground : Always continuity

4-Ground : Always approx. 12 volts

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
C9	34	H7	35	R11	37
C12	34	J6	35	T2	35
F3	32	J7	35		
F4	32	R9	37		

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)	
1	22	Engine Room R/B (Engine Compartment Left)	


: Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)			
IC	25	ngine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)			
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)			
IG	0 5				
IH	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)			
IK					
IL	- 24				
ЗA					
3B	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)			
3C]				
4B	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)			

: Connector Joining Wire Harness and Wire Harness

Code	See Page	oining Wire Harness and Wire Harness (Connector Location)	
IA5	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)	

Code	See Page	Ground Points Location
EA	38	Front Right Fender
ED	38	Front Left Suspension Tower
IE	40	Behind the Combination Meter
IG	40	Right Kick Panel
BI	44	Lower Back Panel





Taillight

Service Hints

C12 Combination SW

10-13 : Continuity with the light control SW at Tail or Head position

TAIL Relay

7)

 \bigcirc

5--3 : Closed with the light control SW at Tail or Head position

O : Parts Location

Code	See Page	Code Se		See Page	Code	See Page
C12	34	J	1	33	L1	36
D2	34	J	6	35	L2	36
F3	32	J8	А	36	R9	37
F4	32	J9	В	36	R11	37

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

: Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)	
IB	25	Facine Dears Main With and Instrument Dears 1/0 (Lower Finish Dears)	
IC	IC 25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)	
ID	25	oor Wire and Instrument Panel J/B (Lower Finish Panel)	
IH	25	Instrument Denel Wire and Instrument Denel V/D (Lower Finish Denel)	
IL	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)	
1A	22	ngine Wire and Engine Room J/B (Engine Compartment Left)	
1C	22	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)	
4B	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)	


: Ground Points

•			
Code	See Page	Ground Points Location	
EA	38	ont Right Fender	
ED	38	Front Left Suspension Tower	
IE	40	Behind the Combination Meter	
BH	44	Under the Left Quarter Pillar	
BI	44	Lower Back Panel	

: Splice Points

-					
Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
14	42	Instrument Panel Wire			





Illumination

Service Hints

C12 Combination SW

10-13 : Continuity with the light control SW at Tail or Head position

TAIL Relay

5-3 : Closed with the light control SW at Tail or Head position

O : Parts Location

Code	See Page	Code	See Page	Co	ode	See Page
A8	34	C12	34	R3	А	35
A10	34	D2	34	R4	В	35
B5	34	E6	34	F	85	35
C6	34	H7	35	F	R7	35
C9	34	J6	35			

C : Relay Blocks

 \bigcirc

Code	See Page	elay Blocks (Relay Block Location)	
1	22	Engine Room R/B (Engine Compartment Left)	
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)	

: Junction Block and Wire Harness Connector

Code	Code See Page Junction Block and Wire Harness (Connector Location)					
IB	25	Engine Deem Main Mire and Instrument Decal I/D (Lower Finish Decal)				
IC	IC 25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)				
IH	25	Instrument Denal Wire and Instrument Denal I/D /Lewer Finish Denal)				
IL	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
1A	22	Engine Wire and Engine Room J/B (Engine Compartment Left)				
1C	22	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)				
4B	20	Leater meant Devel Wire and Center I/D (Debied the Centerion Mater)				
4C	- 30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)				


7 : Ground Points

Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter

: Splice Points


Code	Code See Page Wire Harness with Splice Points		Code	See Page	Wire Harness with Splice Points
14	I4 42 Instrument Panel Wire		15	42	Instrument Panel Wire

Interior Light



90





Interior Light

Service Hints

D4, D5, D6, D7 Door Courtesy SW Front LH, RH, Rear LH, RH

1–Ground : Closed with the door open

L4 Luggage Compartment Light SW

1-Ground : Closed with the luggage compartment door open

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
C9	34	I11 A	35	J10	36
D4	36	l12	36	L3	36
D5	36	l13	36	L4	36
D6	36	J6	35	M2	37
D7	36	J7	35	R7	35

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)		
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)		
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)		
IE	25	Roof Wire and Instrument Panel J/B (Lower Finish Panel)		
IF				
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)		
IH	-			
IK	24			
IL	24			
4B	20	Instrument Denel Wire and Center I/P (Pokind the Combination Mater)		
4C	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)		

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK1	42	Roof Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)

: Ground Points

Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter
IG	40	Right Kick Panel

: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	Code See Page Wire Harness with Splice Po	
B1	44	Roof Wire			



S9 Stop Light SW

2-1 : Closed with the brake pedal depressed

O : Parts Location

	Со	de	See Page	Co	de	See Page	Code	See Page
	Н	9	36	J9	В	36	R11	37
J	8	А	36	R	9	37	S9	35




Sunction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)

. .

Code	See Page	Ground Points Location
BH	44	Under the Left Quarter Pillar
BI	44	Lower Back Panel



A2 Back–Up Light SW (A/T)

2-3 : Closed with the shift lever at R position

B1 Back–Up Light SW (M/T)

2-1 : Closed with the shift lever at R position

O : Parts Location

Code	See Page	Code		See Page	Code	See Page
A2	32	J8	А	36	R10	37
B1	32	J9	В	36	R12	37
J4	35	J1	0	36		

_	
	•


: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)	
IG	25	Instrument Denel Wire and Instrument Denel V/D (Lewer Finish Denel)	
IK	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)	
ЗA	20	Instrument Denal Wire and DLL I/D /Dight Side of the Instrument Denal Deinfergement)	
3B	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)	

: Connector Joining Wire Harness and Wire Harness

Γ	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
	ll2	42	Engine Wire and Instrument Panel Wire (Blower Unit RH)

Code	See Page	Ground Points Location
BH	44	Under the Left Quarter Pillar
BI	44	Lower Back Panel



System Outline

With the ignition SW turned on, the current flows to TERMINAL 8 of the wiper and washer SW, TERMINAL 2 of the front wiper motor through the WIPER fuse, and the current flows to TERMINAL 2 of the washer motor through the WASHER fuse.

1. Low Speed Position

With wiper SW turned to LO position, the current flows from TERMINAL 8 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and causes to the front wiper motor to run at low speed.

2. High Speed Position

With wiper SW turned to HI position, the current flows from TERMINAL 8 of the front wiper and washer SW to TERMINAL 9 to TERMINAL 4 of the front wiper motor to TERMINAL 5 to GROUND and causes to the wiper motor to run at high speed.

3. INT Position

With wiper SW turned to INT position, the relay operates and the current which is connected by relay function flows from TERMINAL 8 of the front wiper and washer SW to TERMINAL 5 to GROUND. This flow of current operates the intermittent circuit and the current flows from TERMINAL 8 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and the functions.

The intermittent operation is controlled by the charge/discharge function of the condenser installed in the relay, and the intermittent time is controlled by a time control SW (w/ intermittent volume SW) to change the charging time of the condenser.

4. MIST Position

With wiper SW turned to MIST position, the current flows from TERMINAL 8 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and causes to the front wiper motor to run at low speed.

5. Washer Continuous Operation

With the washer SW turned to on, the current flows from TERMINAL 2 of the washer motor to TERMINAL 1 to TERMINAL 4 of the front wiper and washer SW to TERMINAL 5 to GROUND and causes to the washer motor to run, and the window washer jet operates. This causes the current to flow to washer continuous operation circuit in TERMINAL 8 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and the washer operates continuously.

Service Hints

C11 Combination SW

5-Ground : Always continuity

8-Ground : Approx. 12 volts with ignition SW at On position

- 7–Ground : Approx. 12 volts with wiper and washer SW at LO position
 - : Approx. 12 volts with wiper and washer SW at MIST position
 - : Approx. 12 volts every approx. 1 to 10 seconds intermittently with wiper and washer SW at INT position
- 6-Ground : Approx. 12 volts with ignition SW on unless wiper motor at STOP position
- 9-Ground : Approx. 12 volts with ignition SW on and wiper and washer SW at HI position

F6 Front Wiper Motor

2-3 : Closed unless wiper motor at STOP position

• : Parts Location

Г

Code	See Page	Code	See Page	Code	See Page
C11	34	F6	32		
F5	32	J6	35		

) : Junction Block and Wire Harness Connector


Code	See Page Junction Block and Wire Harness (Connector Location)	
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IL	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)

Wiper and Washer

•		
Code	See Page	Ground Points Location
EA	38	Front Right Fender
IE	40	Behind the Combination Meter



* 1 : w/ Wireless Door Lock * 2 : w/o Wireless Door Lock

102

HORN Relay

5–3 : Closed with the horn SW on.

O : Parts Location

1	Code	See Page	Code	See Page	Code	See Page
	C10	34	H6	32		

C : Relay Blocks


Code	See Page	Relay Blocks (Relay Block Location)	
1	22	Engine Room R/B (Engine Compartment Left)	

Sunction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
4A	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
	ł	

Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA5	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)



C5 Cigarette Lighter

- 2–Ground : Approx. 12 volts with the ignition SW at ACC or ON position
- 1-Ground : Always continuity

O : Parts Location


Code	See Page	Code	See Page	Code	See Page
C5	34	J6	35		



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
IF	IF 25 Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)		
ЗA	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)	

•		
Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter



C7 Clock

- 4-Ground : Approx. 12 volts with the ignition SW at ACC or ON position
- 1-Ground : Always approx. 12 volts
- 3-Ground : Approx. 12 volts with the light control SW at Tail or Head position
- 2–Ground : Always continuity

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
C7	34	D2	34	J7	35
C12	34	J6	35		

C : Relay Blocks

C

Code	See Page	Relay Blocks (Relay Block Location)	
1	22	Engine Room R/B (Engine Compartment Left)	
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)	

J : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)		
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)		
IF	05			
IH	- 25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)		
IL	24			
ЗA	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)		
4B	20	Lestrument Devel Wire and Center I/D (Debied the Centeringtion Mater)		
4C	- 30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)		

: Ground Points

Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter
IG	40	Right Kick Panel

) : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
14	42	Instrument Panel Wire			



2004 COROLLA (EWD533U)

P-POINT Relay

3–5 : Closed with ignition SW at ACC or ON position 1–Ground : Always continuity

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
C5	34	J7	35		
J6	35	P4	35		

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

Solution Junction Block and Wire Harness Connector

Code	See Page Junction Block and Wire Harness (Connector Location)		
IF			
IH	- 25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)	
ЗA	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)	


Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IF1	42	Console Box Wire and Instrument Panel Wire (Under the Instrument Panel Center)	

: Ground Points

V		
Code	See Page	Ground Points Location

Code	See Page	Sround Points Location	
IE	40	Behind the Combination Meter	
IG	40	Right Kick Panel	



R6 Remote Control Mirror SW

8-6 : Continuity with the operation SW at Down or Right position

- 6-7 : Continuity with the operation SW at Up or Left position
- 8-Ground : Approx. 12 volts with the ignition SW at ACC or ON position

7-Ground : Always continuity

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
J6	35	R17	37		
R6	35	R18	37		

Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
IF	25	25 Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)	
ЗA	20	Instrument Dens Wire and DLL I/D /Dight Side of the Instrument Dens Densfergement)	
3C	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)	
4B	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)	


: Connector Joining Wire Harness and Wire Harness

Code	See Page	ning Wire Harness and Wire Harness (Connector Location)	
IC2	40	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)	
IJ1	42	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)	

: Ground Points

•		
Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter

Automatic Glare–Resistant EC Mirror with Compass



* 1 : w/ Moon Roof * 2 : w/o Moon Roof

I12 Inner Mirror

- 7-Ground : Approx. 12 volts with the ignition SW at ON position
- 6-Ground : Always continuity

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
l12	36	J7	35		

 \bigcirc


: Junction Block and Wire Harness Connector


Code	See Page	See Page Junction Block and Wire Harness (Connector Location)	
IE	25	Roof Wire and Instrument Panel J/B (Lower Finish Panel)	
IH	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)	

: Ground Points

•		
Code	See Page	Ground Points Location
IG	40	Right Kick Panel

Code	e See Page Wire Harness with Splice Points		Code	See Page	Wire Harness with Splice Points
B1					





- System Outline

When the ignition SW is turned on, the current flows through the GAUGE fuse to TERMINAL 1 of the P/W relay to TERMINAL 2 to GROUND. This activates the relay and the current flows through the POWER fuse to TERMINAL 5 of the relay to TERMINAL 3 to TERMINAL B of the power window master SW, TERMINAL 4 of the power window control SW.

1. Manual Operation (Driver's Window)

With the ignition SW turned on and with the power window master SW (Front LH) in Up position, the current flowing to TERMINAL B of the power window master SW flows to TERMINAL DU of the master SW to TERMINAL 4 of the power window motor to TERMINAL 5 to TERMINAL DD of the master SW to TERMINAL E to GROUND and rotates the power window motor in the up direction. The window ascends only while the SW is being pulled. In down operation, the flows of current from TERMINAL B of the power window master SW to TERMINAL DD to TERMINAL 5 of the motor to TERMINAL 4 to TERMINAL DU of the master SW to TERMINAL E to GROUND, flowing in the opposite direction to manual up operation and rotating the motor in reverse, thus opening the window.

2. Auto Down Operation (Driver's Window)

When the front LH window control SW in the power window master SW is pushed strongly on the down side, current flows from TERMINAL B of the master SW to TERMINAL DD to TERMINAL 5 of the power window motor to TERMINAL 4 to TERMINAL DU of the master SW to TERMINAL E to GROUND. Because the hold circuit inside the master SW keeps the relay on the down side activated, the power window motor continues operating even if the power window master SW is released. When the driver's window is fully opened, the hold circuit turns off and the relay on the down side turns off, and auto down operation is completed.

3. Stopping of Auto Down Operation (Driver's Window)

When the master SW (Front LH) is pulled to the up side during auto down operation, a ground circuit opens in the master SW and current does not flow from TERMINAL DU of the master SW to TERMINAL E, so the motor stops, causing auto down operation to stop. If the master SW is pulled continuously, the motor rotates in the up direction in manual up operation.

4. Manual Operation (Front RH Window)

With the power window control SW (Front RH) pulled to the up side, current flowing from TERMINAL 4 of the power window control SW flows to TERMINAL 3 to TERMINAL 4 of the power window motor to TERMINAL 5 to TERMINAL 1 of the power window control SW to TERMINAL 2 to TERMINAL PD of the master SW to TERMINAL E to GROUND and rotates the power window motor (Front RH) in the up direction. Up operation continues only while the power window control SW is pulled to the up side. When the window descends, the current flowing to the motor flows in the opposite direction, from TERMINAL 4 to TERMINAL 5, and the motor rotates in reverse. When the window lock SW is pushed to the lock side, the ground circuit to the passenger's window becomes open. As a result, even if Open/Close operation of the passenger's window is attempted, the current from TERMINAL E of the power window master SW is not grounded and the motor does not rotate, so the passenger's window can not be operated and window lock occurs.

5. Manual Operation (Rear LH, Rear RH Window)

With the power window control SW (Rear LH, rear RH) pulled to the up side, current flowing from TERMINAL 4 of the power window control SW flows to TERMINAL 3 to TERMINAL 5 of the power window motor to TERMINAL 4 to TERMINAL 1 of the power window control SW to TERMINAL 2 to TERMINAL RLD, RRD of the master SW to TERMINAL E to GROUND and rotates the power window motor (Rear LH, rear RH) in the up direction. Up operation continues only while the power window control SW is pulled to the up side. When the window descends, the current flowing to the motor flows in the opposite direction, from TERMINAL 5 to TERMINAL 4, and the motor rotates in reverse. When the window lock SW is pushed to the lock side, the ground circuit to the passenger's window becomes open. As a result, even if Open/Close operation of the passenger's window is attempted, the current from TERMINAL E of the power window master SW is not grounded and the motor does not rotate, so the passenger's window can not be operated and window lock occurs.

Service Hints

D11 Power Window Master SW

B-Ground : Approx. 12 volts with the ignition SW at ON position

- DU-Ground : Approx. 12 volts with the ignition SW on and master SW (Front LH window) at Up position
- DD-Ground : Approx. 12 volts with the ignition SW on and master SW (Front LH window)
 - at Down or Auto Down position

E-Ground : Always continuity

Window Lock SW

Open with window lock SW at Lock position

O : Parts Location

 \bigcirc

Code	See Page	Code	See Page	Code	See Page
D11	36	P6	37	P9	37
J6	35	P7	37	P10	37
P5	37	P8	37	P11	37

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)				
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)				
IF	25	Instrument Dens Wire and Instrument Dens I //D // awar Finish Dens)				
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
4B	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)				

Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)			
IC1	40	Freet Deer I II Wire and leate we ant Devel Wire (Left Kiel, Devel)			
IC3	40	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)			
ID1	42	Instrument Panel Wire and Floor Wire (Left Kick Panel)			
IJ2	42	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)			
BA1	44	Rear Door LH Wire and Floor Wire (Left Center Pillar)			
BB1	44	Rear Door RH Wire and Instrument Panel Wire (Right Center Pillar)			

✓ : Ground Points

Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter


Code	See Page	See Page Wire Harness with Splice Points		See Page	Wire Harness with Splice Points
B4	B4 44 Front Door LH Wire				


Door Lock Control




2004 COROLLA (EWD533U)

* 1 : w/ Power Window * 2 : w/o Power Window







System Outline

The current always flows to TERMINAL 1 of the integration relay through the DOOR fuse.

1. Manual Lock Operation

When the door lock control SW or door key lock and unlock SW are operated to Lock position, a lock signal is input to TERMINAL (A) 9 or (A) 7 of the integration relay and causes the relay to function. The current flows from TERMINAL 1 of the relay to TERMINAL 2 to the door lock motors to TERMINALS (A) 1 and 3 of the relay to TERMINAL 9 to GROUND and the door lock motors locks the door.

2. Manual Unlock Operation

When the door lock control SW or door key lock and unlock SW are operated to Unlock position, an unlock signal is input to TERMINAL (A) 8, (A) 6 or (A) 5 of the integration relay and causes the relay to function. The current flows from TERMINAL 1 of the relay to TERMINALS (A) 1 and 3 to the door lock motors to TERMINAL 2 of the relay to TERMINAL 9 to GROUND and the door lock motors unlocks the door.

3. Double Operation Unlock Operation

When the door key lock and unlock SW LH is turned to the unlock side, only the driver's door is unlocked. By turning the door key lock and unlock SW LH to the unlock side, a signal is input to TERMINAL (A) 6 of the relay, and if the signal is input again within 3 seconds by turning the SW to the unlock side again, current flows from TERMINAL 3 of the integration relay to the door lock motors to TERMINAL 2 of the relay to TERMINAL 9 to GROUND, causing the door lock motors to operate and unlock the doors.

4. Ignition Key Reminder Operation

- * Operating door lock knob (Operation of door lock motors)
 - With the ignition key in the cylinder (Unlock warning SW on), when the door is opened and locked using door lock knob (Door lock motor), the door is locked once but each door is unlocked soon by the function of the relay. As a result, the current flows from TERMINAL 1 of the integration relay to TERMINALS (A) 1 and 3 to the door lock motors to TERMINAL 2 of the relay to TERMINAL 9 to GROUND and unlocks all the doors.
- * Operating door lock control SW or door key lock and unlock SW

With the ignition key in the cylinder (Unlock warning SW on), when the door is opened and locked using door lock control SW or key SW, the door is locked once but each door is unlocked by the function of SW contained in motors, and the signal is input to TERMINAL (A) 19 of the relay. According to this input signal, the current flows from TERMINAL 1 of the relay to TERMINALS (A) 1 and 3 to the door lock motors to TERMINAL 2 of the relay to TERMINAL 9 to GROUND and unlocks all the doors.

* In case of key less lock

With the ignition the key in the cylinder (Unlock warning SW on), when the unlock function is disturbed, for example pushing the door lock knob etc., the door holds on lock condition. After closing the door after, door courtesy SW inputs the signal into TERMINAL 5 or 6 or (A) 13 of the integration relay. By this input signal, the relay works and current flows from TERMINAL 1 of the relay to TERMINALS (A) 1 and 3 to the door lock motors to TERMINAL 2 of the relay to TERMINAL 9 to GROUND and unlocks all the doors.

I11 (A) Integration Relay

- 9–Ground : Always continuity
- 5-Ground : Continuity with the driver's door open
- 1-Ground : Always approx. 12 volts
- 2-Ground : Approx. 12 volts 0.2 seconds with following operation
 - * Door lock control SW locked
 - * Locking the driver's, front passenger's door cylinder with the key
- (A) 9–Ground : Continuity with the door lock control SW locked
- (A)13–Ground : Continuity with the front passenger's door open
- (A)19–Ground : Continuity with the driver's door lock knob unlocked
- (A) 8–Ground : Continuity with the door lock control SW unlocked
- (A) 5-Ground : Continuity with the front passenger's door lock cylinder unlock with the key
- (A) 6-Ground : Continuity with the driver's door lock cylinder unlocked with the key
- (A) 7-Ground : Continuity with the driver's, front passenger's door lock cylinder locked with the key
- (A) 1 or 3–Ground : Approx. 12 volts 0.2 seconds with following operation
 - * Door lock control SW unlocked
 - \ast Door lock control SW locked with the ignition key in cylinder and the driver's door open
 - (Ignition key reminder function)
 - * Door lock knob locked with the ignition key in cylinder and the driver's door open
 - (Ignition key reminder function)
 - * Unlocking the driver's, front passenger's door cylinder with the key

D4, D5, D6, D7 Door Courtesy SW Front LH, RH, Rear LH, RH

1-Ground : Closed with the door open

U1 Unlock Warning SW

1-2 : Closed with the ignition key in cylinder

O : Parts Location

Code	See Page	Code		See Page	Code		See Page
D4	36	D	9	36	D1	4	36
D5	36	D10	В	36	l11	А	35
D6	36	D11	А	36	J	6	35
D7	36	D1	2	36	J	7	35
D8	36	D1	3	36	U	1	35

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)					
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)					
IF							
IH	IH 25 IJ	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)					
IJ							
IK	24						
4A	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)					

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	40	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IJ2	42	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
BA1	44	Rear Door LH Wire and Floor Wire (Left Center Pillar)
BB1	44	Rear Door RH Wire and Instrument Panel Wire (Right Center Pillar)

: Ground Points


•		
Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter
IG	40	Right Kick Panel


Door Lock Control


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B3	44	Front Door RH Wire	B4	44	Front Door LH Wire



* 1 : w/ Power Window * 2 : w/o Power Window







System Outline

Door lock control (Lock and unlock) and panic control (TVIP alarm and flash) is performed by remote control, without the ignition key inserted in the door key cylinder, using low-power electrical waves emitted by a transmitter.

1. Wireless Door Lock or Unlock Normal Operation

With the ignition key not inserted into the ignition key cylinder (Unlock warning SW off) and all the doors completely closed, when the lock or unlock button (Transmitter) is pushed, the door control receiver receives the electrical waves from the transmitter, and sends a signal to the integration relay causing it to operate.

As a result, the integration relay judges whether the door is locked or unlocked based on the signal from the door lock motor and door unlock detection SW, and sends a signal to switch the condition from lock to unlock or vice versa, causing the door lock motor to operate.

2. Visual Confirmation of Lock or Unlock

If all doors indicate that they are locked after the lock command, parking lights and taillights will flash once. If any door indicates that it is open after the unlock command, parking lights and taillights will flash twice.

3. Wireless Door Unlock Operation

Pushing the unlock button (Transmitter) once, driver's door is unlocked. Furthermore, pushing the button again within 3 seconds, the other doors are unlocked.

4. Automatic Lock Operation

With the ignition key not inserted into the ignition key cylinder (Unlock warning SW off) and all the doors completely closed, after pushing the button (Transmitter) to unlock all the doors, if a door is not opened within 30 seconds, all the doors will be automatically relocked.

5. Wireless Control Stop Function

If a door is open (Door courtesy SW on), a signal is input from the door courtesy SW to the integration relay stopping wireless door lock or unlock.

If the ignition key is in the ignition key cylinder (Unlock warning SW on), the unlock warning SW inputs a signal to the integration relay stopping wireless door lock or unlock.

6. Repeat Function

In case an appropriate lock detection signal is not received after outputting a lock signal when pushing the lock button (Transmitter), 1 seconds later, the integration relay output the lock signal again.

7. Remote Panic Operation

Panic will function when doors are locked or unlocked, open or closed. When the panic button (Transmitter) is pushed once, theft alarm sounds and headlights and taillights flash. Then, the panic or the unlock button (Transmitter) is pushed once more, sounding and flashing will stop. Panic will not function when ignition key is in ignition key cylinder.

I11 (A) Integration Relay

- 9–Ground : Always continuity
- 5-Ground : Continuity with the driver's door open
- 1-Ground : Always approx. 12 volts
- 2-Ground : Approx. 12 volts 0.2 seconds with following operation
 - * Door lock control SW locked
 - * Locking the driver's, front passenger's door cylinder with the key
- (A) 9–Ground : Continuity with the door lock control SW locked
- (A)13–Ground : Continuity with the front passenger's door open
- (A)19–Ground : Continuity with the driver's door lock knob unlocked
- (A) 8–Ground : Continuity with the door lock control SW unlocked
- (A) 5-Ground : Continuity with the front passenger's door lock cylinder unlock with the key
- (A) 6-Ground : Continuity with the driver's door lock cylinder unlocked with the key
- (A) 7-Ground : Continuity with the driver's, front passenger's door lock cylinder locked with the key
- (A) 1 or 3–Ground : Approx. 12 volts 0.2 seconds with following operation
 - * Door lock control SW unlocked
 - * Door lock control SW locked with the ignition key in cylinder and the driver's door open
 - (Ignition key reminder function)
 - * Door lock knob locked with the ignition key in cylinder and the driver's door open
 - (Ignition key reminder function)
 - * Unlocking the driver's, front passenger's door cylinder with the key

D4, D5, D6, D7 Door Courtesy SW Front LH, RH, Rear LH, RH

1–Ground : Closed with the door open

U1 Unlock Warning SW

1-2: Closed with the ignition key in cylinder

D3 Door Control Receiver

- 5-Ground : Always approx. 12 volts
- 1–Ground : Always continuity

O : Parts Location

Code	See Page	Co	de	See Page	Co	de	See Page
D2	34	D	9	36	J	6	35
D3	36	D10	В	36	J	7	35
D4	36	D11	Α	36	J8	Α	36
D5	36	D	12	36	J9	В	36
D6	36	D	13	36	Т	2	35
D7	36	D	14	36	U	1	35
D8	36	111	Α	35			

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)				
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)				
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)				
IF						
IH	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
IJ						
IK	24					
3C	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)				
4A	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)				

Wireless Door Lock Control


Connector Joining Wire Harness and Wire Harness							
Code	See Page Joining Wire Harness and Wire Harness (Connector Location)						
IA2	10						
IA5	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)					
IC1	40	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)					
IJ2	42	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)					
BA1	44	Rear Door LH Wire and Floor Wire (Left Center Pillar)					
BB1	44	Rear Door RH Wire and Instrument Panel Wire (Right Center Pillar)					


: Ground Points


Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter
IG	40	Right Kick Panel
BH	44	Under the Left Quarter Pillar


: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B3	44	Front Door RH Wire	B4	44	Front Door LH Wire









TVIP System

Service Hints

- T3 TVIP ECU
- 10-Ground : Approx. 12 volts with the ignition SW at ON position
- 2-Ground : Always approx. 12 volts
- 29-Ground : Always continuity

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
A2	32	G3	35	L4	36
C8	34	H6	32	R7	35
D2	34	l10	35	S3	33
D4	36	I11 A	35	S4	35
D5	36	113	36	S8	35
D6	36	J2	35	T2	35
D7	36	J6	35	Т3	35
D8	36	J7	35	U1	35
D9	36	J10	36		

C : Relay Blocks

 \bigcirc

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

0.1	0						
Code	See Page	Junction Block and Wire Harness (Connector Location)					
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)					
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)					
IE	25	Roof Wire and Instrument Panel J/B (Lower Finish Panel)					
IF							
IG	25						
IH							
IK		Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)					
IL	24						
IM							
1A	22	Engine Wire and Engine Room J/B (Engine Compartment Left)					
ЗA		Lesteres et Desel Mine et d. D.L. VD (Disk) Others (the Lesteres et Desel Deis (etc. etc.))					
3C	- 28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)					
4A	20	Jactument Devel Wine and Center I/D /Debied the Combination Matery					
4B	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)					


: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)		
IA2				
IA4	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)		
IA5				
IC1	40	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)		
ID2	42	Instrument Panel Wire and Floor Wire (Left Kick Panel)		
ll1	40	Engine Wire and Instrument Danel Wire (Plauser Linit DLI)		
ll2	42	Engine Wire and Instrument Panel Wire (Blower Unit RH)		
IJ2	42	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)		

: Ground Points

Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter
IG	40	Right Kick Panel

	Splice Points				
Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
11	42	Instrument Panel Wire	18	40	Jacta and Decisi M/inc
12			19	42	Instrument Panel Wire
17					



System Outline

The moon roof can be operated when the ignition SW is turned to ON position.

1. Slide Open Operation

The moon roof fully opens automatically by pressing the slide open button of the moon roof control SW once. If the moon roof control switch is pressed again when the moon roof is operating, the movement of the moon roof stops. The operation of slide open is not worked when the moon roof at tilt up position.

2. Slide Close Operation

If you keep pressing the slide close button of the moon roof control SW when the moon roof is open, the moon roof closes half and stops the operation once. If you keep pressing the slide close once again, the moon roof fully closes.

3. Tilt Up Operation

If you press the tilt up button of the moon roof control SW, the moon roof is tilted up. However, the moon roof is not tilted up when it is open

4. Tilt Down Operation

If you press the tilt down button when the tilt up of the moon roof control SW is pressed, the moon roof is tilted down.

Service Hints

P/W Relay

5--3 : Closed with the ignition SW at ON position

M2 Moon Roof Control Relay and SW

2-Ground : Approx. 12 volts with the ignition SW at ON position

8–Ground : Always continuity

O : Parts Location


Code	See Page	Code	See Page	Code	See Page
J6	35	M2	37		
J7	35	M3	37		


J : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)			
IE	25	Roof Wire and Instrument Panel J/B (Lower Finish Panel)			
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)			
IH	25	Instrument Parier Wire and Instrument Parier J/B (Lower Finish Parier)			

Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter
IG	40	Right Kick Panel


—							
Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points		
B2	44	Roof Wire					





2004 COROLLA (EWD533U)

Electronically Controlled Transmission



Previous automatic transaxle have selected each gear shift using mechanically controlled throttle hydraulic pressure, governor hydraulic pressure and lock-up hydraulic pressure. The electronically controlled transmission, however, controls the line pressure and lock-up pressure etc. electrically, through the solenoid valve. The engine control module controls each solenoid valve based on the input signals from each sensor, which makes smooth driving possible by shift selection for each gear that is most appropriate to the driving conditions at that time.

1. Gear Shift Operation

During driving, the engine control module selects the shift for each gear which is most appropriate to the driving conditions, based on input signals from the engine coolant temp. sensor to TERMINAL THW of the engine control module, and also the input signals to TERMINAL SPD of the engine control module from the vehicle speed sensor devoted to the electronically controlled transmission. Current is then output to the electronically controlled transmission solenoid. When shifting to 1st speed, the current flows from TERMINAL S1 of the engine control module to TERMINAL 3 of the solenoid to GROUND, and from TERMINAL S2 of the engine control module to TERMINAL 6 of the electronically controlled transmission solenoid to GROUND, and continuity to the No.1 and No.2 solenoid causes the shift.

For 2nd speed, the current flows from TERMINAL S1 of the engine control module to TERMINAL 3 of the solenoid to GROUND, and from TERMINAL S2 of the engine control module to TERMINAL 6 of the solenoid to GROUND, and continuity to solenoids No.1 and No.2 causes the shift.

For 3rd speed, there is no continuity to No. 1 solenoid, only to No. 2, causing the shift.

Shifting into 4th speed (Overdrive) takes place when there is no continuity to both No.1 and No.2 solenoid.

2. Stop Light SW Circuit

If the brake pedal is depressed (Stop light SW on) when driving in lock-up condition, a signal is input to TERMINAL STP of the engine control module, the engine control module operates and continuity to the lock-up solenoid is cut.

3. Overdrive Circuit

* Overdrive on

When the engine is turned on from ignition off, the engine control module turns the O/D on. When the O/D main SW is pushed while the O/D is off, a signal is input into TERMINAL ODMS of the engine control module, and the O/D is turned on by the engine control module. In this case, the engine control module controls the gear shift according to the vehicle's driving condition, using the O/D range. At this time, the O/D off indicator light is off.

* Overdrive off

When the O/D main SW is pushed while the O/D is on, a signal is input into TERMINAL ODMS of the engine control module, and the O/D is turned off. At this time, the current flows through the O/D off indicator light to TERMINAL ODLP of the engine control module. As a result, the O/D off indicator light turns on, and the engine control module controls the gear shift according to the vehicle's driving condition, without using the O/D range.

Service Hints

E3 (A), E4 (B), E5 (C), E6 (D) Engine Control Module

S1, S2–E1 : 9.0–14.0 volts with the ignition SW on and the solenoid on

- 0–1.5 volts with the ignition SW on and the solenoid off
- L-E1: 7.5-14.0 volts with the ignition SW on and the shift lever at L position
- 2-E1: 7.5-14.0 volts with the ignition SW on and the shift lever at 2 position
- R-E1: 7.5-14.0 volts with the ignition SW on and the shift lever at R position
- STP-E1 : 9.0-14.0 volts with the brake pedal depressed

THW-E2 : 0.2-1.0 volts with the engine coolant temp. 60°C (140°F) -120°C (248°F) and engine idling

- VTA-E2 : 0.3-0.8 volts with the ignition SW on and the throttle valve fully closed
 - 3.2-4.9 volts with the ignition SW on and the throttle valve fully open
- VC-E2 : 4.5-5.5 volts with the ignition SW on
- ODMS-E1 : 9.0-14.0 volts with the ignition SW on
 - 0–3.0 volts with the ignition SW on and press continuously the O/D main SW
 - +B-E1 : 9.0-14.0 volts with the ignition SW on
- ODLP-E1 : Approx. 12 volts with the ignition SW on and the O/D main SW turned off

A2 A/T Shift Lever Position SW

- 3--2 : Closed with the shift lever in R position
- 3--4 : Closed with the shift lever in 2 position
- 3--8 : Closed with the shift lever in L position

O : Parts Location

Code	See Page	Co	de	See Page	Co	de	See Page
A2	32	E3	А	34	J4	А	35
A10	34	E4	В	34	J5	В	35
C9	34	E5	С	34	J	7	35
C14	34	E6	D	34	S	1	33
D1	34	I1	0	35	S	9	35
E1	32	J2	Α	35	Т	1	33
E2	32	J3	В	35	V	1	33

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

◯ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)		
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)		
IG	25			
IK		Lestwarent Devel Wire and lestwarent Devel I/D // succe Finish Devel		
IL	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)		
IM				
1A	22	Engine Wire and Engine Room J/B (Engine Compartment Left)		
ЗA				
3B	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)		
3C				
4B	20	Instrument Depart Wire and Contex I/D (Debind the Combination Mater)		
4C	- 30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)		

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	38	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
IA2		
IA4	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)
IA6		
ll1	40	Engine Wire and Instrument Banel Wire (Disuar Linit DLI)
ll2	42	Engine Wire and Instrument Panel Wire (Blower Unit RH)


: Ground Points

•			
Code	See Page	Ground Points Location	
EB	20	Laft Cide of the Outlinder Hand	
EC	38	Left Side of the Cylinder Head	
ED	38	Front Left Suspension Tower	
IG	40	Right Kick Panel	

: Splice Points

_						
	Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
	12	42	Instrument Panel Wire			





The current is applied at all times through the STOP fuse to TERMINAL 2 of the stop light SW.

With the ignition SW turned to on, the current flows through the MAIN fuse to AM2 fuse to ignition SW (IG2) to TERMINAL 32 of the combination meter and the current through the ECU–IG fuse flows to TERMINAL 2 of the cruise control ECU.

When the ignition SW is on and the CRUISE SW is turned on, a signal is input from TERMINAL 2 of the cruise control SW to TERMINAL 1 of the cruise control ECU. As a result, the cruise control ECU functions and the current flows from the ECU–IG fuse to TERMINAL 2 of the cruise control ECU to TERMINAL 16 of the cruise control ECU to GROUND, and the cruise control system is in a condition ready for operation.

At the same time, the current flows through the MAIN fuse to AM2 fuse to ignition SW (IG2) to TERMINAL 32 of the cruise indicator light to TERMINAL 23 to TERMINAL 5 of the cruise control ECU to TERMINAL 16 to GROUND, causing the cruise indicator light to light up, indicating that cruise control is ready for operation.

1. Set Operation

When the CRUISE SW is turned on and the SET SW is pushed with the vehicle speed within the set limit (Approx. 40 km/h, 25 mph to 200 km/h, 124 mph), a signal is input to TERMINAL 11 of the cruise control ECU, and the vehicle speed at the time the SET SW is released is memorized in the ECU as the set speed.

2. Set Speed Control

During cruise control driving, the ECU compares the set speed memorized in the ECU with the actual vehicle speed input into TERMINAL 12 of the cruise control ECU from the combination meter, and controls the cruise control actuator to maintain the set speed.

When the actual speed is lower than the set speed, the ECU causes the current to the cruise control actuator to flow from TERMINAL 15 of the cruise control ECU to TERMINAL 1 of the cruise control actuator to TERMINAL 2 to TERMINAL 7 of the cruise control ECU. As a result, the motor in the cruise control actuator is rotated to open the throttle valve and the throttle cable is pulled to increase the vehicle speed. When the actual driving speed is higher than the set speed, the current to the cruise control actuator flows from TERMINAL 7 of the ECU to TERMINAL 2 of the cruise control actuator to TERMINAL 15 of the cruise control actuator to TERMINAL 1 to TERMINAL 15 of the cruise control ECU.

This causes the motor in the cruise control actuator to rotate to close the throttle valve and return the throttle cable to decrease the vehicle speed.

3. Coast Control

During cruise control driving, while the COAST SW is on, the cruise control actuator returns the throttle cable to close the throttle valve and decrease the driving speed. The vehicle speed when the COAST SW is turned off is memorized, and the vehicle continues at the new set speed.

4. Accel Control

During cruise control driving, while the ACC SW is turned on, the cruise control actuator pulls the throttle cable to open the throttle valve and increase the driving speed.

The vehicle speed when the ACC SW is turned off is memorized and the vehicle continues at the new set speed.

5. Resume Control

Unless the vehicle speed falls below the minimum speed limit (Approx. 40km/h, 25mph) after canceling the set speed by the CANCEL SW, pushing the RES SW will cause the vehicle to resume the speed set before cancellation.

6. Manual Cancel Mechanism

If any of the following operations occurs during cruise control operation, the magnetic clutch of the actuator turns off and the motor rotates to close the throttle valve and the cruise control is released.

- * Placing the shift lever to positions except "D" position (Park/Neutral position SW except "D" position)(A/T), depressing the clutch pedal (Cruise control clutch SW off)(M/T). "Signal is not input to TERMINAL 4 of the ECU"
- * Depressing the brake pedal (Stop light SW on). "Signal input to TERMINAL 3 of the ECU"
- * Pushing the CANCEL SW (CANCEL SW on). "Signal input to TERMINAL 1 of the ECU"
- * Pushing the CRUISE SW off "signal input to TERMINAL 1 of the ECU".

7. Tap–Up Control Function

When the difference between the actual vehicle speed and the set speed is less than 5 km/h (3 mph), the set speed can be increased 1.6 km/h (1 mph) each time by operating the RES/ACC SW quickly within 0.6 seconds.

8. Tap–Down Control Function

When the difference between the actual vehicle speed and the set speed is less than 5 km/h (3 mph), the set speed can be lowered 1.6 km/h (1 mph) each time by operating the SET COAST SW quickly within 0.6 seconds.

9. Auto Cancel Function

A) If any of the following operating conditions occurs during cruise control operation, the set speed is erased, current flow to the magnetic clutch is stopped and the cruise control is released, (CRUISE SW turns off).

When this occurs, the ignition SW must be turned off once before the CRUISE SW will turn on.

- * When current continues to flow to the motor inside the actuator in the throttle valve "OPEN" direction.
- * The motor does not operate despite the motor drive signal being output.

B) If any of the following operating conditions occurs during cruise control operation, the set speed is erased, current flow to the magnetic clutch is stopped and the cruise control is released. (CRUISE SW turn off).

When this occurs, the cancel state is cleared as the CRUISE SW will turn on again.

* Over current to transistor driving the motor or the magnetic clutch.

- * Open circuit in the magnetic clutch.
- * Momentary interruption of vehicle speed signal.
- * Short circuit in the cruise control SW.

C) If any of the following conditions occurs during cruise control operation, the set speed is erased and the cruise control is released. (The power to the magnetic clutch is cut off until the SET SW is "ON" again.)

- * When the vehicle speed falls below the minimum speed limit, approx. 40 km/h (25 mph)
- * When power to the cruise control system is momentarily cut off.

10. Automatic Transaxle Control Function (A/T)

- * In overdrive. If the vehicle speed becomes lower than the overdrive cut speed (Set speed minus approx. 4 km/h, 2.5 mph) during cruise control operation, such as driving up a hill, the overdrive is released and the power is increased to prevent a reduction in vehicle speed.
- * After releasing the overdrive, if the vehicle speed becomes higher than the overdrive return speed (Set speed minus approx. 2 km/h, 1.2 mph) and the ECU judges by the signals from the actuator's potentiometer that the upward slope has finished, the overdrive is resumed after approximately 2 seconds.
- * During cruise control driving, the cruise control operation signal is output from the cruise control ECU to the engine control module. Upon receiving this signal, the engine control module changes the shift pattern to normal.

To maintain smooth cruise control operation (on a downward slope etc.), the lock-up release of the transaxle when the idling point of the throttle position is "ON" is forbidden.

Service Hints

C10 Combination SW

- 2-3 : Continuity with the CRUISE SW on
- 2–3 : Approx. 1540 Ω with the CANCEL SW on Approx. 240 Ω with the RES/ACC SW on Approx. 630 Ω with the SET/COAST SW on

C14 Cruise Control ECU

- 2-Ground : 12 volts with the ignition SW at ON position
- 1–Ground : Approx. 1540 Ω with the CANCEL SW on in the control SW Approx. 630 Ω with the SET/COAST SW on in the control SW Approx. 240 Ω with the RES/ACC SW on in the control SW
- 16–Ground : Always continuity

O : Parts Location

Code	See Page	Code		See Page	Code		See Page
A2	32	D1		34	J3	В	35
C4	32	E4	В	34	J4		35
C9	34	E5	С	34	J6		35
C10	34	E6	D	34	S9		35
C13	34	1	0	35			
C14	14 34		А	35			

) : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

Cruise Control


Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IF	05	
IG	- 25	
IK		Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IL	24	
IM		
1A	22	Engine Wire and Engine Room J/B (Engine Compartment Left)
3B	28	Instrument Denal Wire and DLI I/D (Dight Side of the Instrument Denal Deinforcement)
3C	20	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4B	20	Instrument Denal Wire and Center I/P (Pehind the Combination Mater)
4C	- 30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	oining Wire Harness and Wire Harness (Connector Location)						
IA4	40							
IA5	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)						
ll1	40	Engine Wire and Instrument Panel Wire (Blower Unit RH)						
112	42							

v		
Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter





ABS is a brake system designed to improve the operating ability and securing the stability of the vehicle by preventing the lock–up of the vehicle by controlling the wheel cylinder pressure of all the four wheels at the time of sudden braking.

1. Input Signals

(1) Speed sensor signal

The speed of the wheels is detected and input to TERMINALS FL+, FR+, RL+, and RR+ of the skid control ECU and actuator.

(2) Stop light SW signal

A signal is input to TERMINAL STP of the skid control ECU with actuator when brake pedal is depressed.

2. System Operation

When the wheels are locked-up, the solenoid inside the actuator is controlled by the signal from the skid control ECU with actuator, and the brake fluid in the wheel cylinder will flow through the reservoir and reduce the hydraulic pressure.

While the ABS is in operation, as the skid control ECU with actuator always outputs the operation signal to the pump inside the actuator, and the brake fluid stored inside the reservoir will be sucked up by the pump inside the actuator and returned to the master cylinder.

When the hydraulic pressure of the wheel cylinder is decompressed or increased until the necessary hydraulic pressure, the solenoid inside the actuator is controlled by the control signal from the skid control ECU with actuator and as a result, hydraulic pressure of the wheel cylinder will be closed at both the master cylinder and reservoir sides routes, and the hydraulic pressure of the wheel cylinder will be in the hold condition.

If increase of the hydraulic pressure volume of the wheel cylinder becomes necessary, the control signals from the skid control ECU with actuator control the solenoid inside the actuator, to resume to the normal condition. Thus the brake fluid of the master cylinder will be sent to the wheel cylinder and will increase the hydraulic pressure of the wheel cylinder. At this time, in the case that the brake fluid is left in the reservoir, it will be sucked up by the pump inside the actuator and will be sent to the wheel cylinder.

Service Hints

A3, A4 ABS Speed Sensor Front LH, RH

2-1: 0.92 -1.22 kΩ (25°C, 77°F)

A19, A20 ABS Speed Sensor Rear LH, RH

1–2 : 1.0 –1.4 kΩ (25°C, 77°F)

S1 Skid Control ECU with Actuator

23, 1-Ground : Always continuity

- 3-Ground : Approx. 12 volts with the ignition SW at ON position
- 16–Ground : Approx. 12 volts with the brake pedal depressed
- 2, 24–Ground : Always approx. 12 volts

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
A3	32	C9	34	P3	35
A4	32	D1	34	S1	33
A19	36	D2	34	S9	35
A20	36	l10	35		
B2	32	J6	35		

C : Relay Blocks

Code See Page Relay Blocks (Relay Block Location)		Relay Blocks (Relay Block Location)
1 22 Engine Room R/B (Engine Compartment Left)		Engine Room R/B (Engine Compartment Left)

◯ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)				
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)				
IG	25					
IK	24	hadren ad David Mire and Hadren ad David VD (Lever Fisial David)				
IL		Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
IM						
1A	22	Engine Wire and Engine Room J/B (Engine Compartment Left)				
3B	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)				
4B	20	Instrument Denel Wire and Center I/P (Dekind the Combination Meter)				
4C	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)				

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)					
IA4							
IA5	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)					
IA6							
IB1	40	Engine Room Main Wire and Floor Wire (Cowl Side Panel LH)					
BC1	44 Skid Control Sensor Wire LH and Floor Wire (Quarter Wheel House LH)						
BD1	44	Skid Control Sensor Wire RH and Floor Wire (Quarter Wheel House RH)					

Ground Points

Code	See Page	Ground Points Location	
EA	38	Front Right Fender	
ED	38	Front Left Suspension Tower	
IE	40	Behind the Combination Meter	


: Splice Points

(


(Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points	
	E1 38 Engine Room Main Wire		Engine Room Main Wire				


NOTICE: When inspecting or repairing the SRS, perform the operation in accordance with the following precautionary instructions and the procedure and precautions in the Repair Manual for the applicable model year.

- Malfunction symptoms of the SRS are difficult to confirm, so the DTCs become the most important source of information when troubleshooting. When troubleshooting the SRS, always inspect the DTCs before disconnecting the battery.
- Work must be started after 90 seconds from when the ignition switch is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.
 (The SRS is equipped with a back-up power source so that if work is started within 90 seconds from disconnecting the negative (-) terminal cable of the battery, the SRS may be deployed.)
- When the negative (-) terminal cable is disconnected from the battery, the memory of the clock and audio system will be canceled. So before starting work, make a record of the contents memorized in the audio memory system. When work is finished, reset the audio systems as they were before and adjust the clock. This vehicle has power tilt and power telescopic steering, power seat and power outside rear view mirror which are all equipped with memory function. However, it is not possible to make a record of the memory contents. So when the work is finished, it will be necessary to explain this fact tot the customer, and ask the customer to adjust the features and reset the memory. To avoid erasing the memory in each memory system, never use a back-up power supply from outside the vehicle.
- Before repairs, remove the airbag sensor if shocks are likely to be applied to the sensor during repairs.
- Do not expose the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt pretensioner, airbag sensor assembly, front airbag sensor assembly or side airbag sensor assembly directly to hot air or flames.
- Even in cases of a minor collision where the SRS does not deploy, the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt pretensioner, airbag sensor assembly, front airbag sensor assembly and side airbag sensor assembly should be inspected.
- Never use SRS parts from another vehicle. When replacing parts, replace them with new parts.
- Never disassemble and repair the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt pretensioner, airbag sensor assembly, front airbag sensor assembly or side airbag sensor assembly in order to reuse it.
- If the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt pretensioner, airbag sensor assembly, front airbag sensor assembly or side airbag sensor assembly has been dropped, or if there are cracks, dents or other defects in the case, bracket or connector, replace them with new ones.
- Use a volt/ohmmeter with high impedance (10 kΩ/V minimum) for troubleshooting the system's electrical circuits.
- Information labels are attached to the periphery of the SRS components. Follow the instructions on the notices.
- After work on the SRS is completed, perform the SRS warning light check.
- If the vehicle is equipped with a mobile communication system, refer to the precaution in the IN section of the Repair Manual.



* 1 : w/ Side Airbag





The SRS is a driver and front passenger protection device which has a supplemental role to the seat belts.

When the ignition SW is turned to ON, current from the MAIN fuse flows to AM2 fuse to ignition SW (IG2) to TERMINAL (B) 5 of the airbag sensor assembly.

If an accident occurs while driving, when the frontal impact exceeds a set level, the current from the TERMINAL (B) 5 of the airbag sensor assembly flows to TERMINALS (B) 14, (B) 16, (B) 10, (B) 8, (A) 2 and (C) 5 of the airbag sensor assembly to the airbag squibs and the pretensioners to TERMINALS (B) 13, (B) 17, (B) 11, (B) 7, (A) 1 and (C) 6 of the airbag sensor assembly to TERMINAL (B) 20, (B) 27 or BODY GROUND to GROUND, so that the current flows to the front airbag squibs and the pretensioners, and causes them to operate.

When the side impact also exceeds a set level, the current from the TERMINAL (B) 5 of the airbag sensor assembly flows to TERMINALS (A) 6 and (C) 1 of the airbag sensor assembly to the side airbag squibs to TERMINALS (A) 5 and (C) 2 of the airbag sensor assembly to TERMINAL (B) 20, (B) 27 or BODY GROUND to GROUND, causing side airbag squibs to operate.

The airbag stored inside the steering wheel pad is instantaneously expanded to soften the shock to the driver.

The airbag stored inside the passenger's instrument panel is instantaneously expanded to soften the shock to the front passenger.

Side airbags are instantaneously expanded to soften the shock of side to the driver and front passenger. The pretensioners make sure of the seat belt restrainability.

• Parts Location

Code		See Page	Code	See Page	Code	See Page
A5		32	B6	34	J7	35
A6		32	B7	34	P12	37
A12	Α	34	C9	34	P13	37
A13	В	34	D1	34	S6	35
A14	С	34	E6	34	S7	35
A	15	34	l10	35	S10	37
A16		34	J6	35	S11	37

C : Relay Blocks

Code See Page Relay Blocks (Relay Block Location)		Relay Blocks (Relay Block Location)
1 22 Engine Room R/B (Engine Compartment Left)		Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)					
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)					
IF							
IG							
IH	25						
II	-	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)					
IJ							
IK							
IL	24						
IM							
1A	22	Engine Wire and Engine Room J/B (Engine Compartment Left)					
ЗA	- 28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)					
3B	20						
4B	- 30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)					
4C	50	Instrument Panel Wire and Center J/B (Bening the Combination Meter)					

Connector Joining Wire Harness and Wire Harness

Code	See Page Joining Wire Harness and Wire Harness (Connector Location)					
IA1	40	Envine Deere Main Wire and Instrument Devel Wire // off Cide of the Instrument Devel Deinforcement)				
IA4	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)				
IG1	IG1 42 Instrument Panel Wire and Instrument Panel No.3 Wire (Front Side of the Parking Brake Lever)					


SRS

: Ground Points

Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter
IG	40	Right Kick Panel

Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points	
16	42	Instrument Panel No.3 Wire				



From Power Source System (See Page 48)

16

11

M−B

When the ignition SW is turned to ON position, the current from the ECU–IG fuse flows to TERMINAL 5 of the shift lock control ECU.

Shift Lock Mechanism

With the ignition SW at ON position, when a signal that the brake pedal is depressed (Stop light SW on) and a signal that the shift lever is put in P position is input to the ECU, the ECU operates and the current flows from TERMINAL 5 of the ECU to TERMINAL SLS+ of the shift lock solenoid to TERMINAL SLS– to TERMINAL 1 of the ECU to GROUND. This causes the shift lock solenoid to turn on (Plate stopper disengages) and the shift lever can shift into position other than P.

Service Hints

S5 Shift Lock Control ECU

5-Ground : Approx. 12 volts with the ignition SW at ON position

- 1-Ground : Always continuity
- 3-Ground : Approx. 12 volts with the brake pedal depressed

S9 Stop Light SW

2-1 : Closed with the brake pedal depressed

O : Parts Location


Code	See Page	Code	See Page	Code	See Page
J7	35	S 5	35	S9	35

\bigcirc

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
IC	25	ngine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)	
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)	
IL	24		
ЗA			
3B	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)	
3C			

Code	See Page	Ground Points Location
IG	40	Right Kick Panel



The current is applied at all times to TERMINAL 5 of the combination meter through the DOME fuse.

When the ignition SW is turned to ON position, the current flows to TERMINAL 4 of the combination meter through the GAUGE fuse. When the light control SW is turned to Tail or Head position, current is applied to TERMINAL 18 of the combination meter through the TAIL fuse via the TAIL relay (USA) or the light control SW (Canada).

1. Light Reminder System

When the light control SW is in Tail or Head position, the ignition SW turned to OFF from ON position, and the driver's door opened (Door courtesy SW on), the current flows to TERMINAL 4 of the combination meter stops. As a result, the combination meter is activated and current flows from TERMINAL 5 of the combination meter to TERMINAL 2 to GROUND, the buzzer in the combination meter goes on to remind the light is lighting up.

2. Key Reminder System

When the driver door is opened with the ignition SW off and ignition key remaining in the key cylinder (Unlock warning SW on), a signal is input from the unlock warning SW to TERMINAL 16 of the combination meter, and from the door courtesy SW front LH to TERMINAL 17 of the combination meter. As a result, the buzzer in the combination meter goes on and warns the driver that the key is remaining in the key cylinder.

Service Hints

C9 Combination Meter

4-Ground : Approx. 12 volts with the ignition SW at ON position

- 18-Ground : Approx. 12 volts with the light control SW at Tail or Head position
- 17-Ground : Continuity with the driver's door open
- 2–Ground : Always continuity

D4 Door Courtesy SW Front LH

1-Ground : Closed with the driver's door open

U1 Unlock Warning SW

2-1 : Closed with the ignition key in cylinder

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
C9	34	D2	34	J6	35
C12	34	D4	36	U1	35

) : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)	
1	22	ine Room R/B (Engine Compartment Left)	
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)	

: Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)			
IC	25	ingine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)			
ID	25	loor Wire and Instrument Panel J/B (Lower Finish Panel)			
IG	- 25				
IH	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)			
IL	24				
3B	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)			
4A					
4B	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)			
4C					

v		
Code	See Page	Ground Points Location
IE	40	Behind the Combination Meter

Light Reminder Buzzer and Key Reminder Buzzer

: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
14	42	Instrument Panel Wire			



Current is always applied from the DOME fuse to TERMINAL 5 of the combination meter. When the ignition SW is turned to ON position, the current from the GAUGE fuse flows to TERMINAL 4 of the combination meter and flows TERMINAL 1 of the front passenger seat belt warning light.

Seat Belt Warning System

When the ignition SW turned on, a signal is input to the combination meter. To determine whether the driver has fastened the seat belt, a signal is input from the buckle SW LH to TERMINAL 12 of the combination meter. When the seat belt is not fastened, the seat belt warning light in the combination meter blinks, and emits a warning sound.

In addition, the front passenger is recognized by a sensor (Occupant detection sensor) is installed in the front passenger seat, and determines whether the seat belt is fastened. When not fastened, the signals from the occupant detection sensor is input to TERMINAL 11 of the combination meter, and the front passenger seat belt warning light blinks.

Service Hints

B6 Buckle SW LH

3-1 : Open with the driver's seat belt in use

C9 Combination Meter

- 5-Ground : Always approx. 12 volts
- 4-Ground : Approx. 12 volts with the ignition SW at ON position
- 1–Ground : Always continuity

C : Parts Location

Code	See Page	Code	See Page	Code	See Page
B6	34	F7	35	J7	35
B7	34	J3	35		
C9	34	J6	35		

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)


Solution Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
IC	25	ngine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)	
IG	25	had a set of the set of the design of the set of the se	
IL	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)	
ЗA	28	Instrument Danel Wire and PH 1/P (Pight Side of the Instrument Danel Painforcement)	
3B	20	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)	
4B	30	Instrument Denel Wire and Center I/D (Dekind the Combination Mater)	
4C		Instrument Panel Wire and Center J/B (Behind the Combination Meter)	

: Connector Joining Wire Harness and Wire Harness

Code	See Page Joining Wire Harness and Wire Harness (Connector Location)	
IG1	42	Instrument Panel Wire and Instrument Panel No.3 Wire (Front Side of the Parking Brake Lever)
ll2	42	Engine Wire and Instrument Panel Wire (Blower Unit RH)

Code	See Page	Ground Points Location
EB	38	Left Side of the Cylinder Head
IE	40	Behind the Combination Meter
IG	40	Right Kick Panel



Service Hints

DEF Relay

5--3 : Closed with the ignition SW at ON position and the rear window defogger SW on

O : Parts Location

Code	See Page	Code		See Page	Code	See Page
N2	37	R15	Α	37		
R5	35	R16	В	37		

\bigcirc

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)		
IG	25			
IL		Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)		
IM	24			
3B	28 Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)			

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID1	42	Instrument Panel Wire and Floor Wire (Left Kick Panel)


: Ground Points

Code	See Page	Ground Points Location	
IE	40	whind the Combination Meter	
BJ	44	Under the Right Quarter Pillar	

: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B5	44	Floor Wire			





Service Hints

R3 (A) Radio and Player

- (A) 4–Ground : Always approx. 12 volts
- (A) 3–Ground : Approx. 12 volts with the ignition SW at ACC or ON position
- (A) 7-Ground : Always continuity

O : Parts Location

Code	See Page	Code		See Page	Code	See Page
A17	34	R3	А	35	R14	37
F8	36	R4	В	35	T4	37
F9	36	R	13	37	T5	37

: Relay Blocks

 \bigcirc

Code	See Page	Relay Blocks (Relay Block Location)	
1	22	Engine Room R/B (Engine Compartment Left)	


Sunction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)	
IC	25	ngine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)	
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)	
IL	24		
ЗA	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)	
4C	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)	

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IC2	40	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)	
ID1	42	strument Panel Wire and Floor Wire (Left Kick Panel)	
IJ1	42	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)	
BE1	44	Speaker Tweeter LH Wire and Front Door LH Wire (Inside of the Front Door LH)	
BF1	44	Speaker Tweeter RH Wire and Front Door RH Wire (Inside of the Front Door RH)	


•		
Code	See Page	Ground Points Location
IF	40	Behind the Combination Meter






B–W

B-W





Service Hints

B2 Brake Fluid Level Warning SW

1-2 : Closed with the float down

C9 Combination Meter

4, 32–Ground : Approx. 12 volts with the ignition SW at ON position

1, 13, 36, 37–Ground : Always continuity

5-Ground : Always approx. 12 volts

F10 Fuel Sender

2–3 : Approx. 4 Ω at fuel full

Approx. 107 Ω at fuel empty

O1 Oil Pressure SW

1-Ground : Opened with the oil pressure above approx. 19.61 kpa (2.84 psi, 0.2 kgf/cm²)

O : Parts Location

Code	See Page	Co	de	See Page	Code	See Page
A7	32	J	1	33	J6	35
B2	32	J2	А	35	O1	33
C9	34	J3	В	35	V1	33
F10	36	J4	А	35	W1	33
l10	35	J5	В	35		

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

\bigcirc

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)				
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)				
IG	25					
IK	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
IL						
IM						
1A	22	Engine Wire and Engine Room J/B (Engine Compartment Left)				
3B	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)				
4B	20	Instrument Denel Wire and Center I/D (Dehind the Combination Mater)				
4C	- 30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)				


: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)			
IA4					
IA5	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)			
IA6					
ID2	42	Instrument Panel Wire and Floor Wire (Left Kick Panel)			
ll2	42	Engine Wire and Instrument Panel Wire (Blower Unit RH)			

7: Ground Points

Code	See Page	Ground Points Location
EA	38	Front Right Fender
EB	38	Left Side of the Cylinder Head
ED	38	Front Left Suspension Tower
IE	40	Behind the Combination Meter

: Splice Points					
Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	38	Engine Room Main Wire	12	42	Instrument Panel Wire



System Outline

The current is applied at all times through the RDI FAN fuse to TERMINAL 5 of the FAN NO.1 relay. When the ignition SW is turned on, the current flows through the ECU–IG fuse to FAN NO.1 relay (Coil side) to TERMINAL 6 of the engine control module. At the same time as this current flow, the current from ECU–IG fuse flows to the FAN NO.2 relay (Coil side) to TERMINAL 3 of the pressure SW.

1. Low Speed Operation

When the A/C system is operating, the FAN NO.1 Relay is turned on. As a result, the current flows from the RDI FAN fuse to FAN NO.1 relay (Point side) to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to TERMINAL 3 of the FAN NO.2 relay to TERMINAL 4 to TERMINAL 2 of the radiator fan resistor to TERMINAL 1 to GROUND, and the radiator fan motor rotates at low speed.

2. High Speed Operation

When the pressure SW is on or engine control module operated, the FAN NO.1 and NO.2 relay is turned on. As a result, the current flows from the RDI FAN fuse to FAN NO.1 relay (Point side) to radiator fan motor to TERMINAL 3 of the FAN NO.2 Relay to TERMINAL 5 to GROUND, and the radiator fan motor rotates at high speed.

Service Hints

P2 Pressure SW

3–2 : Open below approx. 12.5 kgf/cm² (178 psi, 1225 kpa) Close above approx. 15.5 kgf/cm² (220 psi, 1520 kpa)

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
E6	34	R1	33		
P2	33	R2	33		

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA5	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)


: Ground Points

Code	See Page	Ground Points Location
EA	38	Front Right Fender
ED	38	Front Left Suspension Tower

: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E4	38	Engine Room Main Wire			





- System Outline

Current is applied at all times through the HEATER fuse to TERMINAL 5 of the HTR relay. When the ignition SW is turned on, the current flows through the GAUGE fuse to TERMINAL 2 of the HTR relay to TERMINAL 1 to TERMINAL 6 of the blower SW.

1. Heater Blower Motor Operation

* Low speed operation

When the blower SW is moved to LO position, the current flows to TERMINAL 6 of the blower SW to TERMINAL 5 to GROUND, causing the HTR relay to turn on. This causes the current flows from the HEATER fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to the blower motor to the blower resistor to GROUND, rotating the blower motor at low speed.

* Medium speed operation (Operation at M1, M2)

When the blower SW is moved to M1 position, the current flows to TERMINAL 6 of the blower SW to TERMINAL 5 to GROUND, causing the HTR relay to turn on. This causes the current flows from the HEATER fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to the blower motor to the blower resistor to TERMINAL 2 of the blower SW to TERMINAL 5 to GROUND. At this time, the blower resistance of the blower resistor is smaller than at low speed, so the blower motor rotates at medium low speed.

When the blower SW is moved to M2 position, the current flows through the HTR relay to the blower motor to the blower resistor to TERMINAL 1 of the blower SW to TERMINAL 5 to GROUND. At this time, resistance of the blower resistor is smaller than at M1 position, so the blower motor rotates at medium high speed.

* High speed operation

When the blower SW is moved to HI position, the current flows to TERMINAL 6 of the blower SW to TERMINAL 5 to GROUND, causing the HTR relay to turn on.

This causes the current flows from the HEATER fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to the blower motor to TERMINAL 4 of the blower SW to TERMINAL 5 to GROUND, rotating the blower motor at high speed.

2. Air Conditioning Operation

When the blower SW is set on, the current flows from the HTR fuse to the HTR relay (Point side) to the A/C fuse to the TERMINAL 2 of the A/C SW. If the A/C SW is turned on, at this time a signal is input into the engine control module. This activates the engine control module and M/G CLT relay. So that current flows from the A/C fuse to M/G CLT relay (Point side) to A/C magnetic clutch. Causing the compressor to operate.

Service Hints

HTR Relay

5-3 : Closed with the ignition SW at ON position and the blower SW on

P2 Pressure SW

1–4 : Open with the refrigerant pressure at less than approx. 2.0 kgf/cm² (28.4 psi, 196.1 kpa) or more than approx. 32.0 kgf/cm² (455 psi, 3138.1 kpa)

O : Parts Location

Code	See Page	Co	Code See Page Code		de	See Page	
A1	32	В	3	34	E5	В	34
A8	34	В	4	34	J	3	35
A9	34	В	5	34	J	7	35
A11	34	E3	А	34	P	2	33

) : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)					
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)					
IF	05						
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)					
IM	24						
ЗA	20	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)					
3B	28						

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	38	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
IA6	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)
IH1	42	Instrument Panel Wire and A/C Sub Wire (Left Upper Side of the Blower Unit)
112	42	Engine Wire and Instrument Panel Wire (Blower Unit RH)

: Ground Points

v		
Code	See Page	Ground Points Location
EA	38	Front Right Fender
IG	40	Right Kick Panel

: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
17	42	Instrument Panel Wire			



Service Hints

HTR Relay

5--3 : Closed with the ignition SW at ON position and the blower SW on

O : Parts Location

Code	See Page	Code	See Page	Code	See Page
A8	34	B3	34	B5	34
A11	34	B4	34	J7	35

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)				
IG	25	Instrument Denal Wire and Instrument Denal I/D (Leuver Finish Denal)				
IM	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
3A	20	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)				
3B	28					

Connector Joining Wire Harness and Wire Harness

Co	ode	See Page Joining Wire Harness and Wire Harness (Connector Location)	
IH	-11	42	Instrument Panel Wire and A/C Sub Wire (Left Upper Side of the Blower Unit)


: Ground Points


Code	See Page	Ground Points Location
IG	40	Right Kick Panel

: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
17	42	Instrument Panel Wire			


I GROUND POINT





* 1 : w/ Automatic Glare–Resistant EC Mirror * 2 : w/ Moon Roof * 3 : w/o Moon Roof

I GROUND POINT



O : Parts Location

Code		See Page	Code		See Page	Code		See Page
J2	А	35	J5	В	35	J8	А	36
J3	В	35	J	6	35	J9	В	36
J4	А	35	J		35			

C : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

Sunction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IE	25	Roof Wire and Instrument Panel J/B (Lower Finish Panel)
IF		
IH	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
ЗA	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4B	30	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA4		
IA5	40	Engine Room Main Wire and Instrument Panel Wire (Left Side of the Instrument Panel Reinforcement)
IA6	-	
IC1	40	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IF1	42	Console Box Wire and Instrument Panel Wire (Under the Instrument Panel Center)
IG1	42	Instrument Panel Wire and Instrument Panel No.3 Wire (Front Side of the Parking Brake Lever)
IH1	42	Instrument Panel Wire and A/C Sub Wire (Left Upper Side of the Blower Unit)
ll1	10	Environ Mfree and Instrument Devisit Mfree (Discuss Linit Di I)
112	- 42	Engine Wire and Instrument Panel Wire (Blower Unit RH)
IJ2	42	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)


: Ground Points

Code	See Page	Ground Points Location	
EA	38	Front Right Fender	
EB	- 38	Loft Side of the Outinder Lload	
EC		Left Side of the Cylinder Head	
ED	38	Front Left Suspension Tower	
IE	40	Behind the Combination Meter	
IF	40	Benind the Compination Meter	
IG	40	Right Kick Panel	
BH	44	Under the Left Quarter Pillar	
BI	44	Lower Back Panel	
BJ	44	Under the Right Quarter Pillar	

: Splice Points


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	38	Engine Room Main Wire	B1	44	Roof Wire
E2	38	Engine Wire	B2	44	Rool wire
E4	38	Engine Room Main Wire	B3	44	Front Door RH Wire
18	42	Instrument Panel Wire	B4	44	Front Door LH Wire


The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other Parts.



[LOCATION] (1) : Engine Room R/B, Engine Room J/B (See Page 22)

- 2 : Instrument Panel J/B (See Page 24)
- ③: RH R/B, RH J/B (See Page 28)





Engine Room R/B, Engine Room J/B (See Page 22)

	Fuse	System	Page
5A	ALT–S	Charging	56
10A	HAZARD	Turn Signal and Hazard Warning Light	78
10A	HEAD LH LWR	Headlight	70
10A	HEAD LH UPR	Headlight	70
10A	HEAD RH LWR	Headlight	70
104		Combination Meter	180
10A	HEAD RH UPR	Headlight	70
		Horn	102
10A	HORN	TVIP System	134
		Wireless Door Lock Control	126
		ABS	154
		Clock	106
		Combination Meter	180
		Cruise Control	148
		Headlight	70
		Illumination	86
15A	DOME	Interior Light	90
		Light Reminder Buzzer and Key Reminder Buzzer	168
		Radio and Player	176
		Seat Belt Warning	172
		SRS	159
		TVIP System	134
		Wireless Door Lock Control	126
15A	EFI	Electronically Controlled Transmission	142
ISA		Engine Control	58
15A	FOG	Fog Light	76
30A	ABS NO.1	ABS	154
		ABS	154
		Charging	56
		Combination Meter	180
		Cruise Control	148
30A	MAIN	Electronically Controlled Transmission	142
		Engine Control	58
		SRS	159
		Starting and Ignition	52
		TVIP System	134
30A	RDI FAN	Radiator Fan	186
40A	ABS NO.2	ABS	154
		Headlight	70
40A	HEAD MAIN	TVIP System	134
		Wireless Door Lock Control	126

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
		Charging	56
100A	ALT	Illumination	86
		Taillight	82

Instrument Panel J/B (See Page 24)

	Fuse	System	Page
7.5A	OBD	Engine Control	58
10A	A/C	Air Conditioning	188
		Fog Light	76
10A	ECU–B	Headlight	70
		TVIP System	134
		ABS	154
		Cruise Control	148
10A	ECU–IG	Radiator Fan	186
		Shift Lock	166
		TVIP System	134
		ABS	154
		Air Conditioning	188
		Automatic Glare–Resistant EC Mirror with Compass	112
		Back–Up Light	96
		Charging	56
		Combination Meter	180
		Cruise Control	148
		Electronically Controlled Transmission	142
		Engine Control	58
10A	GAUGE	Fog Light	76
TUA	GAUGE	Headlight	70
		Heater	192
		Interior Light	90
		Light Reminder Buzzer and Key Reminder Buzzer	168
		Moon Roof	140
		Power Window	114
		Rear Window Defogger	174
		Seat Belt Warning	172
		SRS	159
		Turn Signal and Hazard Warning Light	78
10A	M-HTR/DEF I-UP	Engine Control	58
		ABS	154
		Charging	56
		Combination Meter	180
15A	AM2	Cruise Control	148
		Electronically Controlled Transmission	142
		Engine Control	58
		SRS	159

* These are the page numbers of the first page on which the related system is shown.


J POWER SOURCE (Current Flow Chart)

	Fuse	System	Page
15A	AM2	Starting and Ignition	52
ISA	AIVIZ	TVIP System	134
		Cigarette Lighter	104
		Clock	106
15A	CIG	Power Outlet	108
		Radio and Player	176
		Remote Control Mirror	110
15A	P/POINT	Power Outlet	108
		ABS	154
		Cruise Control	148
15A	STOP	Electronically Controlled Transmission	142
ISA	3106	Engine Control	58
		Shift Lock	166
		Stop Light	94
		Clock	106
		Engine Control	58
15A	TAIL	Headlight	70
IJА		Illumination	86
		Light Reminder Buzzer and Key Reminder Buzzer	168
		Taillight	82
15A	WASHER	Wiper and Washer	98
		Door Lock Control	118
25A	DOOR	Interior Light	90
		Wireless Door Lock Control	126
25A	WIPER	Wiper and Washer	98
30A	POWER	Moon Roof	140
JUA	FUVER	Power Window	114
40A	DEFOG	Rear Window Defogger	174
40.4		Air Conditioning	188
40A	HEATER	Heater	192

* These are the page numbers of the first page on which the related system is shown.

K CONNECTOR LIST









































В3

















l r

1 2




B 4

Black


B 5

C 2 Brown















C 5














C14





D 1

D 2




D 3



1

5





D 7





D12



D 9










D11


K CONNECTOR LIST





K CONNECTOR LIST







L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Magnetic Clutch	90980–11271	C13	Cruise Control Clutch SW	90980–10906
	A/T Shift Lever Position SW		C14	Cruise Control ECU	90980–12094
A 2	Back–Up Light SW	90980–11784	D 1	Data Link Connector 3	90980-11665
	Park/Neutral Position SW	-	D 2	Daytime Running Light Relay	90980-12034
A 3	ABS Speed Sensor Front LH		D 3	Door Control Receiver	90980–11909
A 4	ABS Speed Sensor Front RH	90980–11003	D 4	Door Courtesy SW Front LH	
A 5	Airbag Sensor Front LH		D 5	Door Courtesy SW Front RH	_
A 6	Airbag Sensor Front RH	90980–11856	D 6	Door Courtesy SW Rear LH	90980–10871
Α7	Ambient Temp. Sensor	90980–11030	D 7	Door Courtesy SW Rear RH	-
	A/C SW			Door Key Lock and Unlock SW Front LH	
A 8	Air Inlet Control SW	90980–12162	D 8	Door Lock Motor Front LH	-
	Defroster Mode Detection SW	-		Door Unlock Detection SW Front LH	-
	A/T Shift Lever Illumination			Door Key Lock and Unlock SW Front RH	90980–12226
A10	O/D Main SW	90980–12211	D 9	Door Lock Motor Front RH	-
A11	Air Inlet Control Servo Motor	90980–11909		Door Unlock Detection SW Front RH	-
A12	Airbag Sensor Assembly	90980–11869	D10	Door Lock Control SW Front LH	90980–10797
A13	Airbag Sensor Assembly	90980–11872		Door Lock Control SW Front LH	
A14	Airbag Sensor Assembly	90980–11867	D11	Power Window Master SW	90980–12122
A15	Airbag Squib (Front Passenger Airbag		D12	Door Lock Control SW Front RH	90980–10797
AIU	Assembly)	90980–12160	D13	Door Lock Motor Rear LH	
A16	Airbag Squib (Steering Wheel Pad)		D14	Door Lock Motor Rear RH	90980–12226
A17	Antenna Amplifier	90980–10871	E 1	Electronically Controlled Transmission	90980–10854
A18	Automatic Light Control Sensor	90980–11107		Solenoid	90980-10834
A19	ABS Speed Sensor Rear LH	90980–11900	E 2	Engine Coolant Temp. Sensor	90980–10737
A20	ABS Speed Sensor Rear RH		E 3	Engine Control Module	90980–12144
B 1	Back–Up Light SW	90980–11250	E 4	Engine Control Module	90980–12145
B 2	Brake Fluid Level Warning SW	90980–11207	E 5	Engine Control Module	90980–12146
B 3	Blower Motor	90980–10214	E 6	Engine Control Module	90980–12142
B 4	Blower Resistor	90980–11136	F 1	Front Fog Light LH	90980-11156
B 5	Blower SW	90980–10877	F 2	Front Fog Light RH	
B 6	Buckle SW LH	90980-12257	F 3	Front Parking Light LH	
	Seat Position Sensor			Front Turn Signal Light LH	90980-11020
Β7	Buckle SW RH	90980–11950	F4	Front Parking Light RH	
	Occupant Detection Sensor			Front Turn Signal Light RH	
C 1	Camshaft Position Sensor	90980–10947	F 5	Front Washer Motor	90980–10981
C 2	Camshaft Timing Oil Control Valve (VVT)	90980–11162	F 6	Front Wiper Motor	90980–11599
C 3	Crankshaft Position Sensor	90980–10947	F 7	Front Passenger Seat Belt Warning Light	90980–11296
C 4	Cruise Control Actuator	90980–11150	F 8	Front Door Speaker LH	90980-10935
C 5	Cigarette Lighter	90980-10760	F 9	Front Door Speaker RH	
	Power Outlet (Front)		F10	Fuel Pump	90980–11077
C 6	Cigarette Lighter Illumination	90980–11148		Fuel Sender	
C 7	Clock	90980–11950	G 1	Generator	90980–11349
C 8	Clutch Start SW	90980–10825	G 2	Generator	90980-09373
C 9	Combination Meter	90980–12169	G 3	Glass Breakage Sensor ECU	90980–10799
C10	Combination SW	90980–12183	H 1	Headlight LH (High)	90080–98039
C11	Combination SW	90980-12008	H 2	Headlight LH (Low)	90080–98038
C12	Combination SW	90980–12007	Н3	Headlight RH (High)	90080–98039

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
H 4	Headlight RH (Low)	90080–98038	P 4	Power Outlet (Rear)	90980–10760
H 5	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980–10869	P 5	Power Window Control SW Front RH	
H 6	Horn	90980-10619	P 6	Power Window Control SW Rear LH	90980–10789
Η7	Hazard SW	90980–10933	Ρ7	Power Window Control SW Rear RH	
H 8	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980–10794	P 8	Power Window Motor Front LH	
	High Mounted Stop Light (Bulb Type)	90980-10860	P 9	Power Window Motor Front RH	
H 9	High Mounted Stop Light (LED Type)	90980–11367	P10	Power Window Motor Rear LH	90980–10797
11	Idle Air Control Valve	90980–11145	P11	Power Window Motor Rear RH	
12	Ignition Coil and Igniter No.1		P12	Pretensioner LH	
13	Ignition Coil and Igniter No.2		P13	Pretensioner RH	90980–12253
14	Ignition Coil and Igniter No.3	90980–11885	R 1	Radiator Fan Motor	00000 40000
15	Ignition Coil and Igniter No.4		R 2	Radiator Fan Resistor	90980–10928
16	Injector No.1		R 3	Radio and Player	90980–10997
17	Injector No.2		R 4	Radio and Player	90980-10996
18	Injector No.3	90980–11875	R 5	Rear Window Defogger SW	90980–10789
19	Injector No.4		R 6	Remote Control Mirror SW	90980-11657
I10	Ignition SW	90980–11778	R 7	Rheostat	90980-12217
I11	Integration Relay	90980–12203	R 9	Rear Combination Light LH	90980-10795
	Inner Mirror		R10	Rear Combination Light LH	90980–11148
112	Personal Light	90980–11794	R11	Rear Combination Light RH	90980–10795
l13	Interior Light	90980–10908	R12	Rear Combination Light RH	90980–11148
J 1	Junction Connector	90980–10803	R13	Rear Speaker LH	
J 2	Junction Connector	00000 44045	R14	Rear Speaker RH	90980–11299
J 3	Junction Connector	90980–11915	R15	Rear Window Defogger	90980-10914
J 4	Junction Connector	00000 44004	R16	Rear Window Defogger	90980-10913
J 5	Junction Connector	90980–11661	R17	Remote Control Mirror LH	00000 40007
J 6	Junction Connector	90980–11539	R18	Remote Control Mirror RH	90980–10907
J 7	Junction Connector	90980–11686	S 1	Skid Control ECU with Actuator	82824–12300
J 8	Junction Connector	00080 11661	S 2	Starter	90980-09463
J 9	Junction Connector	90980–11661	S 3	Starter	90980-11400
J10	Junction Connector	90980-10803	S 4	Security Indicator	90980-11013
K 1	Knock Sensor	90980–11875	S 5	Shift Lock Control ECU	90980-11909
L 1	License Plate Light LH		S 6	Side Airbag Squib LH	90980–11864
L 2	License Plate Light RH	90980–11148	S 7	Side Airbag Squib RH	90900-11004
L 3	Luggage Compartment Light		S 8	Starter Cut Relay	82660-0C010
L 4	Luggage Compartment Light SW	90980–11097	S 9	Stop Light SW	90980–11118
M 1	Mass Air Flow Meter	90980–11317	S10	Side Airbag Sensor LH	00080 10005
M 2	Moon Roof Control Relay and SW	00080 10700	S11	Side Airbag Sensor RH	90980–12225
	Personal Light	90980–10799	T 1	Throttle Position Sensor	90980–11261
M 3	Moon Roof Motor and Limit SW	90980–11011	T 2	Turn Signal Flasher Relay	90980-10799
N 1	Noise Filter (Ignition)	90980–10843	Т3	TVIP ECU	90980-12169
N 2	Noise Filter (Rear Window Defogger)	90980-10825	T 4	Tweeter LH	00020 10015
01	Oil Pressure SW	90980–11363	T 5	Tweeter RH	90980–10915
P 1	Power Steering Oil Pressure SW	90980–11428	U 1	Unlock Warning SW	90980-10860
P 2	Pressure SW	90980–10943	V 1	Vehicle Speed Sensor (Combination Meter)	90980–11143
P 3	Parking Brake SW	90980-10871	V 2	VSV (Canister Closed Valve)	90980–11162

L

L PART NUMBER OF CONNECTORS


Code	Dart Nama	Part Number	Code	Dart Nama	Part Number
	Part Name		Code	Part Name	Part Number
	VSV (EVAP)	90980-11156			
	Vapor Pressure Sensor	90980–11143			
	VSV (Vapor Pressure Sensor)	90980–11859			
W 1	Washer Level Sensor	90980–11068			
					1
					1
			·	<u> </u>	+
├			·		+
			-		
			-		
					1
			·	<u> </u>	1
					1
			·		+
├ ──┤			·		
┝───┤			·		
├ ── 					

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number

L






- [A] : System Title
- **[B]** : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

- O = Orange


The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L-Y



- **[C]** : The position of the parts is the same as shown in the wiring diagram and wire routing.
- **[D]** : Indicates the pin number of the connector. The numbering system is different for female and male connectors.
 - Example : Numbered in order from upper left to lower right

Numbered in order from upper right to lower left




The numbering system for the overall wiring diagram is the same as above


[E] : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example : 1 Indicates Relay Block No.1

[F] : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.



- [G] : Indicates related system.
- [H] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (≥). Outside numerals are pin numbers.



- [I] : () is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.
- [J] : Indicates a shielded cable.




- [K] : Indicates and located on ground point.
- **[L]** : The same code occuring on the next page indicates that the wire harness is continuous.


²¹6 SYSTEM INDEX


SYSTEMS LOCA	TION	SYSTEMS	LOCATION
ABS	12–2	Light Reminder Buzzer	19–3
Air Conditioning	26–2	Moon Roof	18–3
Automatic Glare–Resistant EC Mirror with Compass	14–4	Power Outlet	21–3
Back–Up Light	10–8	Power Source	1~27–1
Charging	2–2	Power Window	17–2
Cigarette Lighter	21–2	Radiator Fan	25–3
Clock	21–2	Radio and Player	23–2
Combination Meter	24–2	Rear Window Defogger	22–2
Cruise Control	. 11–2	Remote Control Mirror	20–2
Door Lock Control	15–2	Seat Belt Warning	19–2
Electronically Controlled Transmission	10–2	Shift Lock	18–4
Engine Control	3–2	SRS	13–2
Fog Light	4–8	Starting	
Headlight	4–3	Stop Light	7–2
Heater	27–2	Taillight	6–2
Horn	21–4	Turn Signal and Hazard Warning Light	
Ignition	1–3	TVIP System	16–2
Illumination	8–2	Wiper and Washer	14–2
Interior Light	9–2	Wireless Door Lock Control	15–8
Key Reminder Buzzer	19–4		







2 COROLLA












4 COROLLA







4 COROLLA (Cont' d)




5 COROLLA




6 COROLLA










8 COROLLA










10 COROLLA









11 COROLLA





12 COROLLA




13 COROLLA









14 COROLLA




2004 COROLLA (EWD533U)




15 COROLLA (Cont' d)





16 COROLLA






18 COROLLA







20 COROLLA




21 COROLLA





22 COROLLA



23 COROLLA







25 COROLLA

