2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

## 2007 ENGINE

# Engine - 3.0L (4V) - Escape & Mariner

# **SPECIFICATIONS**

#### **GENERAL SPECIFICATIONS**

#### **GENERAL SPECIFICATIONS**

Item	Specification
Engine	
Bore/stroke	89.0 x 79.5 mm (3.12 in)
Compression ratio	10.0:1
Displacement	3.0L (4V) (182 CID)
Engine and transaxle assembly weight (without accessory drive components)	234 kg (516 lb)
Engine weight (without accessory drive components and flexplate)	146 kg (322 lb)
Fire order	1-4-2-5-3-6
No. cylinders	6
Oil pressure (Minimum at 1,500 rpm with engine warmed up after 10 minutes of idling)	76 kPa (11 psi)
Spark plug	AGSF-32M Gap = 1.30-1.40 mm (0.052-0.056 in)
Cylinder Head and Valve Train	
Combustion chamber volume	52 cc (3.17 CI)
Cylinder head gasket surface flatness	-
Roller follower ratio @ max. lift	2.0:1
Valve arrangement (front to rear)	LH intake I-I-I-I-I-I LH exhaust E-E-E-E-E RH intake I-I-I-I-I-I RH exhaust E-E-E-E-E-E
Valve face angle	45.5 degrees
Valve face runout	0.05 mm (0.001 in)
Valve guide bore diameter	6.015-6.044 mm (0.236-0.237 in)
Valve head diameter - exhaust	30 mm (1.18 in)
Valve head diameter - intake	35 mm (1.38 in)
Valve head diameter (exhaust) - gauge diameter	28.0 mm (1.10236 in)
Valve head diameter (intake) - gauge diameter	33.5 mm (1.3189 in)
Valve seat angle	44.75 degrees
Valve seat runout	0.04 mm (0.001 in)
Valve seat width - exhaust	1.4-1.7 mm (0.055-0.066 in)

# 2007 Ford Escape 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

Valve seat width - intake	1.1-1.4 mm (0.043.0.055 in)
Value spring compression pressure $(N \alpha)$ spec	693 N @ 30 09 mm
length)	(156  lbs  @ 1.18  in)
Valve spring free length (approx.)	46.6 mm (1.84 in)
Valve spring installed height (N @ spec. length)	39.89 mm (1.57 in)
Valve spring installed pressure	240 N @ 39.89 mm (53.95 lbs @ 1.57 in)
Valve spring installed pressure - service limit	10% force loss @ specified height
Valve spring squareness	2.5%
Valve stem diameter - exhaust	5.950-5.970 mm (0.2343-0.2350 in)
Valve stem diameter - intake	5.975-5.995 mm (0.2350-0.2358 in)
Valve stem-to-guide clearance - exhaust	0.045-0.094 mm (0.0017-0.037 in)
Valve stem-to-guide clearance - intake	0.019-0.069 mm (0.0007-0.0027 in)
Hydraulic Lash Adjuster	· · · · · · · · · · · · · · · · · · ·
Clearance to bore	0.018-0.069 mm (0.0007-0.0027 in)
Collapsed lash adjuster gap	0.50-1.11 mm (0.019-0.043 in)
Diameter (standard)	16-15.988 mm (0.6290-0.6294 in)
Hydraulic leakdown rate	5-25 seconds
Camshaft	
Allowable lobe lift loss	0.76 mm (0.03 in)
Camshaft journal bore inside diameter	27.012-26.987 mm (1.063-1.062 in)
Camshaft journal-to-bearing clearance - service limit	0.121 mm (0.0047 in)
Camshaft journal-to-bearing clearance - standard	0.025-0.076 mm (0.001-0.0029 in)
End play - service limit	0.190 mm (0.00748 in)
Journal diameter (all)	26.962-26.936 mm (1.061-1.060 in)
Lobe lift	4.80 mm (0.189 in)
Runout	-
Theoretical valve lift @ 0 lash	9.80 mm (0.388 in)
Cylinder Block	
Cylinder bore diameter - grade 1	89.000-89.010 mm (3.50393-3.504323 in)
Cylinder bore diameter - grade 2	89.010-89.020 mm (3.504323-3.504717 in)
Cylinder bore diameter - grade 3	89.020-82.030 mm (3.504717-3.50511 in)
Cylinder bore maximum out-of-round	0.015 mm (0.0005 in)
Cylinder bore maximum out-of-round - service limit	0.020 mm (0.0007 in)
Cylinder bore maximum taper	0.020 mm (0.0008 in)
Head gasket surface flatness	-
Main bearing bore inside diameter	67.998-68.022 mm (2.677-2.6780 in)
Crankshaft	
Connecting rod journal diameter	49.969-49.991 mm (1.967-1.968 in)
Connecting rod journal maximum out-of-round	0.006 mm (0.0002 in)
Connecting rod journal maximum taper	0.008 mm (0.0003 in)
sábado, 31 de agosto de 2019 08:14:44 a.m.	Page 2 © 2011 Mitchell Repair Information Company, LL

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

Crankshaft maximum end play	0.135-0.255 mm (0.005-0.010 in)
Main bearing journal diameter	62.968-62.992 mm (2.467-2.479 in)
Main bearing journal maximum out-of-round	0.006 mm (0.0002 in)
Main bearing journal maximum taper	0.008 mm (0.0003 in)
Main bearing journal-to-cylinder block clearance	0.024-0.072 mm (0.0009-0.003 in)
Piston and Connecting Rod	
Connecting rod bearing bore diameter	53.015-53.035 mm (2.0872-2.0879 in)
Connecting rod bearing-to-crankshaft clearance	0.028-0.066 mm (0.001-0.0025 in)
Connecting rod length (center-to-center)	138.06-138.14 mm (5.435-5.38 in)
Connecting rod maximum allowed bend	0.038 mm per 25 (0.0014 per 0.984 in)
Connecting rod maximum allowed twist	0.050 mm per 25 (0.0019 per 0.984 in)
Connecting rod pin bore diameter	21.017-21.031 mm (0.827-0.828 in)
Connecting rod side clearance	0.100-0.30 mm (0.0039-0.0118 in)
Connecting rod-to-pin clearance - service limit	0.035 mm (0.0013 in)
Connecting rod-to-pin clearance - standard	0.004-0.02 mm (0.0001-0.0007 in)
Piston diameter - coated, grade 1	88.990-89.010 mm (3.5035-3.5043 in)
Piston diameter - coated, grade 2	88.998-89.022 mm (3.5039-3.5048 in)
Piston diameter - coated, grade 3	89.010-89.030 mm (3.5043-3.5051 in)
Piston diameter - uncoated, grade 1	88.970-88.980 mm (3.50275-3.50314 in)
Piston diameter - uncoated, grade 2	88.978-88.992 mm (3.50306-3.50362 in)
Piston diameter - uncoated, grade 3	89.010-89.030 mm (3.50432-3.50511 in)
Piston pin bore diameter	21.008-21.012 mm (0.8270-0.8272 in)
Piston pin diameter	21.011-21.013 mm (0.8271-0.8273 in)
Piston pin length	60.51-60.08 mm (2.382-2.365 in)
Piston ring end gap - compression (bottom, gauge diameter)	0.27-0.42 mm (0.0106-0.0165 in)
Piston ring end gap - compression (bottom, service limit)	0.65 mm (0.0255 in) max
Piston ring end gap - compression (top, gauge diameter) <sup>a</sup>	0.100-0.250 mm (0.0039-0.0098 in)
Piston ring end gap - compression (top, service limit)	0.50 mm (0.0196 in) max
Piston ring end gap - oil ring (steel rail, gauge diameter)	0.15-0.65 mm (0.0059-0.0255 in)
Piston ring end gap - oil ring (steel rail, service limit)	0.90 mm (0.0354 in) max
Piston ring groove width - compression (bottom)	1.530-1.545 mm (0.0602-0.0608 in)
Piston ring groove width - compression (top)	1.230-1.245 mm (0.0484-0.0490 in)
Piston ring groove width - oil ring	3.030-3.055 mm (0.1192-0.0120 in)
Piston ring-to-groove clearance	-

Page 3 © 2011 Mitchell Repair Information Company, LLC.

# 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

Piston ring width	-
Piston pin-to-piston fit	0.002 to 0.009 mm (0.00007-0.0003 in)
Piston-to-connecting rod clearance	-
Piston-to-cylinder bore clearance	0.012 to 0.022 mm (0.0005-0.0009 in)

<sup>a</sup> Specification 82.4 mm (3.2441 in) diameter gauge

# MATERIAL

# Material

Item	Specification	Fill Capacity
High Temperature Nickel Anti- Seize Lubricant XL-2 (US): CXG-2-B (Canada)	ESE-M12A4-A	-
MERCON® Multi-Purpose Automatic Transmission Fluid XT-2-QDX (US); XT-2-LM12 (Canada)	MERCON®	-
Motorcraft Metal Surface Prep ZC-31	-	-
Motorcraft SAE 5W-20 Premium Synthetic Blend Motor Oil XO-5W20-QSP (US); Motorcraft SAE 5W-20 Super Premium Motor Oil CXO-5W20-LSP12 (Canada); or equivalent	WSS-M2C930-A	5.7L (6.0 qt) includes filter change
Penetrating and Lock Lubricant XL-1 (US); CXC-51-A (Canada)	-	-
Silicone Brake Caliper Grease and Dielectric Compound XG-3-A	ESE-M1C171-A	-
Silicone Gasket and Sealant TA-30	WSE-M4G323-A4	-
Thread Sealant with PTFE TA-24	WSK-M2G350-A2	-

# **TORQUE SPECIFICATIONS**

# **TORQUE SPECIFICATIONS**

Description	Nm	lb-ft	lb-in
Accelerator cable bracket bolts	10	-	89
Accelerator cable snow shield bolts	10	-	89
Accessory drive belt tensioner bolt	45	33	-
Air conditioning compressor bracket bolts	25	18	-

# 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

Air conditioning compressor bolts	25	18	-
Battery cable nut	10		89
Block heater	21	15	-
Brake hose and wiring retainers	15	11	
Camshaft journal and thrust cap bolts <sup>a</sup>	-	-	-
Camshaft oil seal retainer bolts	10	-	89
Camshaft position (CMP) sensor bolt	10	-	89
Catalyst monitor sensor electrical connector bracket nut	10		89
Center accessory drive belt idler pulley bolt	25	18	-
Coil-on-plug bolts	6	-	53
Coolant bypass tube nut and bolt	10	-	89
Coolant pump bolts	10	-	89
Crankcase cover bolts	10	-	89
Crankshaft position (CKP) sensor bolt	10	-	89
Crankshaft pulley bolt <sup>a</sup>	-	-	-
Cross brace bolts	90	66	-
Cross brace nut	175	129	-
Cylinder head bolts <sup>a</sup>	-	-	-
Driveshaft-to-power takeoff bolts and washers	37	27	-
Engine control wiring harness (B+) shield nuts	6	-	53
Engine front cover bolts and studs <sup>a</sup>	-	-	-
Engine lift bracket bolt	118	87	-
Engine oil filter <sup>a</sup>	-	-	-
Engine oil pressure (EOP) switch	14	10	-
Engine support insulator bolts	48	35	-
Engine support insulator bracket bolt	90	66	-
Engine support insulator bracket nuts	55	41	-
Exhaust gas recirculation (EGR) tube	40	30	-
EGR tube nuts	40	30	-
EGR vacuum regulator stud bolt nut	6	-	53
Exhaust manifold nuts <sup>a</sup>	-	-	-
Exhaust manifold studs	12	9	-
Exhaust Y-pipe flange nuts	29	21	
Flexplate bolts	80	59	-
Front roll restrictor bolt	115	85	
Gearshift cable bracket bolts	23	17	
Generator B+ wiring harness nut	6		53
Generator B+ wire nut	8	-	71
Generator bolt	47	35	-
Generator studs	8	-	71
	1	1	

### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

Generator stud nuts	47	35	-
Ground strap bolt	10	-	89
Ground wire bolt	10	-	89
Ground wire eyelet nut	25	18	-
Halfshaft support bracket bolts	48	35	-
Heated oxygen sensor (HO2S)	47	35	-
Ignition coil-on-plug bolts	6	-	53
Intermediate shaft bracket nuts	27	20	
Lateral support crossmember bolts	115	85	
LH accessory drive belt idler pulley bolt	47	35	-
LH transaxle support insulator through bolt	115	85	-
Lower ball joint pinch bolts and nuts	63	46	
Lower intake manifold bolts <sup>a</sup>	-	-	-
Oil level indicator tube stud bolt	10	-	89
Oil pan baffle nuts <sup>a</sup>	-	-	-
Oil pan bolts and studs	25	18	-
Oil pan drain plug	26	19	-
Oil pan-to-transaxle bolts	40	30	-
Oil pump bolts	10	-	89
Oil pump screen and pickup tube bolts and nut	10	-	89
Output shaft speed (OSS) sensor bolt	13	10	-
Power distribution box cable nuts	12	9	-
Power transfer unit (PTU) bolts	45	33	
PTU vent tube bolt	14	10	
Powertrain control module (PCM) wiring nut	8		71
Radio interference capacitor nut	6	-	53
Rear transaxle support insulator through bolt	103	76	-
RH accessory drive belt idler pulley and bracket bolts	25	18	-
RH and LH lower splash shield bolts	9	-	80
RH transaxle support insulator bracket nuts and bolt	80	59	-
RH radio ignition interference capacitor nut	6	-	53
RH transaxle support insulator through bolt	115	85	-
Speed control actuator nuts	9	-	80
Stabilizer link-to-strut nuts	63	46	
Tie-rod end nuts	55	41	
Timing chain guide bolts	25	18	-
Timing chain tensioner bolts	25	18	-
Torque converter-to-flexplate nuts	40	30	-
Transaxle cooler tube bracket bolt	13	10	
Transaxle cooler tube fitting nut	23	17	
Transaxle-to-engine bolts	47	35	-

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

Transaxle-to-engine stud and nuts	48	35	-
Transaxle-to-oil pan bracket bolt	25	18	-
Upper intake manifold bolts <sup>a</sup>	-	-	-
Upper radiator support bracket bolts	10	-	89
Valve cover bolts and stud bolts <sup>a</sup>		-	-
Wiring harness-to-valve cover stud bolt nut	6	-	53

<sup>a</sup> Refer to the procedure.

# **DESCRIPTION AND OPERATION**

## ENGINE

The 3.0L (4V) is a V-6 engine has the following features:

- Dual overhead camshafts
- Four valves per cylinder
- Sequential multiport fuel injection (SFI)
- Composite lower intake manifold and composite upper intake manifold
- Aluminum cylinder heads
- Two-piece design aluminum cylinder block
- Electronic ignition system with 6 ignition coils

#### Identification

For quick identification refer to the safety certification decal.

- The decal is located on the LH front door lock face panel.
- An engine identification label is also attached to the engine.
- The symbol code on the identification tag identifies each engine for determining parts usage; for instance, engine displacement in liters or cubic inch displacement and model year.

#### Exhaust Emission Control System

Operation and required maintenance of the exhaust emission control devices used on this engine are covered in the **Introduction - Gasoline Engines** article.

#### Induction System

The SFI provides the fuel/air mixture needed for combustion in the cylinders. The 6 solenoid-operated fuel injectors:

• are mounted between the fuel rail and the intake manifold.

	sábado, 31 de agosto de 2019 08:14:44 a.m.	Page 7	© 2011 Mitchell Repair Information Company, L	LC.
--	--	--------	---	-----

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- meter fuel into the air intake stream in accordance with engine demand.
- are positioned so that their tips direct fuel just ahead of the engine intake valves.

#### Valve Train

The camshafts are mounted in the cylinder heads and act against a roller follower to open and close the valves. A hydraulic lash adjuster is located on one side of the roller follower and the valve tip on the opposite end. The camshafts are driven off the front of each cylinder head by 2 chains (one each side). Both of the chains are driven by sprockets that are located on the crankshaft, just in front of the oil pump.

#### Positive Crankcase Ventilation System

All engines are equipped with a closed-type positive crankcase ventilation system recycling the crankcase vapors to the upper intake manifold.

#### Lubrication System

The engine lubrication system is of the force-feed type in which oil is supplied under full pressure to the crankshaft, connecting rod bearings and timing chain tensioners. The flow of oil to the valve tappets and valve train is controlled by a restricting orifice located in the head gaskets.

#### Oil Pump

The lubrication system is designed to provide optimum oil flow to critical components of the engine through its entire operating range.

The heart of the system is a positive displacement internal gear oil pump.

Generically this design is known as a gerotor pump, which operates as follows:

- The oil pump is mounted on the front face of the cylinder block.
- The inner rotor is piloted on the crankshaft post and is driven through flats on the crankshaft.
- System pressure is limited by an integral, internally-vented relief valve which directs the bypassed oil back to the inlet side of the oil pump.
- Oil pump displacement has been selected to provide adequate volume to make sure of correct oil pressure both at hot idle and maximum speed.
- The relief valve calibration protects the system from excessive pressure during high viscosity conditions.
- The relief valve is designed to provide adequate connecting rod bearing lubrication under high-temperature and high-speed conditions.

#### **Cooling System**

The engine cooling system includes the following:

- Radiator
- Dual electric fan assemblies

sábado, 31 de agosto de 2019 08:14:44 a.m.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- Degas bottle (aids in maintaining the correct volume of engine coolant)
- Coolant thermostat
- Coolant hoses

#### **Engine Cylinder Identification**



N0069904

**Fig. 1: Engine Cylinder Identification Courtesy of FORD MOTOR CO.** 

# **DIAGNOSTIC TESTS**

#### ENGINE

For basic engine mechanical concerns, refer to **ENGINE SYSTEM - GENERAL INFORMATION** article. For driveability concerns, refer to the **Introduction - Gasoline Engines** article.

# **IN-VEHICLE SERVICING**

**UPPER INTAKE MANIFOLD** 

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0000279

<u>Fig. 2: Exploded View Of Upper Intake Manifold With Torque Specifications (1 Of 3)</u> Courtesy of FORD MOTOR CO.

Item	Part Number	Description
1	W702251	Accelerator cable snow shield bolts (2 required)
2	9E776	Accelerator cable snow shield
3	9A825	Speed control cable to throttle body
4	9A758	Accelerator cable to throttle body
5	-	Accelerator/speed control cable bracket bolt (3 required)

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0037632

# Fig. 3: Exploded View Of Upper Intake Manifold With Torque Specifications (2 Of 3) Courtesy of FORD MOTOR CO.

Item	Part Number	Description
6	W52593	Clamp
7	9D289	Fuel vapor tube
8	-	Exhaust gas recirculation (EGR) tube fitting (part of 9D477)
9	14A464	Throttle position (TP) sensor electrical connector (part of 9H589)
10	W700497	Wiring retainer (part of 9H589)
11	-	Transaxle vent tube retainer (part of 7034)
12	-	Vacuum tube (part of 9E498)
13	14A464	Idle air control (IAC) valve electrical connector (part of 9H589)
14	14A464	EGR vacuum regulator electrical connector (part of 9H589)
15	-	EGR vacuum regulator stud bolt nut
16	-	Wiring retainer (part of 9H589)
17	-	Positive crankcase ventilation (PCV) tube
18	-	Vacuum tube fitting (part of 9E498)
19	392984	Brake booster vacuum hose clamp

Page 11 © 2011 Mitchell Repair Information Company, LLC.

2007 Ford Escape	
2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner	

20	2C053	Brake booster vacuum hose
21	14A464	Engine control wiring harness electrical connectors (part of 9H589)



N0037633

#### **Fig. 4: Exploded View Of Upper Intake Manifold (3 Of 3)** Courtesy of FORD MOTOR CO.

Item	Part Number	Description
22	-	Throttle body coolant hose clamps (2 required)
23	-	Throttle body coolant hoses (2 required)
24	9Y450	Upper intake manifold bolt (8 required)
25	9424	Upper intake manifold
26	_	Upper intake manifold gasket (6 required)

#### REMOVAL

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to **JACKING AND LIFTING** article.
- 2. Drain the engine cooling system. For additional information, refer to **ENGINE COOLING** article.
- 3. Disconnect the battery ground cable. For additional information, refer to **<u>BATTERY</u>**, **<u>MOUNTING</u>** <u>**AND CABLES**</u> article.
- 4. Remove the air cleaner outlet pipe. For additional information, refer to **INTAKE AIR DISTRIBUTION AND FILTERING - 3.0L (4V)** article.

sábado, 31 de agosto de 2019 08:14:44 a.m.

Page 12 © 2011 Mitchell Repair Information Company, LLC.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 5. Remove the 2 bolts and the accelerator cable snow shield.
- 6. Disconnect the speed control and accelerator cables from the throttle body.
- 7. Remove the 3 accelerator/speed control cable bracket bolts and position the cables and brackets aside.
- 8. Disconnect the exhaust gas recirculation (EGR) tube fitting from the EGR valve.
- 9. Disconnect the fuel vapor tube from the upper intake manifold.
- 10. Disconnect the throttle position (TP) sensor electrical connector and detach the wiring retainer.
- 11. Detach the transaxle vent tube from the throttle body stud bolt.
- 12. Disconnect the vacuum harness tube fittings from the EGR valve and the EGR vacuum regulator.
- 13. Disconnect the idle air control (IAC) valve electrical connector.
- 14. Disconnect the EGR vacuum regulator electrical connector.
- 15. Remove the nut from the EGR vacuum regulator stud bolt and detach the wiring retainer.
- 16. Disconnect the positive crankcase ventilation (PCV), brake booster and vacuum harness tubes from the upper intake manifold.
- 17. Detach the main engine wiring harness electrical connectors from the upper intake manifold.
- 18. Disconnect the 2 throttle body coolant hoses.
- 19. Remove the 8 bolts and the upper intake manifold.
  - Remove and discard the gaskets.

#### INSTALLATION

# NOTE: Clean and inspect all sealing surfaces. Install new gaskets.

- 1. Position the upper intake manifold and install the bolts.
  - Tighten in the sequence shown to 10 Nm (89 lb-in).



## **Fig. 5: Identifying Tightening Sequence Of Upper Intake Manifold Bolts** Courtesy of FORD MOTOR CO.

- 2. Connect the 2 throttle body coolant hoses.
- 3. Attach the main engine wiring harness electrical connectors to the upper intake manifold.
- 4. Connect the PCV, brake booster and vacuum harness tubes to the upper intake manifold.
- 5. Attach the wiring retainer to the EGR vacuum regulator stud bolt and install the nut.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- Tighten to 6 Nm (53 lb-in).
- 6. Connect the EGR vacuum regulator electrical connector.
- 7. Connect the IAC valve electrical connector.
- 8. Connect the vacuum harness tube fittings to the EGR valve and the EGR vacuum regulator.
- 9. Attach the transaxle vent tube to the throttle body stud bolt.
- 10. Connect the TP sensor electrical connector and attach the wiring retainer.
- 11. Connect the fuel vapor tube to the upper intake manifold.
- 12. Connect the EGR tube fitting to the EGR valve.
  - Tighten to 40 Nm (30 lb-ft).
- 13. Position the accelerator/speed control cables and brackets and install the 3 bolts.
  - Tighten to 10 Nm (89 lb-in).
- 14. Attach the speed control and accelerator cables to the throttle body.
- 15. Install the accelerator cable snow shield and the 2 bolts.
  - Tighten to 10 Nm (89 lb-in).
- 16. Install the air cleaner outlet pipe. For additional information, refer to **INTAKE AIR DISTRIBUTION AND FILTERING - 3.0L (4V)** article.
- 17. Connect the battery ground cable. For additional information, refer to **<u>BATTERY, MOUNTING AND</u>** <u>**CABLES**</u> article.
- 18. Fill and bleed the engine cooling system. For additional information, refer to **ENGINE COOLING** article.

# LOWER INTAKE MANIFOLD



N0000281

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

#### Fig. 6: Exploded View Of Lower Intake Manifold **Courtesy of FORD MOTOR CO.**

Item	Part Number	Description
1	9288	Fuel tube
2	14A464	Fuel rail pressure and temperature sensor electrical connector (part of 9H589)
3	-	Fuel rail pressure and temperature sensor vacuum tube fitting (part of 9E498)
4	14A464	Fuel injector electrical connector (6 required) (part of 9H589)
5	W708187	Lower intake manifold bolt (8 required)
6	9K461	Lower intake manifold
7	9439	Lower intake manifold gasket (6 required)

#### REMOVAL

- WARNING: Do not smoke or carry lighted tobacco or open flame of any type when working on or near any fuel-related component. Highly flammable mixtures are always present and may be ignited, resulting in possible personal injury.
- WARNING: Fuel in the fuel system remains under high pressure even when the engine is not running. Before repairing or disconnecting any of the fuel system components, the fuel system pressure must be relieved to prevent accidental spraying of fuel, causing personal injury or a fire hazard.
- 1. Release the fuel system pressure. For additional information refer to **FUEL SYSTEM GENERAL INFORMATION** article.
- 2. Disconnect the battery ground cable. For additional information, refer to BATTERY, MOUNTING AND CABLES article.
- 3. Remove the upper intake manifold. For additional information, refer to **Upper Intake Manifold**.
- 4. Disconnect the fuel supply tube quick connect coupling at the fuel rail. For additional information, refer to FUEL SYSTEM - GENERAL INFORMATION article.
- 5. Disconnect the fuel rail pressure and temperature sensor electrical connector and vacuum tube.
- 6. Disconnect the 6 fuel injector electrical connectors.
- 7. Remove the 8 lower intake manifold bolts and the lower intake manifold.
  - Remove and discard the gaskets.

#### INSTALLATION

#### NOTE: Clean and inspect all sealing surfaces. Install new gaskets.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 1. Position the lower intake manifold and install the bolts.
  - Tighten in the sequence shown to 10 Nm (89 lb-in).



#### **Fig. 7: Identifying Tightening Sequence Of Lower Intake Manifold Bolts Courtesy of FORD MOTOR CO.**

- 2. Connect the fuel injector electrical connectors.
- 3. Connect the fuel rail pressure and temperature sensor electrical connector and vacuum tube.
- 4. Connect the fuel supply tube quick connect coupling at the fuel rail. For additional information, refer to **FUEL SYSTEM GENERAL INFORMATION** article.
- 5. Install the upper intake manifold. For additional information, refer to Upper Intake Manifold.
- 6. Connect the battery ground cable. For additional information, refer to **<u>BATTERY, MOUNTING AND</u>** <u>**CABLES**</u> article.

#### VALVE COVER - LH

#### Material

Item	Specification
Motorcraft Metal Surface Prep ZC-31	-
Silicone Gasket and Sealant TA-30	WSE-M4G323-A6

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0045739

# Fig. 8: Exploded View Of Left Valve Cover - 1 Of 2 (With Torque Specifications) Courtesy of FORD MOTOR CO.

Item	Part Number	Description
1	N621942	Power steering pressure (PSP) tube bracket nut
2	3A719	PSP tube bracket
3	W701627	Engine lift bracket bolt
4	17A084	Engine lift bracket
5	W702251	Accelerator cable snow shield bolt (2 required)
6	9E766	Accelerator cable snow shield
7	6853	Crankcase ventilation tube

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



# Fig. 9: Exploded View Of Left Valve Cover - 2 Of 2 (With Torque Specifications) Courtesy of FORD MOTOR CO.

Item	Part Number	Description
8	W700497	Wiring retainer (2 required) (part of 9H589)
9	13A506	Wiring retainer (2 required) (part of 9H589)
10	6C519	Valve cover bolt (5 required)
11	6C519	Valve cover stud bolt (8 required)
12	6A505	Valve cover
13	6A559	Valve cover gasket

#### REMOVAL

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

# CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, can cause engine failure.

- 1. Remove the LH ignition coil-on-plugs. For additional information, refer to **ENGINE IGNITION 3.0L** (4V) article.
- 2. Remove the power steering pressure (PSP) tube bracket nut and position the PSP tube and bracket aside.
- 3. If equipped, remove the bolt and the engine lift bracket.
- 4. Remove the 2 bolts and the accelerator cable snow shield.

# CAUTION: Do not disconnect the crankcase ventilation tube from the valve cover or damage to the ventilation tube may occur.

- 5. Disconnect the crankcase ventilation tube from the air cleaner outlet pipe.
- 6. Detach the 4 wiring retainers from the valve cover stud bolts.

#### NOTE: Inspect the crankcase ventilation tube and valve cover sealing area. If either a new valve cover or crankcase ventilation tube is required, both components must be installed new.

- 7. Remove the 5 bolts, 8 stud bolts and the valve cover.
  - Remove and discard the gasket.

#### INSTALLATION

1. Clean the valve cover, cylinder head and front cover sealing surfaces with metal surface prep and install a new valve cover gasket.

# NOTE: The valve cover must be installed and the bolts and stud bolts tightened within 4 minutes of sealant application.

- 2. Apply a 5 mm (0.19 in) dot of silicone gasket sealant to the front cover-to-cylinder head joints.
- 3. Position the valve cover and install the bolts and stud bolts.
  - Tighten in the sequence shown to 10 Nm (89 lb-in).

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 10: Identifying Tightening Sequence Of Valve Cover Bolts & Studs** Courtesy of FORD MOTOR CO.

- 4. Attach the 4 wiring retainers to the valve cover stud bolts.
- 5. Attach the crankcase ventilation tube to the air cleaner outlet pipe.
- 6. Install the accelerator cable snow shield and the 2 bolts.
  - Tighten to 10 Nm (89 lb-in).
- 7. If equipped, install the engine lift bracket and the bolt.
  - Tighten to 118 Nm (87 lb-ft).
- 8. Position the PSP tube and bracket and install the nut.
  - Tighten to 25 Nm (18 lb-ft).
- 9. Install the LH ignition coil-on-plugs. For additional information, refer to **ENGINE IGNITION 3.0L** (4V) article.

#### VALVE COVER - RH

#### Material

Item	Specification
Motorcraft Metal Surface Prep ZC-31	-
Silicone Gasket and Sealant TA-30	WSE-M4G323-A6

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0000687

#### **Fig. 11: Exploded View Of Right Valve Cover Courtesy of FORD MOTOR CO.**

Item	Part Number	Description
1	14A464	Positive crankcase ventilation (PCV) valve electrical connector (part of 12A580)
2	6K817	PCV tube
3	W700497	Wiring retainer (3 required)
4	6C519	Valve cover stud bolt (10 required)
5	6582	Valve cover
6	6584	Valve cover gasket

#### REMOVAL

# CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, can cause engine failure.

- 1. Remove the upper intake manifold. For additional information, refer to Upper Intake Manifold.
- Remove the RH ignition coil-on-plugs. For additional information, refer to <u>ENGINE IGNITION 3.0L</u> (<u>4V</u>) article.
- 3. Disconnect the positive crankcase ventilation (PCV) valve electrical connector.
- 4. Disconnect the PCV tube from the PCV valve and position it aside.

sábado, 31 de agosto de 2019 08:14:45 a.m.	Page 21	© 2011 Mitchell Repair Information Company, LLC.
, - J	J	, -

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 5. Disconnect the radio ignition interference capacitor electrical connector and detach the 3 wiring retainers from the stud bolts.
- 6. Remove the nut and the radio ignition interference capacitor.
- 7. Remove the 2 nuts and position the engine control harness aside.
- 8. Remove the bolt, 9 stud bolts and the valve cover.
  - Remove and discard the gasket.

#### **INSTALLATION**

1. Clean the valve cover, cylinder head and front cover sealing surfaces with metal surface prep and install a new valve cover gasket.

#### NOTE: The valve cover must be installed and the bolts and stud bolts tightened within 4 minutes of sealant application.

- 2. Apply a 5 mm (0.19 in) dot of silicone gasket sealant to the front cover-to-cylinder head joints.
- 3. Position the valve cover and install the stud bolts.
  - Tighten in the sequence shown to 10 Nm (89 lb-in).



N0000349

#### Fig. 12: Identifying Tightening Sequence Of Valve Cover Stud Bolts **Courtesy of FORD MOTOR CO.**

- 4. Position the engine control harness and install the nuts.
  - Tighten to 6 Nm (53 lb-in).
- 5. Install the radio ignition interference capacitor and the nut.
  - Tighten to 6 Nm (53 lb-in).
- 6. Attach the wiring retainers to the stud bolts and connect the radio ignition interference capacitor electrical connector.
- 7. Connect the PCV tube to the PCV valve.
- 8. Connect the PCV valve electrical connector.
- 9. Install the RH ignition coil-on-plugs. For additional information, refer to ENGINE IGNITION 3.0L (4V) article.
- 10. Install the upper intake manifold. For additional information, refer to Upper Intake Manifold.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

## LOWER END COMPONENTS - EXPLODED VIEW



#### N0062467

# **Fig. 13: Exploded View Of Crankshaft Pulley and Front Seal Courtesy of FORD MOTOR CO.**

Item	Part Number	Description
1	W701512	Crankshaft pulley bolt
2	W701511	Washer
3	6316	Crankshaft pulley
4	6700	Crankshaft front seal

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0062468

# **Fig. 14: Exploded View Of Flexplate and Rear Seal** Courtesy of FORD MOTOR CO.

Item	Part Number	Description
1	W701559	Flexplate bolt (8 required)
2	6375	Flexplate
3	6701	Crankshaft rear oil seal

1. For additional information, refer to the following procedures.

#### **CRANKSHAFT PULLEY**

#### **Special Tools**

Illustration	Tool Name	<b>Tool Number</b>
	Strap Wrench	303-D055 (D85L-6000-A)
ST1438-A		
ST1287-A	Replacer, Crankshaft Damper	303-102 (T74P-6316-B)

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

Remover, Crankshaft Vibration Damper 303-009 (T58P-6316-D)
---

#### Material

Item	Specification
Motorcraft SAE 5W-20 Premium Synthetic Blend Motor Oil XO-5W20-QSP (US); Motorcraft SAE 5W-20 Super Premium Motor Oil CXO-5W20-LSP12 (Canada); or equivalent	WSS-M2C930-A
Silicone Gasket and Sealant TA-30	WSE-M4G323-A4
Motorcraft Metal Surface Prep ZC-31	-

#### REMOVAL

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to <u>JACKING</u> <u>AND LIFTING</u> article.
- 2. Remove the accessory drive belt. For additional information, refer to <u>ACCESSORY DRIVE 3.0L (4V)</u> article.
- 3. Use the special tool to hold the crankshaft pulley and remove the crankshaft pulley bolt.



#### Fig. 15: Locating Special Tool (303-D055) And Crankshaft Pulley Bolt Courtesy of FORD MOTOR CO.

4. Using the special tool, remove the crankshaft pulley.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 16: Removing Crankshaft Pulley Using Special Tool (303-009)** Courtesy of FORD MOTOR CO.

#### INSTALLATION

1. Lubricate the front cover and the crankshaft front seal inner lip with clean engine oil.

# NOTE: Clean the keyway and slot using metal surface prep before applying silicone gasket and sealer.

# NOTE: The crankshaft pulley must be installed and the bolt tightened within 4 minutes of applying the silicone gasket and sealer.

2. Apply silicone gasket and sealant to the end of the keyway slot.



A0010615

**Fig. 17: Applying Silicone Gasket And Sealant Courtesy of FORD MOTOR CO.** 

# NOTE: Lubricate the outside diameter sealing surface with clean engine oil.

3. Using the special tool, install the crankshaft pulley.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 18: Installing Crankshaft Pulley Using Special Tools (303-102, 303-335)** Courtesy of FORD MOTOR CO.

- 4. Install the bolt and washer. Using the special tool to hold the crankshaft pulley, tighten the bolt in 4 stages:
  - Stage 1: Tighten to 120 Nm (89 lb-ft).
  - Stage 2: Loosen one full turn.
  - Stage 3: Tighten to 50 Nm (37 lb-ft).
  - Stage 4: Tighten an additional 90 degrees.



#### **Fig. 19: Locating Special Tool (303-D055) And Crankshaft Pulley Bolt** Courtesy of FORD MOTOR CO.

# CRANKSHAFT FRONT SEAL

#### **Special Tools**

Illustration	Tool Name	Tool Number	
ST1385-A	Remover, Oil Seal	303-409 (T92C-6700CH)	
	Installer, Front Cover Seal	303-335 (T88T-6701-A)	

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### Material

Item	Specification
Motorcraft Metal Surface Prep	
ZC-31	
Motorcraft SAE 5W-20 Premium Synthetic Blend	
Motor Oil	
XO-5W20-QSP (US); Motorcraft SAE 5W-20	WSS-M2C930-A
Super Premium Motor Oil CXO-5W20-LSP12	
(Canada); or equivalent	

#### REMOVAL

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to <u>JACKING</u> <u>AND LIFTING</u> article.
- 2. Remove the crankshaft pulley. For additional information, refer to Crankshaft Pulley.
- 3. Using the special tool, remove and discard the crankshaft front seal.



**Fig. 20: Removing Crankshaft Front Seal Using Special Tool (303-409)** Courtesy of FORD MOTOR CO.

#### INSTALLATION

#### NOTE: Clean all sealing surfaces with metal surface prep.

- 1. Apply clean engine oil to the seal lip and seal bore before installing the seal.
- 2. Using the special tools, install a new crankshaft front seal.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 21: Installing Crankshaft Seal Using Special Tools (303-335 And 303-102)** Courtesy of FORD MOTOR CO.

3. Install the crankshaft pulley. For additional information, refer to Crankshaft Pulley.

## FLEXPLATE

#### **REMOVAL AND INSTALLATION**

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to <u>JACKING</u> <u>AND LIFTING</u> article.
- 2. Remove the transmission. For additional information, refer to <u>AUTOMATIC</u> <u>TRANSAXLE/TRANSMISSION - CD4E</u> article.
- 3. Remove the bolts and the flexplate.
  - To install, tighten to 80 Nm (59 lb-ft).
- 4. To install, reverse the removal procedure.

#### CRANKSHAFT REAR SEAL

#### **Special Tools**

Illustration	Tool Name	Tool Number
ST1187-A	Slide Hammer	307-005 (Т59L-100-В)
	Remover, Crankshaft Rear Seal	303-519 (T95P-6701-EH)
ST1382-A		
	Installer, Crankshaft Rear Main Oil Seal	303-178 (T82L-6701-A)

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

5T1327-A		
ST1333-A	Installer Bolts, Crankshaft Rear Main Oil Seal	303-384 (T91P-6701-A)

#### Material

Item	Specification
Motorcraft Metal Surface Prep	-
ZC-31	
Motorcraft SAE 5W-20 Premium Synthetic Blend	
Motor Oil	
XO-5W20-QSP (US); Motorcraft SAE 5W-20	WSS-M2C930-A
Super Premium Motor Oil CXO-5W20-LSP12	
(Canada); or equivalent	

#### REMOVAL

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to **JACKING** AND LIFTING article.
- 2. Remove the flexplate. For additional information, refer to Flexplate.
- 3. Using the special tools, remove and discard the crankshaft rear oil seal.



#### Fig. 22: Identifying Special Tools (307-005 And 303-519) **Courtesy of FORD MOTOR CO.**

#### **INSTALLATION**

#### NOTE: Clean all sealing surfaces with metal surface prep.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

# NOTE: Apply clean engine oil to the seal lip and seal bore before installing the seal.

1. Using the special tools, install the crankshaft rear oil seal.



#### **Fig. 23: Identifying Special Tools (303-384 And 303-178)** Courtesy of FORD MOTOR CO.

2. Install the flexplate. For additional information, refer to **Flexplate**.

## **ENGINE FRONT COVER**

#### Material

Item	Specification
Motorcraft Metal Surface Prep	-
ZC-31 Silicone Gasket and Sealant	
TA-30	WSE-M4G323-A6
Motorcraft SAE 5W-20 Premium Synthetic Blend Motor Oil	
XO-5W20-QSP (US); Motorcraft SAE 5W-20	WSS-M2C930-A
(Canada); or equivalent	

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0043947

# <u>Fig. 24: Exploded View Of Engine Front Cover Components - 1 Of 3 (With Torque Specifications)</u> Courtesy of FORD MOTOR CO.

Item	Part Number		Description
1	W505415		Generator upper air duct bolt
2	10C392		Generator upper air duct
3	W505415		Generator shield bolt
4	W705848		Pin-type retainer
5	10A389		Generator shield
6	W709986		Generator bolt (2 required)
7	W520414		Generator stud nut
8	W710416		Generator stud
9	10300		Generator
10	W701542		Heated oxygen sensor (HO2S) electrical
sábado, 31 de	e agosto de 2019 08:14:45 a.m.	Page 32	© 2011 Mitchell Repair Information Company, L

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



<u>Fig. 25: Exploded View Of Engine Front Cover Components - 2 Of 3 (With Torque Specifications)</u> Courtesy of FORD MOTOR CO.

Item	Part Number	Description
12	W701625	Accessory drive belt tensioner bolt
13	6B209	Accessory drive belt tensioner
14	-	Accessory drive belt idler pulley bolt (part of 6C348)
15	6C348	Accessory drive belt idler pulley
16	14A464	Crankshaft position (CKP) sensor electrical connector (part of 9H589)
17	14A464	Camshaft position (CMP) sensor electrical connector (part of 9H589)
18	W701656	Power steering pump bolt (3 required)
19	3A696	Power steering pump
20	W708221	Engine front cover bolt (3 required)
21	W708222	Engine front cover bolt (3 required)

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0043948

#### Fig. 26: Exploded View Of Engine Front Cover Components - 3 Of 3 (With Torque Specifications) Courtesy of FORD MOTOR CO.

Item	Part Number	Description
22	W709678	Oil pan-to-front cover bolts (2 required)
23	W701525	Engine front cover bolt (7 required)
24	W710030	Engine front cover stud bolt (3 required)
25	6019	Engine front cover
26	-	Engine front cover gasket (3 required)

REMOVAL

# CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, can cause engine failure.

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to <u>JACKING</u> <u>AND LIFTING</u> article.
- 2. Release the fuel system pressure. For additional information, refer to <u>FUEL SYSTEM GENERAL</u> <u>INFORMATION</u> article.
- 3. Disconnect the battery ground cable. For additional information, refer to **<u>BATTERY, MOUNTING</u>** <u>AND CABLES</u> article.
- 4. Remove the crankshaft front seal. For additional information, refer to <u>Lower End Components -</u> <u>Exploded View</u> and <u>Crankshaft Front Seal</u>.

sábado, 31 de agosto de 2019 08:14:45 a.m.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

5. Remove the 5 bolts and the pin-type retainer and the RH lower splash shield.



# **Fig. 27: Locating RH Lower Splash Shield Bolts Courtesy of FORD MOTOR CO.**

- 6. Remove the generator upper air duct bolt and the air duct.
- 7. Remove the generator shield pin-type retainer, bolt and the generator shield.
- 8. Remove the 2 generator bolts.
- 9. Remove the generator stud nut and stud and position the generator aside.
- 10. Remove the LH and RH valve covers. For additional information, refer to <u>Valve Cover LH</u> and <u>Valve</u> <u>Cover RH</u>.
- 11. Remove the engine support insulator. For additional information, refer to **Engine Support Insulators**.
- 12. Remove the bolt and the accessory drive belt tensioner.
- 13. Remove the bolt and the idler pulley.
- 14. Remove the nut and position the heated oxygen sensor (HO2S) electrical connector bracket aside.
- 15. Disconnect the crankshaft position (CKP) sensor electrical connector.
- 16. Disconnect the camshaft position (CMP) sensor electrical connector.

# NOTE: The bolt positioned behind the power steering pressure tube will remain in the pump housing.

- 17. Remove the 3 power steering pump bolts and position the power steering pump aside.
- 18. If equipped, remove the 3 nuts and position the speed control actuator aside.
- 19. Remove the 2 oil pan-to-front cover bolts.
- 20. Remove the 13 bolts, 3 stud bolts and the engine front cover.
  - Remove and discard the gaskets.

#### INSTALLATION

#### CAUTION: Do not use metal scrapers, wire brushes, power abrasive discs or other abrasive means to clean the sealing surfaces. These tools cause scratches and gouges which make leak paths.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

# CAUTION: Do not damage the oil pan gasket while cleaning the sealant from the lower cylinder block-to-oil pan joint.

- 1. Use a plastic scraping tool to remove all traces of sealant.
  - Clean all sealing surfaces with metal surface prep and install new gaskets.

# NOTE: The engine front cover must be installed and the bolts tightened within 4 minutes of applying sealant.

2. Apply a 6 mm (0.23 in) diameter dot of silicone gasket and sealer to the cylinder block, lower cylinder block, cylinder head and oil pan mating surfaces.



**Fig. 28: Identifying Area For Applying Sealant** Courtesy of FORD MOTOR CO.

# NOTE: Fasteners 1, 8 and 16 are stud bolts.

- 3. Position the engine front cover and install the bolts.
  - Tighten in the sequence shown to 25 Nm (18 lb-ft).
2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0000340

## Fig. 29: Identifying Tightening Sequence Of Front Cover Bolts Courtesy of FORD MOTOR CO.

- 4. Install the 2 oil pan-to-front cover bolts.
  - Tighten to 25 Nm (18 lb-ft).
- 5. Remove the oil pan plug and drain the engine oil.
  - Install the plug and tighten to 26 Nm (19 lb-ft).
- 6. Position the power steering pump and install the 3 bolts.
  - Tighten to 25 Nm (18 lb-ft).
- 7. Connect the CMP electrical connector.
- 8. Connect the CKP electrical connector.
- 9. Position the HO2S bracket and install the nut.
  - Tighten to 10 Nm (89 lb-in).
- 10. Install the idler pulley and the bolt.
  - Tighten to 25 Nm (18 lb-ft).
- 11. Install the accessory drive belt tensioner and the bolt.
  - To install, tighten to 45 Nm (33 lb-ft).
- 12. If equipped, install the speed control actuator and 3 nuts.
- 13. Install the engine support insulator. For additional information, refer to **Engine Support Insulators**.
- 14. Install the LH and RH valve covers. For additional information, refer to <u>Valve Cover LH</u> and <u>Valve</u> <u>Cover RH</u>.
- 15. Position the generator and install the stud.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- Tighten to 7 Nm (62 lb-in).
- 16. Install the generator stud nut.
  - Tighten to 47 Nm (35 lb-ft).
- 17. Install the 2 generator bolts.
  - Tighten to 47 Nm (35 lb-ft).
- 18. Install the generator shield, bolt and pin-type retainer.
  - Tighten to 4 Nm (35 lb-in).
- 19. Install the generator upper air duct and the bolt.
  - Tighten to 4 Nm (35 lb-in).
- 20. Install the RH lower splash shield, 5 bolts and the pin-type retainer.
  - Tighten to 9 Nm (80 lb-in).



**Fig. 30: Locating RH Lower Splash Shield Bolts** Courtesy of FORD MOTOR CO.

- 21. Install the crankshaft front seal. For additional information, refer to <u>Lower End Components Exploded</u> <u>View</u> and <u>Crankshaft Front Seal</u> in this section.
- 22. Fill the engine with clean engine oil.
- 23. Connect the battery ground cable. For additional information, refer to **<u>BATTERY, MOUNTING AND</u>** <u>**CABLES**</u> article.

### TIMING DRIVE COMPONENTS

#### REMOVAL

- CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, can cause engine failure.
- CAUTION: Failure to verify correct timing drive component alignment will result in severe engine damage.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

1. Remove the engine front cover. For additional information, refer to **Engine Front Cover**.

CAUTION: This pulse wheel is used in several different engines. Install the pulse wheel with the keyway in the slot stamped "30" or "30RFF" (orange in color).

2. Remove the ignition pulse wheel.



## **Fig. 31: Identifying Ignition Pulse Wheel** Courtesy of FORD MOTOR CO.

3. Install the damper bolt.



Fig. 32: Identifying Damper Bolt Courtesy of FORD MOTOR CO.

# NOTE: LH shown, RH similar.

4. Remove the LH and RH spark plugs.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### A0026583

# **Fig. 33: Locating Spark Plugs** Courtesy of FORD MOTOR CO.

- 5. Rotate the crankshaft clockwise to position the crankshaft keyway in the 11 o'clock position and position the camshafts in the correct position. This will position the number one cylinder at top dead center (TDC).
  - Verify that the camshafts are correctly located. If not, rotate the crankshaft one additional turn and recheck.



#### Fig. 34: Identifying Crankshaft Keyway In 11 O'Clock Position Courtesy of FORD MOTOR CO.

6. Rotate the crankshaft clockwise 120 degrees to the 3 o'clock position to locate the RH camshafts in the neutral position.



A0011067

**Fig. 35: Identifying Crankshaft Keyway** Courtesy of FORD MOTOR CO.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

7. Verify that the RH camshafts are in the neutral position.



**Fig. 36: Locating Camshafts Align Marks Courtesy of FORD MOTOR CO.** 

- 8. Remove the RH timing chain tensioner arm.
  - 1. Remove the bolts.
  - 2. Remove the tensioner.
  - 3. Remove the tensioner arm.



### **Fig. 37: Identifying RH Timing Chain Tensioner Arm & Bolts** Courtesy of FORD MOTOR CO.

9. Remove the bolts, RH timing chain guide and the timing chain.



**Fig. 38: Locating Timing Chain Guide & Bolts** Courtesy of FORD MOTOR CO.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

10. Rotate the crankcase clockwise 600 degrees (1-2/3 turns) to position the crankcase keyway in the 11 o'clock position. This will position the LH camshafts in the neutral position.



**Fig. 39: Positioning Crankcase Key Way In 11 O'Clock Position** Courtesy of FORD MOTOR CO.

11. Verify the LH camshafts are in the neutral position.



#### **Fig. 40: Locating Camshafts Aligning Marks** Courtesy of FORD MOTOR CO.

- 12. Remove the LH timing chain and tensioner arm.
  - 1. Remove the bolts.
  - 2. Remove the tensioner.
  - 3. Remove the tensioner arm.



# Fig. 41: Locating LH Timing Chain & Tensioner Arm

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

# **Courtesy of FORD MOTOR CO.**

13. Remove the LH timing chain and timing chain guide.



#### **Fig. 42: Locating Timing Chain & Timing Chain Guide** Courtesy of FORD MOTOR CO.

14. Remove the damper bolt and the crankshaft sprockets.



#### **Fig. 43: Locating Damper Bolt & Crankshaft Sprockets Courtesy of FORD MOTOR CO.**

### INSTALLATION

# CAUTION: Failure to verify correct timing drive component alignment will result in severe engine damage.

1. Install the crankshaft sprockets with the timing marks out.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



**Fig. 44: Locating Crankshaft Sprockets With Timing Marks Out** Courtesy of FORD MOTOR CO.

### NOTE: LH shown, RH similar.

2. Position the chain tensioner in a soft-jawed vise.



**Fig. 45: Identifying Chain Tensioner In Soft-Jawed Vise** Courtesy of FORD MOTOR CO.

# NOTE: LH shown, RH similar.

3. Hold the chain tensioner ratchet lock mechanism away from the ratchet stem with a small pick.



**Fig. 46: Holding Chain Tensioner Ratchet Lock Mechanism Away From Ratchet Stem Courtesy of FORD MOTOR CO.** 

#### CAUTION: During tensioner compression, do not release the ratchet stem until the tensioner piston is fully bottomed in its bore or damage to the ratchet stem will result.

- 4. Slowly compress the timing chain tensioner.
- 5. Retain the tensioner piston with a 1.5 mm (0.05 in) wire or paper clip.



#### Fig. 47: Retaining Tensioner Piston With 1.5-mm (0.06-in) Wire Or Paper Clip Courtesy of FORD MOTOR CO.

- 6. If timing marks in the timing chains are not evident, use a permanent-type marker to mark the crankshaft and camshaft timing marks on the LH and RH timing chains.
  - 1. Mark any link to use as the crankshaft timing mark.
  - 2. Starting with the crankshaft timing mark, count 29 links and mark the link.
  - 3. Continue counting to link 42 and mark the link.



#### Fig. 48: Locating Crankshaft & Camshaft Timing Marks On LH & RH Timing Chains Courtesy of FORD MOTOR CO.

7. Verify that the LH camshafts are correctly positioned.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 49: Locating Camshafts Aligning Marks** Courtesy of FORD MOTOR CO.

- 8. Position the LH timing chain and guide and install the bolts.
  - Align the marks on the timing chain with the marks on the camshaft and crankshaft sprockets.
  - Tighten to 25 Nm (18 lb-ft).



### Fig. 50: Aligning Marks On Timing Chain With Marks On Camshaft And Crankshaft Sprockets Courtesy of FORD MOTOR CO.

- 9. Install the LH timing chain tensioner arm and the LH timing chain tensioner.
  - 1. Install the tensioner arm.
  - 2. Position the tensioner.
  - 3. Install the bolts.
  - 4. Tighten to 25 Nm (18 lb-ft).



2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

#### **Fig. 51: Identifying Timing Chain Tensioner Arm & Bolts Courtesy of FORD MOTOR CO.**

10. Install the crankshaft damper bolt and rotate the crankshaft clockwise 120 degrees until the crankshaft keyway is in the 3 o'clock position.



**Fig. 52: Locating Crankshaft Keyway Courtesy of FORD MOTOR CO.** 

11. Verify that the RH camshafts are correctly positioned.



**Fig. 53: Locating Camshafts Align Marks** Courtesy of FORD MOTOR CO.

- 12. Install the RH timing chain and chain guide and install the bolts.
  - Align the marks on the timing chain with the marks on the camshaft and crankshaft sprockets.
  - Tighten to 25 Nm (18 lb-ft).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### Fig. 54: Aligning Marks On Timing Chain With Marks On Camshaft And Crankshaft Sprockets Courtesy of FORD MOTOR CO.

- 13. Install the RH timing chain tensioner and tensioner arm.
  - 1. Install the tensioner arm.
  - 2. Position the tensioner.
  - 3. Install the bolts.
  - 4. Tighten to 25 Nm (18 lb-ft).



### **Fig. 55: Identifying Tensioner Arm, Tensioner And Bolts** Courtesy of FORD MOTOR CO.

- 14. Remove the LH and RH timing chain tensioner piston retaining wires.
- 15. Rotate the crankshaft counterclockwise 120 degrees to top dead center (TDC).

# CAUTION: Failure to verify correct timing drive component alignment will result in severe engine damage.

- 16. Verify the timing with the following steps.
  - 1. There should be 12 chain links between the camshaft timing marks.
  - 2. There should be 27 chain links between the camshaft and the crankshaft timing marks.
  - 3. There should be 30 chain links between the camshaft and the crankshaft timing marks.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0031782

#### **Fig. 56: Checking Chain Links Timing Marks** Courtesy of FORD MOTOR CO.

17. Remove the crankshaft damper bolt.



A0011064

**Fig. 57: Identifying Damper Bolt** Courtesy of FORD MOTOR CO.

# CAUTION: This pulse wheel is used in several different engines. Install the pulse wheel with the keyway in the slot stamped "30" or "30RFF" (orange in color).

18. Install the ignition pulse wheel.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 58: Identifying Ignition Pulse Wheel Courtesy of FORD MOTOR CO.**

- 19. Install the LH and RH spark plugs.
  - Tighten to 15 Nm (11 lb-ft).



**<u>Fig. 59: Locating Spark Plugs</u>** Courtesy of FORD MOTOR CO.

20. Install the engine front cover. For additional information, refer to **Engine Front Cover**.

# VALVE TRAIN COMPONENTS - EXPLODED VIEW

### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0062732

# Fig. 60: Exploded View Of Left Valve Train Components (With Torque Specifications) Courtesy of FORD MOTOR CO.

Item	Part Number		Description
1	6A266		LH intake camshaft
2	6B280		Intake camshaft thrust bearing cap
3	W710702		Intake camshaft thrust bearing cap bolt (2 required)
4	6A258		Intake camshaft bearing cap (3 required)
5	W710702		Intake camshaft bearing cap bolt (6 required)
6	6A266		LH exhaust camshaft
7	6B280		Exhaust camshaft thrust bearing cap
8	W710702		Exhaust camshaft thrust bearing cap bolt
sábado, 31 de	e agosto de 2019 08:14:45 a.m.	Page 51	© 2011 Mitchell Repair Information Company, I

# 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

		(2 required)
9	6B280	Exhaust camshaft bearing cap (4 required)
10	W710702	Exhaust camshaft bearing cap bolt (8 required)
11	6A359	Coolant pump drive pulley
12	6K292	Camshaft oil seal
13	W701242	Camshaft oil seal retainer bolt (2 required)
14	6B293	Camshaft oil seal retainer
15	6B295	Camshaft oil seal retainer gasket
16	6529	Roller follower (12 required)
17	6518	Valve spring retainer key (24 required)
18	6514	Valve spring retainer (12 required)
19	6513	Valve spring (12 required)
20	6A517	Valve stem seal (12 required)
21	6C501	Hydraulic lash adjuster (12 required)

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0062733

Б

# <u>Fig. 61: Exploded View Of Right Valve Train Components (With Torque Specifications)</u> Courtesy of FORD MOTOR CO.

Item	Part Number	Description
1	6529	Roller follower
2	6518	Valve spring retainer key
3	6514	Valve spring retainer
4	6513	Valve spring
5	6A517	Valve stem seal
6	6C501	Hydraulic lash adjuster
7	W710702	Camshaft bearing cap bolt (16 required)
8	6B280	Camshaft bearing thrust cap (2 required)
9	6A258	Camshaft bearing cap (6 required)
10	6A266	Exhaust camshaft

Page 53 © 2011 Mitchell Repair Information Company, LLC.

# 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

11 6A266 Intake camsha	aft
------------------------	-----

1. For additional information, refer to the following procedures.

# **CAMSHAFTS - LH**

**Special Tools** 

Illustration	<b>Tool Name</b>	Tool Number
ST1970-A	Installer, Camshaft Oil Seal	303-464 (T94P-6256-BH)
ST3042-A	Installer, Camshaft Pulley	303-458 (T94P-6312-AH3), part of 303-S455
ST1586-A	Installer, Power Steering Pump Pulley	211-185 (T91P-3A733-A)
5T3044-A	Plate, Water Pump Pulley	303-456 (T94P-6312-AH1), part of 303-S455
ST2060-A	Protector, Camshaft Oil Seal	303-463 (T94P-6256-AH)
ST3D45-A	Protector, Water Pump Shaft	303-457 (T94P-6312-AH2), part of 303-S455
	Remover, Crankshaft Vibration Damper	303-009 (T58P-6316-D)

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### Material

Item	Specification
Motorcraft Metal Surface Prep	
ZC-31	
Motorcraft SAE 5W-20 Premium Synthetic Blend	
Motor Oil	
XO-5W20-QSP (US); Motorcraft SAE 5W-20	WSS-M2C930-A
Super Premium Motor Oil CXO-5W20-LSP12	
(Canada); or equivalent	

#### REMOVAL

- 1. Remove the coolant pump belt. For additional information refer to <u>ACCESSORY DRIVE 3.0L (4V)</u> article.
- 2. Remove the timing drive components. For additional information, refer to **<u>Timing Drive Components</u>**.

# CAUTION: Failure to use the correct special tools, assembled as shown in the illustration, will result in damage to the coolant pump pulley and/or special tools.

3. Using the special tools, remove the coolant pump pulley.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



Fig. 62: Removing Coolant Pump Pulley Courtesy of FORD MOTOR CO.

### CAUTION: To make sure of correct sealing, do not scratch the camshaft.

4. Using the special tools, remove and discard the camshaft oil seal.



#### **Fig. 63: Identifying Special Tools (303-409)** Courtesy of FORD MOTOR CO.

- 5. Remove the 2 bolts and the camshaft oil seal retainer.
  - Discard the press-in-place gasket.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



Fig. 64: Locating Camshaft Oil Seal Retainer & Bolts Courtesy of FORD MOTOR CO.

> CAUTION: Cylinder head camshaft bearing caps must be assembled in their original positions. Some engines have factory markings on the camshaft bearing caps (as shown in illustration). Engines that do not have the factory markings must be marked for correct position and orientation prior to removal. Failure to install the camshaft bearing caps in their original position may result in severe engine damage.

6. If necessary, mark the camshaft bearing cap position and orientation as shown in the illustration.



Fig. 65: Marking Camshaft Bearing Caps Courtesy of FORD MOTOR CO.

### CAUTION: After loosening all of the camshaft bearing cap bolts, remove the

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

# camshaft bearing thrust caps (1L and 6L) first, or damage to the thrust caps may occur.

# NOTE: Make sure the camshaft bearing caps are marked as instructed in the previous step.

- 7. Loosen the bolts evenly in the sequence shown.
  - 1. Remove the camshaft bearing thrust caps (1L and 6L).
  - 2. Remove the remaining camshaft bearing caps.
  - 3. Remove the camshafts from the cylinder head.



#### **Fig. 66: Identifying Loosening Sequence Of Camshaft Bearing Thrust Caps** Courtesy of FORD MOTOR CO.

#### INSTALLATION

- 1. Lubricate the camshafts with clean engine oil and carefully position the camshafts into the cylinder head.
  - Align the camshafts as shown.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



**Fig. 67: Locating Camshafts Aligning Marks** Courtesy of FORD MOTOR CO.

CAUTION: The camshaft caps must be installed in their original positions or damage to the engine may occur.

# CAUTION: Do not install the camshaft journal thrust caps until all of the camshaft bearing caps have been installed, or damage to the thrust caps may occur.

- 2. Lubricate the bearing surfaces of the camshaft bearing caps with clean engine oil and install the bearing caps.
  - Loosely install the bolts.



### <u>Fig. 68: Locating Camshaft Bearing Caps Installing Sequence</u> Courtesy of FORD MOTOR CO.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 3. Lubricate the bearing surfaces of the camshaft bearing thrust caps with clean engine oil and install the bearing thrust caps.
  - Loosely install the bolts.



#### **Fig. 69: Locating Camshaft Bearing Thrust Caps** Courtesy of FORD MOTOR CO.

- 4. Install the bolts.
  - Tighten in the sequence shown to 8 Nm (71 lb-in).



**Fig. 70: Identifying Tightening Sequence Of Bolts Courtesy of FORD MOTOR CO.** 

# NOTE: Clean the sealing surfaces with metal surface prep before installing a new press-in-place gasket.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 5. Install the camshaft oil seal retainer and the 2 bolts.
  - Tighten to 10 Nm (89 lb-in).



Fig. 71: Locating Camshaft Oil Seal Retainer & Bolts Courtesy of FORD MOTOR CO.

# NOTE: Lubricate the camshaft oil seal with clean engine oil.

6. Using the special tools, install the camshaft oil seal.



**Fig. 72: Identifying Special Tools (303-463, 303-464 And 211-185)** Courtesy of FORD MOTOR CO.

# CAUTION: Failure to use the correct special tools, assembled as shown in the illustration, will result in damage to the coolant pump pulley and/or special tools.

- 7. Install the special tool on the camshaft as shown in the illustration.
  - Adjust the collar on the special tool screw to get the best thread engagement in the rear of the camshaft.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



Fig. 73: Installing Special Tool On Camshaft Courtesy of FORD MOTOR CO.

CAUTION: Failure to use the correct special tools, assembled as shown in the illustration, will result in damage to the coolant pump pulley and/or special tools.

# NOTE: Only the roller collared nut from the Power Steering Pump Pulley Installer (211-185) is used on Camshaft Pulley Installer (303-458).

- 8. Position the coolant pump pulley over the previously installed special tool and on the end of the camshaft. Install the special tools as shown in the illustration.
  - Using the special tools, install a new service coolant pump pulley flush with the end of the camshaft.



**Fig. 74: Installing Coolant Pump Pulley** Courtesy of FORD MOTOR CO.

- 9. Install the timing drive components. For additional information, refer to **<u>Timing Drive Components</u>**.
- 10. Install the coolant pump belt. For additional information refer to <u>ACCESSORY DRIVE 3.0L (4V)</u> article.

# CAMSHAFTS - RH

#### Material

Item		Specification
sábado, 31 de agosto de 2019 08:14:45 a.m.	Page 62	© 2011 Mitchell Repair Information Company, LLC

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

Motorcraft SAE 5W-20 Premium Synthetic Blend Motor Oil XO-5W20-QSP (US); Motorcraft SAE 5W-20 Super Premium Motor Oil CXO-5W20-LSP12 (Canada); or equivalent	WSS-M2C930-A
--	--------------

#### REMOVAL

- 1. Remove the timing drive components. For additional information, refer to **<u>Timing Drive Components</u>**.
  - CAUTION: Cylinder head camshaft bearing caps must be assembled in their original positions. Some engines have factory markings on the camshaft bearing caps (as shown in illustration). Engines that do not have the factory markings must be marked for correct position and orientation prior to removal. Failure to install the camshaft bearing caps in their original position may result in severe engine damage.
- 2. If necessary, mark the camshaft bearing cap position and orientation as shown in the illustration.



N0071873

**Fig. 75: Marking Camshaft Bearing Cap Positions** Courtesy of FORD MOTOR CO.

CAUTION: After loosening all of the camshaft bearing cap bolts, remove the camshaft bearing thrust caps (5R and 1R) first, or damage to the thrust caps may occur.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

# NOTE: Make sure the camshaft bearing caps are marked as instructed in the previous step.

- 3. Loosen the bolts evenly in the sequence shown.
  - 1. Remove the camshaft bearing thrust caps (5R and 1R).
  - 2. Remove the remaining camshaft bearing caps.
  - 3. Remove the camshafts from the cylinder head.



N0045707

### <u>Fig. 76: Identifying Loosening Sequence Of Camshaft Bearing Bolts</u> Courtesy of FORD MOTOR CO.

#### INSTALLATION

- 1. Lubricate the camshafts with clean engine oil and carefully position the camshafts into the cylinder head.
  - Align the camshafts as shown.



2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

**Fig. 77: Locating Camshafts Align Marks** Courtesy of FORD MOTOR CO.

# CAUTION: The camshaft caps must be installed in their original positions or damage to the engine may occur.

# CAUTION: Do not install the camshaft bearing thrust caps until all of the camshaft bearing caps have been installed, or damage to the thrust caps may occur.

- 2. Lubricate the bearing surfaces of the camshaft bearing caps with clean engine oil and install the bearing caps.
  - Loosely install the bolts.
- 3. Lubricate the bearing surfaces of the camshaft bearing thrust caps with clean engine oil and install the bearing thrust caps.
  - Loosely install the bolts.
- 4. Install the bolts.
  - Tighten in the sequence shown to 10 Nm (89 lb-in).



N0000342

# **Fig. 78: Identifying Tightening Sequence Of Bolts Courtesy of FORD MOTOR CO.**

5. Install the timing drive components. For additional information, refer to **<u>Timing Drive Components</u>**.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

## CAMSHAFT ROLLER FOLLOWER

#### **Special Tools**

Illustration	Tool Name	Tool Number
ST1975-A	Compressor, Valve Spring	303-473 (T94P-6565-BH)

#### Material

Item	Specification
Motorcraft SAE 5W-20 Premium Synthetic Blend	
Motor Oil	
XO-5W20-QSP (US); Motorcraft SAE 5W-20	WSS-M2C930-A
Super Premium Motor Oil CXO-5W20-LSP12	
(Canada); or equivalent	

#### **REMOVAL AND INSTALLATION**

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to **JACKING** AND LIFTING article.
- 2. Remove the LH and RH valve covers. For additional information, refer to <u>Valve Cover LH</u> and <u>Valve</u> <u>Cover RH</u>.

# CAUTION: Only use hand tools when removing or installing the spark plugs or damage may occur to the cylinder head or spark plug.

- 3. Remove the 6 spark plugs.
  - To install, tighten to 15 Nm (11 lb-ft).
- 4. Remove the RH splash shield.
  - To install, tighten to 9 Nm (80 lb-in).
- 5. Rotate the crankshaft until the camshaft lobe is pointing directly away from the roller follower.
- 6. Using the special tool, remove the roller followers.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 79: Removing Roller Using Special Tool (303-473)** Courtesy of FORD MOTOR CO.

### NOTE: Lubricate the camshaft followers with clean engine oil.

7. To install, reverse the removal procedure.

# HYDRAULIC LASH ADJUSTER

#### Material

Item	Specification
Motorcraft SAE 5W-20 Premium Synthetic Blend	
XO-5W20-QSP (US); Motorcraft SAE 5W-20	WSS-M2C930-A
Super Premium Motor Oil CXO-5W20-LSP12 (Canada); or equivalent	

#### **REMOVAL AND INSTALLATION**

1. Remove the camshaft roller followers. For additional information, refer to Camshaft Roller Follower.

# NOTE: Mark the positions of the hydraulic lash adjusters to make sure they are assembled in their original positions.

2. Remove the hydraulic lash adjusters.

# NOTE: Inspect the hydraulic lash adjusters for scoring marks and uneven wear in the bore. Install new lash adjusters if necessary.

- 3. To install, reverse the removal procedure.
  - Lubricate the hydraulic lash adjusters with clean engine oil.

### VALVE SPRING, RETAINER, AND SEAL

#### **Special Tools**

Illustration	Tool Name		Tool Number	
-				-
sábado, 31 de agosto de 2019 08:14:	45 a. m.	Page 67 © 20	11 Mitchell Repair Information Company	, LLC.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

ST1975-A	Compressor, Valve Spring	303-473 (T94P-6565-BH)
ST1977-A	Installer, Valve Stem Oil Seal	303-470 (T94P-6510-CH)

### Material

Item	Specification
Motorcraft SAE 5W-20 Premium Synthetic Blend	
Motor Oil	
XO-5W20-QSP (US); Motorcraft SAE 5W-20	WSS-M2C930-A
Super Premium Motor Oil CXO-5W20-LSP12	
(Canada); or equivalent	

#### REMOVAL

- 1. Remove the camshaft roller followers. For additional information, refer to **Camshaft Roller Follower**.
  - NOTE: If air pressure has forced the piston to the bottom of the cylinder, any loss of air pressure will allow the valve(s) to fall into the cylinder. A rubber band, tape or string wrapped around the end of the valve stem will prevent this from happening.
- 2. Pressurize the cylinder using compressed air.
- 3. Using the special tool, remove the key, retainer and the valve spring.



**Fig. 80: Identifying Special Tool (303-473)** Courtesy of FORD MOTOR CO.

# NOTE: Camshaft removed for clarity.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

4. Remove the valve seal.



**Fig. 81: Removing Valve Stem Seal** Courtesy of FORD MOTOR CO.

### INSTALLATION

# NOTE: Lubricate the valve guide with clean engine oil.

1. Using the special tool, install the valve seal.



### **<u>Fig. 82: Installing Valve Seal</u>** Courtesy of FORD MOTOR CO.

2. Using the special tool, install the valve spring, retainer and key.



Fig. 83: Identifying Special Tool (303-473)

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

# **Courtesy of FORD MOTOR CO.**

3. Install the camshaft roller followers. For additional information, refer to **Camshaft Roller Follower**.

# **CYLINDER HEAD - RH**

#### Material

Item	Specification
Motorcraft Metal Surface Prep ZC-31	-
Motorcraft SAE 5W-20 Premium Synthetic Blend Motor Oil XO-5W20-QSP (US); Motorcraft SAE 5W-20 Super Premium Motor Oil CXO-5W20-LSP12 (Canada); or equivalent	WSS-M2C930-A

# CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, can cause engine failure.

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to **JACKING AND LIFTING** article.
- 2. Remove the lower intake manifold. For additional information, refer to Lower Intake Manifold.
- 3. Remove the coolant bypass tube. For additional information, refer to **ENGINE COOLING** article.
- 4. Remove the RH camshafts. For additional information, refer to Camshafts RH.

# CAUTION: The camshaft roller followers must be installed in their original positions.

5. Remove the camshaft roller followers.

# CAUTION: The hydraulic lash adjusters must be installed in their original positions.

- 6. Remove the hydraulic lash adjusters.
- 7. Remove the 6 RH exhaust manifold nuts and position the manifold aside.

# NOTE: New cylinder head bolts must be installed. They are torque-to-yield designed and cannot be reused.

8. Remove the bolts in the sequence shown.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 84: Identifying Removing Sequence Of Cylinder Head Bolts** Courtesy of FORD MOTOR CO.

- 9. Remove the cylinder head and support the cylinder head on a bench with the head gasket side up.
  - Discard the gasket and the bolts.

# NOTE: The straightedge used must be flat within 0.0051 mm (0.0002 in) per foot of tool length.

10. Inspect all areas of the deck face with a straightedge and feeler gauge. The cylinder head must not have depressions deeper than 0.0254 mm (0.001 in) across a 38.1 mm (1.5 in) square area, or scratches more than 0.0254 mm (0.001 in).

### INSTALLATION

### CAUTION: Do not use metal scrapers, wire brushes, power abrasive discs or other abrasive means to clean the sealing surfaces. These tools cause scratches and gauges which make leak paths.

- 1. Use a plastic scraping tool to remove all traces of the head gasket.
  - Clean all surfaces with metal surface prep.
- 2. Clean the cylinder head bolt holes in the cylinder block. Make sure all coolant, oil or other foreign material is removed.
- 3. Position a new gasket and the cylinder head.

# NOTE: New cylinder head bolts must be installed. They are torque-to-yield designed and cannot be reused.

- 4. Install the bolts and tighten in 6 stages in the sequence shown.
  - Stage 1: Tighten to 40 Nm (30 lb-ft).
  - Stage 2: Tighten bolts 90 degrees.
  - Stage 3: Loosen one full turn.
  - Stage 4: Tighten to 40 Nm (30 lb-ft).
  - Stage 5: Tighten 90 degrees.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

• Stage 6: Tighten 90 degrees.



**Fig. 85: Identifying Tightening Sequence Of Cylinder Head Bolts** Courtesy of FORD MOTOR CO.

# CAUTION: The hydraulic lash adjusters must be installed in their original positions.

- 5. Install the hydraulic lash adjusters.
  - Lubricate the hydraulic lash adjusters with clean engine oil.

# CAUTION: The camshaft roller followers must be installed in their original positions.

- 6. Install the camshaft roller followers.
  - Lubricate the camshaft roller followers with clean engine oil.
- 7. Position the RH exhaust manifold and install the nuts.
  - Tighten in the sequence shown to 20 Nm (15 lb-ft).



# **Fig. 86: Identifying Tightening Sequence Of RH Exhaust Manifold Nuts** Courtesy of FORD MOTOR CO.

- 8. Install the RH camshafts. For additional information, refer to Valve Cover RH.
- 9. Install the coolant bypass tube. For additional information, refer to **ENGINE COOLING** article.
#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

10. Install the lower intake manifold. For additional information, refer to Lower Intake Manifold.

## **CYLINDER HEAD - LH**

#### Material

Item	Specification
Motorcraft Metal Surface Prep	
ZC-31	-
Motorcraft SAE 5W-20 Premium Synthetic Blend	
Motor Oil	
XO-5W20-QSP (US); Motorcraft SAE 5W-20	WSS-M2C930-A
Super Premium Motor Oil CXO-5W20-LSP12	
(Canada); or equivalent	

#### REMOVAL

# CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, can cause engine failure.

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to **JACKING** AND LIFTING article.
- 2. Remove the lower intake manifold. For additional information, refer to Lower Intake Manifold.
- 3. Remove the coolant bypass tube. For additional information, refer to **ENGINE COOLING** article.
- 4. Remove the LH camshafts. For additional information, refer to <u>Valve Train Components Exploded</u> <u>View</u> and <u>Camshafts - LH</u>.
- 5. Remove the LH exhaust manifold. For additional information refer to **<u>EXHAUST SYSTEM</u>** article.
- 6. Remove the oil level indicator and tube. For additional information, refer to <u>Oil Level Indicator and</u> <u>Tube</u>.
- 7. Remove the 3 bolts and position the coolant pump aside.



**Fig. 87: Locating Coolant Pump And Bolts** Courtesy of FORD MOTOR CO.

# CAUTION: The camshaft roller followers must be installed in their original positions.

8. Remove the camshaft roller followers.

CAUTION: The hydraulic lash adjusters must be installed in their original positions.

9. Remove the hydraulic lash adjusters.

# NOTE: New cylinder head bolts must be installed. They are torque-to-yield designed and cannot be reused.

10. Remove the bolts in the sequence shown.



N0001536

#### **Fig. 88: Identifying Loosening Sequence Of Cylinder Head Bolts** Courtesy of FORD MOTOR CO.

- 11. Remove the cylinder head and support the cylinder head on a bench with the head gasket side up.
  - Discard the gasket and the bolts.

# NOTE: The straightedge used must be flat within 0.0051 mm (0.0002 in) per foot of tool length.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

12. Inspect all areas of the deck face with a straightedge and feeler gauge. The cylinder head must not have depressions deeper than 0.0254 mm (0.001 in) across a 38.1 mm (1.5 in) square area, or scratches more than 0.0254 mm (0.001 in).

#### INSTALLATION

#### CAUTION: Do not use metal scrapers, wire brushes, power abrasive discs or other abrasive means to clean the sealing surfaces. These tools cause scratches and gouges which make leak paths.

- 1. Use a plastic scraping tool to remove all traces of the head gasket.
  - Clean all surfaces with metal surface prep.
- 2. Clean the cylinder head bolt holes in the cylinder block. Make sure all coolant, oil or other foreign material is removed.
- 3. Position a new gasket and the cylinder head.

# NOTE: New cylinder head bolts must be installed. They are torque-to-yield designed and cannot be reused.

- 4. Install the bolts and tighten in 6 stages in the sequence shown.
  - Stage 1: Tighten to 40 Nm (30 lb-ft).
  - Stage 2: Tighten bolts 90 degrees.
  - Stage 3: Loosen one full turn.
  - Stage 4: Tighten to 40 Nm (30 lb-ft).
  - Stage 5: Tighten 90 degrees.
  - Stage 6: Tighten 90 degrees.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0001535

## **Fig. 89: Identifying Tightening Sequence Of Cylinder Head Bolts** Courtesy of FORD MOTOR CO.

# CAUTION: The hydraulic lash adjusters must be installed in their original positions.

- 5. Install the hydraulic lash adjusters.
  - Lubricate the hydraulic lash adjusters with clean engine oil.

# CAUTION: The camshaft roller followers must be installed in their original positions.

- 6. Install the camshaft roller followers.
  - Lubricate the camshaft roller followers with clean engine oil.
- 7. Position the coolant pump and install the bolts.
  - Tighten to 10 Nm (89 lb-in).
- 8. Install the oil level indicator and tube. For additional information refer to **Oil Level Indicator and Tube**.
- 9. Install the LH exhaust manifold. For additional information refer to **EXHAUST SYSTEM** article.
- 10. Install the camshafts. For additional information, refer to <u>Valve Train Components Exploded View</u> and <u>Camshafts LH</u>.
- 11. Install the coolant bypass tube. For additional information, refer to **ENGINE COOLING** article.
- 12. Install the lower intake manifold. For additional information, refer to Lower Intake Manifold.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

# **ENGINE LUBRICATION COMPONENTS - EXPLODED VIEW**



N0031783

# <u>Fig. 90: Exploded View Of Oil Pan, Oil Pump Screen and Pickup Tube and Oil Pan Baffle (With Torque Specifications)</u> Courtesy of FORD MOTOR CO.

Item	Part Number	Description
1	W701605	Oil pan-to-engine bolt (10 required)
2	W701606	Oil pan-to-engine stud bolt (5 required)
3	W500120	Oil pan-to-transaxle bolt (2 required)
4	6675	Oil pan
5	6710	Oil pan gasket
6	W701582	Oil pump screen and pickup tube nut
7	W700005	Oil pump screen and pickup tube bolts (2 required)

	sábado, 31 de agosto de 2019 08:14:46 a.m.	Page 77	© 2011 Mitchell Repair Information Company, LLC.
I		ragori	e zerr miterien riepan methatien eenparij, zze.

## 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

8	6622	Oil pump screen and pickup tube
9	6625	Oil pump screen and pickup tube O-ring seal
10	W701542	Oil pan baffle nut (7 required)
11	6687	Oil pan baffle



N0000295

# **Fig. 91: Exploded View Of Oil Pump** Courtesy of FORD MOTOR CO.

Item	Part Number	Description
1	W500300	Oil pump bolt (4 required)
2	6621	Oil pump

1. For additional information, refer to the following procedures.

# OIL PAN

#### Material

Item		Specification
Motorcraft Metal Surface Prep ZC-31	-	
Motorcraft SAE 5W-20 Premium Synthetic Blend Motor Oil XO-5W20-QSP (US); Motorcraft SAE 5W-20 Super Premium Motor Oil CXO-5W20-LSP12	WSS-M	2C930-A
sábado, 31 de agosto de 2019 08:14:46 a.m.	Page 78	© 2011 Mitchell Repair Information Company, LL

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

(Canada); or equivalent	
Silicone Gasket and Sealant TA-30	WSE-M4G323-A4

#### REMOVAL

# CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, can cause engine failure.

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to <u>JACKING</u> <u>AND LIFTING</u> article.
- 2. Remove the exhaust flexible pipe. For additional information, refer to **EXHAUST SYSTEM** article.
- 3. Drain the engine oil and install the drain plug.
  - Tighten to 26 Nm (19 lb-ft).
- 4. Remove and discard the oil filter.
- 5. Remove the 2 oil pan-to-transaxle bolts.

# **NOTE:** For reference during installation, mark the location of the stud bolts.

- 6. Remove the 10 bolts, 5 stud bolts and the oil pan.
  - Remove and discard the oil pan gasket.

#### INSTALLATION

#### CAUTION: Do not use metal scrapers, wire brushes, power abrasive discs or other abrasive means to clean the sealing surfaces. These tools cause scratches and gouges which make leak paths.

- 1. Use a plastic scraping tool to remove all traces of the oil pan gasket.
  - Clean all sealing surfaces with metal surface prep and install a new oil pan gasket.

# NOTE: The oil pan must be installed and the bolts tightened within 4 minutes of sealant application.

2. Apply a 10 mm (0.39 in) diameter dot of silicone sealant to the areas indicated.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 92: Identifying Area For Applying Sealant Courtesy of FORD MOTOR CO.**

- 3. Position the oil pan and loosely install the bolts and stud bolts.
- 4. Install the oil pan-to-transaxle bolts.
  - Tighten to 40 Nm (30 lb-ft).
- 5. Tighten the oil pan-to-engine bolts and stud bolts in the sequence shown to 25 Nm (18 lb-ft).



#### **Fig. 93: Identifying Tightening Sequence Of Oil Pan-To-Engine Bolts And Stud Bolts** Courtesy of FORD MOTOR CO.

- 6. Install a new oil filter.
  - Tighten to 16 Nm (12 lb-ft).
- 7. Install the exhaust flexible pipe. For additional information, refer to **EXHAUST SYSTEM** article.
- 8. Fill the engine with clean engine oil.

#### OIL PUMP SCREEN AND PICKUP TUBE

#### Material

Item	Specification
Motorcraft SAE 5W-20 Premium Synthetic Blend	
Motor Oil	
XO-5W20-QSP (US); Motorcraft SAE 5W-20	WSS-M2C930-A
Super Premium Motor Oil CXO-5W20-LSP12	
(Canada); or equivalent	

sábado, 31 de agosto de 2019 08:14:46 a.m.	Page 80	© 2011 Mitchell Repair Information Company, LLC
--	---------	---

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

#### REMOVAL

# CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, may cause engine failure.

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to **JACKING AND LIFTING** article.
- 2. Remove the oil pan. For additional information, refer to **Engine Lubrication Components Exploded <u>View</u> and <u><b>Oil Pan**</u>.
- 3. Remove the bolts, nut and the oil pump screen and pickup tube.
  - Remove and discard the O-ring seal.



#### **Fig. 94: Locating Oil Pump Screen & Pickup Tube Bolts** Courtesy of FORD MOTOR CO.

#### INSTALLATION

- 1. Install a new O-ring seal on the oil pump screen and pickup tube.
  - Lubricate the O-ring seal with clean engine oil.
- 2. Install the oil pump screen and pickup tube.
  - 1. Position the oil pump screen and pickup tube.
  - 2. Install the bolts and tighten to 10 Nm (89 lb-in).
  - 3. Install the nut and tighten in 2 stages.
    - Stage 1: Tighten to 5 Nm (44 lb-in).
    - Stage 2: Tighten 45 degrees.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 95: Identifying Oil Pump Screen, Pickup Tube & Bolts** Courtesy of FORD MOTOR CO.

3. Install the oil pan. For additional information, refer to **Oil Pan**.

# OIL PAN BAFFLE

#### **REMOVAL AND INSTALLATION**

# CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, may cause engine failure.

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to <u>JACKING</u> <u>AND LIFTING</u> article.
- 2. Remove the oil pump screen and pickup tube. For additional information, refer to **Engine Lubrication** <u>Components - Exploded View</u> and <u>Oil Pump Screen and Pickup Tube</u>.
- 3. Remove the 7 nuts and the oil pan baffle.
  - To install tighten the oil pan baffle nuts in 2 stages.
    - Stage 1: Tighten to 5 Nm (44 lb-in).
    - Stage 2: Tighten an additional 45 degrees.
- 4. To install, reverse the removal procedure.

#### OIL PUMP

#### REMOVAL

# CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, may cause engine failure.

1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to <u>JACKING</u> <u>AND LIFTING</u> article.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 2. Remove the timing drive components. For additional information, refer to **<u>Timing Drive Components</u>**.
- 3. Remove the oil pump screen and pickup tube. For additional information, refer to <u>Engine Lubrication</u> <u>Components - Exploded View</u> and <u>Oil Pump Screen and Pickup Tube</u>.
- 4. Remove the bolts in the sequence shown.



### **Fig. 96: Identifying Removing Sequence Of Oil Pump Bolts** Courtesy of FORD MOTOR CO.

#### INSTALLATION

- 1. Position the oil pump and install the bolts.
  - Tighten in the sequence shown to 10 Nm (89 lb-in).



#### **Fig. 97: Identifying Tightening Sequence Of Oil Pump Bolts** Courtesy of FORD MOTOR CO.

- 2. Install the oil pump screen and pickup tube. For additional information, refer to <u>Engine Lubrication</u> <u>Components - Exploded View</u> and <u>Oil Pump Screen and Pickup Tube</u>.
- 3. Install the timing drive components. For additional information, refer to **<u>Timing Drive Components</u>**.

# OIL LEVEL INDICATOR AND TUBE

#### Material

Item		Specification
Motorcraft SAE 5W-20 Premium Synthetic Blend Motor Oil		
sábado, 31 de agosto de 2019 08:14:46 a.m.	Page 83	© 2011 Mitchell Repair Information Company, Ll

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

XO-5W20-QSP (US); Motorcraft SAE 5W-20 Super Premium Motor Oil CXO-5W20-LSP12 (Canada); or equivalent

WSS-M2C930-A



#### Fig. 98: Exploded View Of Oil Level Indicator & Tube (With Torque Specifications) Courtesy of FORD MOTOR CO.

Item	Part Number	Description
1	6750	Oil level indicator
2	W701822	Oil level indicator tube bolt
3	6754	Oil level indicator tube
4	110282	Oil level indicator O-ring seal

#### **REMOVAL AND INSTALLATION**

- 1. Detach the upper radiator hose pin-type retainer from the radiator core support and position the hose aside.
- 2. Remove the 4 upper radiator support bracket bolts and the 2 brackets.
  - To install, tighten to 10 N.m (89 lb-in).
- 3. Remove the oil level indicator.
- 4. Remove the stud bolt and then remove the oil level indicator tube by guiding it between the radiator core support and the cooling fan.
  - Remove and discard the O-ring seal.
  - To install, tighten to 10 Nm (89 lb-in).

Page 84 © 2011 Mitchell Repair Information Company, LLC.

## NOTE: Install a new O-ring seal and lubricate with clean engine oil.

# NOTE: Installation of the oil level indicator may require the assistance of a second technician to align the tube with the orifice.

5. To install, reverse the removal procedure.

## **ENGINE SUPPORT INSULATORS**

#### **Special Tools**

Illustration	Tool Name	Tool Number
ST2425-A	3-Bar Engine Support Kit	303-F072
<b>ST1595-A</b>	Lifting Brackets, Engine	303-050 (T70P-6000)
ST2743A	Universal Adapter Brackets	014-0001

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



Fig. 99: Exploded View Of Engine Support Insulators (With Torque Specifications) **Courtesy of FORD MOTOR CO.** 

Item	Part Number	Description	
1	N621942	Power steering pressure (PSP) tube bracket nut	
2	-	PSP tube bracket (part of 3A719)	
3	N621942	Engine support insulator bracket nuts (3 required)	
4	W709667	Engine support insulator bracket bolt	
5	-	Engine support insulator bracket	
6	W500233	Engine support insulator bolts (3 required)	
7	6068	Engine support insulator	

#### **REMOVAL AND INSTALLATION**

- 1. Remove the lower intake manifold. For additional information, refer to Lower Intake Manifold.
- 2. Remove the engine support insulator bracket bolt.
  - To install, tighten to 90 Nm (66 lb-ft).
- 3. Install the special tools.
  - 1. Position the 2 universal adapter brackets on top of the cylinder block.
  - 2. Install 2 M8 x 1.25 x 36 mm (1.41 in) bolts and tighten to 10 Nm (89 lb-in).
  - 3. Position the universal lifting bracket onto the 2 universal adapter brackets.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



4. Fasten the universal lifting bracket to the 2 universal adapter brackets with a suitable nut and bolt.

**Fig. 100: Identifying Special Tools (303-050 And 014-0001)** Courtesy of FORD MOTOR CO.

4. Using the special tools, lift the engine 12 mm (0.47 in).

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0035706

#### **Fig. 101: Lifting Engine 12 mm (0.47 in) Courtesy of FORD MOTOR CO.**

- 5. Remove the nut and position the PSP tube bracket aside.
  - To install, tighten to 25 Nm (18 lb-ft).
- 6. Remove the 3 nuts and the engine support insulator bracket.
  - To install, tighten to 55 Nm (41 lb-ft).
- 7. Remove the 3 bolts and the engine support insulator.
  - To install, tighten to 48 Nm (35 lb-ft).
- 8. To install, reverse the removal procedure.

# REMOVAL

#### ENGINE

#### **Special Tools**

Illustration	Tool Name	Tool Number
(	Lifting Brackets, Engine	303-050 (T70P-6000)

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### REMOVAL

# NOTE: For additional information, refer to the exploded views under the engine assembly procedure.

#### All vehicles

- 1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to <u>JACKING</u> <u>AND LIFTING</u> article.
- 2. Release the fuel system pressure. For additional information, refer to <u>FUEL SYSTEM GENERAL</u> <u>INFORMATION</u> article.
- 3. Remove the battery tray. For additional information, refer to **<u>BATTERY, MOUNTING AND CABLES</u>** article.
- 4. Remove the air cleaner outlet pipe and air cleaner. For additional information, refer to **INTAKE AIR DISTRIBUTION AND FILTERING 3.0L (4V)** article.
- 5. Disconnect the power steering pressure (PSP) switch electrical connector.
  - Remove the nut and detach the ground wire and PSP hose bracket.



2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

#### Fig. 102: Locating Power Steering Pressure (PSP) Switch Electrical Connector Courtesy of FORD MOTOR CO.

6. Remove the lower radiator air deflectors.



A0019937

## Fig. 103: Splash Shields Courtesy of FORD MOTOR CO.

- 7. Remove the exhaust system flexpipe. For additional information, refer to **<u>EXHAUST SYSTEM</u>** article.
- 8. Remove the generator. For additional information, refer to <u>GENERATOR AND REGULATOR</u> article.
- 9. Remove the accessory drive belt from the remaining pulleys and the engine.
- 10. Remove the LH halfshaft. For additional information, refer to **FRONT DRIVE HALFSHAFTS** article.
- 11. Drain the engine coolant. For additional information, refer to **ENGINE COOLING** article.
- 12. Drain the engine oil and install the drain plug.
  - Tighten to 26 Nm (19 lb-ft).

# All wheel drive (AWD) vehicles

# CAUTION: Do not reuse the CV joint bolts and washers. Install new bolts and washers or damage to the vehicle may occur.

13. Remove and discard the 6 front driveshaft-to-power take off bolts and washers.



A0090352

**Fig. 104: Locating Driveshaft-To-Power Take Off Bolts & Washers** Courtesy of FORD MOTOR CO.

# CAUTION: Do not reuse the bolts and straps for the center U-joint. Install new bolts and straps or damage to the vehicle may occur.

#### NOTE: There is a difference in the length of the head of the replacement yoke strap bolts from the production bolts. The longer head pinion bolts can be used in either location.

- 14. Remove the front driveshaft.
  - 1. Index-mark the front driveshaft to the center bearing.
  - 2. Remove and discard the bolts and straps.



Fig. 105: Locating Straps & Bolts Courtesy of FORD MOTOR CO.

# All vehicles

15. Disconnect the A/C clutch electrical connector.



#### Fig. 106: Locating A/C Clutch Field Coil Electrical Connector Courtesy of FORD MOTOR CO.

16. Remove the bolts and position the A/C compressor aside.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### Fig. 107: Locating A/C Compressor & Bolts Courtesy of FORD MOTOR CO.

17. Remove the nut and the power steering pump pulley.



**Fig. 108: Locating Power Steering Pump Pulley & Nut** Courtesy of FORD MOTOR CO.

# NOTE: The bolt positioned behind the power steering pressure (PSP) tube will remain in the pump housing.

18. Remove the power steering pump bolts and position the pump aside.



Fig. 109: Locating Power Steering Pump Bolts Courtesy of FORD MOTOR CO.

19. Remove the 4 bolts and the lateral support crossmember.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### A0087403

## <u>Fig. 110: Identifying Lateral Support Crossmember And Bolts</u> Courtesy of FORD MOTOR CO.

20. Remove the front roll restrictor bolt and the 2 bolts for the engine support crossmember.



# <u>Fig. 111: Identifying Front Roll Restrictor Bolt & Bolts For Engine Support Crossmember</u> Courtesy of FORD MOTOR CO.

- 21. Remove the rear nut and the engine support crossmember.
  - Discard the nut.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 112: Identifying Cross Brace And Rear Nut** Courtesy of FORD MOTOR CO.

22. Disconnect the 2 transmission cooler tubes.



#### **Fig. 113: Locating Transmission Cooler Tubes Courtesy of FORD MOTOR CO.**

23. Disconnect the exhaust gas recirculation (EGR) tube fitting from the converter.



#### **Fig. 114: Locating EGR Tube-To-RH Catalytic Converter Fitting** Courtesy of FORD MOTOR CO.

24. Remove the bolts and the accelerator cable snow shield.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 115: Locating Accelerator Cable Snow Shield Bolts** Courtesy of FORD MOTOR CO.

25. Disconnect the accelerator cable and the speed control actuator cable and remove the cable bracket bolts.



#### **Fig. 116:** Accelerator Cable, Speed Control Actuator Cable & Cable Bracket Bolts Courtesy of FORD MOTOR CO.

26. Remove the bolt and position the cables and brackets aside.



**<u>Fig. 117: Cable Bracket</u>** Courtesy of FORD MOTOR CO.

27. Disconnect the hoses.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## **<u>Fig. 118: Locating Hoses</u>** Courtesy of FORD MOTOR CO.

28. Disconnect the heater hoses and the throttle body coolant hose.



## **Fig. 119: Locating Heater Hoses & Throttle Body Coolant Hose** Courtesy of FORD MOTOR CO.

- 29. Disconnect the fuel supply tube quick connect coupling. For additional information, refer to <u>FUEL</u> <u>SYSTEM - GENERAL INFORMATION</u> article.
- 30. Detach the wiring harness pin-type retainer from the gearshift cable bracket.



**Fig. 120: Locating Pin-Type Retainer Courtesy of FORD MOTOR CO.** 

31. Disconnect the gearshift cable from the transaxle.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 121: Locating Shift Cable End At Manual Lever** Courtesy of FORD MOTOR CO.

32. Remove the bolts and position the gearshift cable and bracket aside.



#### **Fig. 122: Locating Gearshift Cable Bracket Bolts** Courtesy of FORD MOTOR CO.

33. Disconnect the differential pressure feedback EGR sensor electrical connector and detach the pin-type retainer.



#### **Fig. 123: Locating EGR Sensor Electrical Connector Courtesy of FORD MOTOR CO.**

34. Disconnect the EGR tube fitting and remove the EGR tube and the differential pressure feedback EGR sensor as an assembly.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### Fig. 124: Locating Exhaust Gas Recirculation (EGR) Tube Courtesy of FORD MOTOR CO.

- 35. Disconnect the evaporative emissions canister purge valve vacuum tube from the intake manifold.
  - Detach the vacuum tube retainer from the transmission fill tube.



Fig. 125: Locating Vacuum Tube Retainer **Courtesy of FORD MOTOR CO.** 

36. Disconnect the brake booster vacuum tube and the vacuum reservoir tube.



A0089239

## Fig. 126: Locating Brake Booster Vacuum Tube & Vacuum Reservoir Tube **Courtesy of FORD MOTOR CO.**

37. Disconnect the manifold absolute pressure (MAP) sensor vacuum tube and electrical connector.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### Fig. 127: Locating Manifold Absolute Pressure (MAP) Sensor Vacuum Tube & Electrical Connector Courtesy of FORD MOTOR CO.

- 38. Disconnect the powertrain control module (PCM) electrical connectors and remove the nut.
  - Position the wiring aside.



**Fig. 128: Locating Powertrain Control Module (PCM) Electrical Connectors Courtesy of FORD MOTOR CO.** 

39. Remove the bolt and detach the ground wire.



**Fig. 129: Locating Ground Wire & Bolt** Courtesy of FORD MOTOR CO.

40. Remove the power distribution box cover.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 130: Locating Power Distribution Box Cover Courtesy of FORD MOTOR CO.**

41. Remove the nuts and disconnect the cables.



Fig. 131: Locating Cables & Nuts Courtesy of FORD MOTOR CO.

42. Disconnect the electrical connector from the power distribution box.



**Fig. 132: Power Distribution Box Electrical Connector Courtesy of FORD MOTOR CO.** 

43. Remove the bolts and disconnect the ground strap and the electrical connector.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 133: Locating Ground Strap & Electrical Connector Courtesy of FORD MOTOR CO.**

44. Detach the wiring harness retainers from the battery tray bracket and position the wiring harness aside.



**Fig. 134: Wiring Harness Retainers Courtesy of FORD MOTOR CO.** 

45. If equipped, disconnect the engine block heater electrical connector.



**Fig. 135: Locating Engine Block Heater Electrical Connector Courtesy of FORD MOTOR CO.** 

46. Detach the heated oxygen sensor (HO2S) wiring retainer from the radiator center support.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### Fig. 136: Locating Heated Oxygen Sensor (HO2S) Wiring Retainer Courtesy of FORD MOTOR CO.

47. Disconnect the output shaft speed (OSS) sensor electrical connector and remove the bolt and the OSS sensor.



## **Fig. 137: Locating Output Shaft Speed (OSS) Sensor Electrical Connector Courtesy of FORD MOTOR CO.**

48. Remove the torque converter inspection cover.



#### **Fig. 138: Locating Torque Converter Inspection Cover** Courtesy of FORD MOTOR CO.

49. Remove the 4 torque converter nuts.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 139: Locating Torque Converter Nuts Courtesy of FORD MOTOR CO.**

50. Remove the 2 oil pan-to-transaxle bolts.



**Fig. 140: Locating Oil Pan-To-Transaxle Bolts** Courtesy of FORD MOTOR CO.

# CAUTION: Do not allow the engine oil pan to rest on the powertrain lift.

51. Using the special tools, secure the engine and transaxle to the powertrain lift.



**Fig. 141: Securing Engine & Transaxle To Powertrain Lift Using Special Tool (014-0001)** Courtesy of FORD MOTOR CO.

#### NOTE: The next 5 steps must be carried out with the vehicle raised and the

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

# universal powertrain lift in position.

52. Remove the RH transaxle support insulator bolt.



#### **Fig. 142: Locating RH Transaxle Support Insulator Bolt Courtesy of FORD MOTOR CO.**

53. Remove the bolt, nuts and the RH transaxle support insulator.



## **Fig. 143: Locating Transaxle Support Insulator Bolt & Nuts** Courtesy of FORD MOTOR CO.

54. Remove the rear transaxle support bolt.



**Fig. 144: Locating Transaxle Mount Bolt Courtesy of FORD MOTOR CO.** 

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

55. Remove the front engine support bolts and nut.



**Fig. 145: Locating Front Engine Support Bolts & Nut** Courtesy of FORD MOTOR CO.

- 56. Remove the powertrain from the vehicle.
- 57. Disconnect the heated oxygen and catalyst monitor sensor electrical connectors and detach the pin-type retainers from the transaxle support bracket.



#### <u>Fig. 146: Locating Heated Oxygen & Catalyst Monitor Sensor Electrical Connectors</u> Courtesy of FORD MOTOR CO.

58. Disconnect the transmission range (TR) sensor electrical connector.



#### **Fig. 147: Locating Transmission Range (TR) Sensor Electrical Connector Courtesy of FORD MOTOR CO.**

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

59. Disconnect the transaxle wiring harness electronic control switch electrical connector.



### <u>Fig. 148: Locating Transaxle Wiring Harness Electronic Control Switch Electrical Connector</u> Courtesy of FORD MOTOR CO.

60. Detach the transaxle control harness from the brackets.



#### **Fig. 149: Locating Transaxle Control Harness Courtesy of FORD MOTOR CO.**

61. Disconnect the turbine speed sensor (TSS) electrical connector.



**Fig. 150: Locating Turbine Speed Sensor (TSS) Electrical Connector Courtesy of FORD MOTOR CO.** 

#### **AWD** vehicles

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 62. Remove the RH exhaust manifold nuts and the manifold.
  - Discard the nuts and gasket.



Country of FORD MOTOR CO.

63. Remove and discard the 6 RH exhaust manifold studs.



#### Fig. 152: Locating Exhaust Manifold Studs Courtesy of FORD MOTOR CO.

64. Remove the bolts and the halfshaft support bracket.



### **Fig. 153: Locating Half Shaft Support Bracket & Bolts** Courtesy of FORD MOTOR CO.

65. Remove the bolt, detach the pin-type retainer and position the power take off vent tube aside.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 154: Locating Pin-Type Retainer & Bolt** Courtesy of FORD MOTOR CO.

## All vehicles

66. Remove the 7 remaining transaxle-to-engine bolts.



**Fig. 155: Locating Transaxle-To-Engine Bolts Courtesy of FORD MOTOR CO.** 

#### NOTE: Once the engine is supported by the engine crane, remove the engine-tolift table support brackets.

67. Using the special tools, remove the engine from the universal powertrain lift.



<u>Fig. 156: Removing Engine From Universal Powertrain Lift</u> Courtesy of FORD MOTOR CO.
#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

#### DISASSEMBLY

#### ENGINE

#### **Special Tools**

Illustration	<b>Tool Name</b>	<b>Tool Number</b>
ST3044-A	Plate, Water Pump Pulley	303-456 (T94P-6312-AH1), part of 303-S455
ST3045-A	Protector, Water Pump Shaft	303-457 (T94P-6312-AH2), part of 303-S455
ST1382-A	Remover, Crankshaft Rear Oil Seal	303-519 (T95P-6701-EH)
ST1286-A	Remover, Crankshaft Vibration Damper	303-009 (T58P-6316-D)
ST1385-A	Remover, Oil Seal	303-409 (T92C-6700CH)
ST1187-A	Slide Hammer	307-005 (Т59L-100-В)
5T1438-A	Strap Wrench	303-D055 (D85L-6000-A)

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

# CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, can cause engine failure.

NOTE: For additional information, refer to the exploded view under the assembly procedure.

#### All vehicles

1. Remove the bolts and the flexplate.



**Fig. 157: Locating Flexplate & Bolts** Courtesy of FORD MOTOR CO.

2. Using the special tools, remove and discard the crankshaft rear oil seal.



#### Fig. 158: Identifying Special Tools (307-005 And 303-519) Courtesy of FORD MOTOR CO.

- 3. Mount the engine on a suitable stand.
- 4. Detach the engine control sensor wiring connectors from the upper intake manifold.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 159: Locating Engine Control Sensor Wiring Connectors Courtesy of FORD MOTOR CO.**

5. Detach the wiring retainer, remove the nut and the heated oxygen sensor (HO2S) electrical connector bracket.



#### **Fig. 160: Locating Heated Oxygen Sensor (HO2S) Electrical Connector Bracket** Courtesy of FORD MOTOR CO.

6. Disconnect the exhaust gas recirculation (EGR) vacuum regulator electrical connector and remove the nut. Detach the wiring harness retainer.



#### <u>Fig. 161: Locating Exhaust Gas Recirculation (EGR) Vacuum Regulator Electrical Connector</u> Courtesy of FORD MOTOR CO.

7. Disconnect the knock sensor (KS) electrical connector.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 162: Locating Knock Sensor (KS) Electrical Connector Courtesy of FORD MOTOR CO.**

8. Remove the nuts and the engine control wire harness.



Fig. 163: Locating Engine Control Wiring Harness & Nuts Courtesy of FORD MOTOR CO.

9. Disconnect the idle air control (IAC) valve and the throttle position (TP) sensor electrical connectors, and detach the wiring retainer.



#### **Fig. 164: Idle Air Control Valve & Throttle Position Sensor Electrical Connectors Courtesy of FORD MOTOR CO.**

10. Remove the positive crankcase ventilation (PCV) tube.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 165: Locating Positive Crankcase Ventilation (PCV) Tube** Courtesy of FORD MOTOR CO.

11. Disconnect the vacuum tube fittings from the EGR valve, EGR vacuum regulator and the intake manifold.



#### <u>Fig. 166: Vacuum Tube Fittings At EGR Valve, EGR Vacuum Regulator & Intake Manifold</u> Courtesy of FORD MOTOR CO.

12. Disconnect the throttle body coolant hose.



#### **Fig. 167: Locating Throttle Body Coolant Hose Courtesy of FORD MOTOR CO.**

- 13. Remove the bolts and upper intake manifold.
  - Discard the gaskets.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 168: Locating Upper Intake Manifold Bolts Courtesy of FORD MOTOR CO.**

14. Disconnect the engine coolant temperature (ECT) sensor electrical connector.



#### **Fig. 169: Locating Engine Coolant Temperature (ECT) Sensor Electrical Connector** Courtesy of FORD MOTOR CO.

15. Disconnect the RH coil-on-plug electrical connectors and detach the wiring retainer.



#### **Fig. 170: Coil-On-Plug Electrical Connectors & Wiring Retainers** Courtesy of FORD MOTOR CO.

16. Disconnect the radio interference capacitor electrical connector and detach the wiring retainers.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 171: Locating Radio Interference Capacitor Electrical Connector** Courtesy of FORD MOTOR CO.

17. Disconnect the LH coil-on-plug electrical connectors and detach the 2 wiring retainers.



#### <u>Fig. 172: Coil-On-Plug Electrical Connectors & Wiring Retainers</u> Courtesy of FORD MOTOR CO.

18. Disconnect the camshaft position sensor (CMP) and oil pressure sensor electrical connectors and detach the wiring retainers.



#### Fig. 173: Locating Camshaft Position Sensor (CMP) & Oil Pressure Sensor Electrical Connectors & Wiring Retainers Courtesy of FORD MOTOR CO.

19. Disconnect the crankshaft position (CKP) sensor electrical connector and detach the wiring retainers.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 174: Locating Crankshaft Position (CKP) Sensor Electrical Connector Courtesy of FORD MOTOR CO.**

- 20. Disconnect the fuel rail pressure and temperature sensor electrical connector and vacuum tube.
  - Remove the engine vacuum harness.



#### **Fig. 175: Locating Fuel Rail Pressure & Temperature Sensor Electrical Connector Courtesy of FORD MOTOR CO.**

21. Disconnect the fuel injector electrical connectors and remove the fuel charging wiring harness.



#### **Fig. 176: Locating Fuel Injector Electrical Connectors Courtesy of FORD MOTOR CO.**

- 22. Remove the bolts and the lower intake manifold.
  - Discard the gaskets.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



**Fig. 177: Locating Lower Intake Manifold Bolts Courtesy of FORD MOTOR CO.** 

CAUTION: When removing the coil-on-plugs, a slight twisting motion will break the seal and ease removal.

#### NOTE: LH shown, RH similar.

23. Remove the bolts and the 6 coil-on-plugs.



Fig. 178: Coil-On-Plug Bolts Courtesy of FORD MOTOR CO.

24. Remove the nut and the radio interference capacitor.



**Fig. 179: Locating Radio Interference Capacitor Nut** Courtesy of FORD MOTOR CO.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 25. Remove the bolts and the RH valve cover.
  - Discard the gasket.



#### **Fig. 180: Locating RH Valve Cover Bolts** Courtesy of FORD MOTOR CO.

26. Remove the bolt and the engine lift bracket.



#### **Fig. 181: Locating Lift Bracket & Bolt** Courtesy of FORD MOTOR CO.

- 27. Remove the bolts and the LH valve cover.
  - Discard the gasket.



**Fig. 182: Locating LH Valve Cover Bolts** Courtesy of FORD MOTOR CO.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

#### Front wheel drive (FWD) vehicles

- 28. Remove the nuts, the RH exhaust manifold and the gasket.
  - Discard the gasket and nuts.



Fig. 183: Locating Gasket & Nuts Courtesy of FORD MOTOR CO.

29. Remove and discard the 6 RH exhaust manifold studs.



#### **Fig. 184: Locating Exhaust Manifold Studs Courtesy of FORD MOTOR CO.**

30. Remove the bolts and the halfshaft support bracket.



Fig. 185: Locating Halfshaft Support Bracket & Bolts Courtesy of FORD MOTOR CO.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

#### All vehicles

- 31. Remove the nuts, the LH exhaust manifold and the gasket.
  - Discard the gasket and nuts.



#### **Fig. 186: Locating LH Exhaust Manifold & Gasket** Courtesy of FORD MOTOR CO.

32. Remove and discard the 6 LH exhaust manifold studs.



**Fig. 187: Locating Exhaust Manifold Studs Courtesy of FORD MOTOR CO.** 

33. Remove and discard the oil filter.



A0018485

#### **<u>Fig. 188: Locating Oil Filter</u>** Courtesy of FORD MOTOR CO.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

34. Cut and remove the coolant pump belt.



**Fig. 189: Cutting Coolant Pump Belt** Courtesy of FORD MOTOR CO.

35. Disconnect the hoses.



**<u>Fig. 190: Locating Hoses</u>** Courtesy of FORD MOTOR CO.

36. Remove the 3 bolts and the coolant pump.



**Fig. 191: Locating Coolant Pump & Bolts Courtesy of FORD MOTOR CO.** 

37. Disconnect the hoses and remove the coolant tube.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 192: Locating Coolant Tube** Courtesy of FORD MOTOR CO.

38. Remove the nut, bolt and the coolant bypass tube.



#### **Fig. 193: Locating Coolant Bypass Tube Bolt & Nut** Courtesy of FORD MOTOR CO.

- 39. Remove the stud bolt and the oil level indicator and tube.
  - Remove and discard the O-ring seal.



#### **Fig. 194: Positioning Oil Level Indicator Tube Courtesy of FORD MOTOR CO.**

- 40. Remove the bolts, studs and the oil pan.
  - Discard the gasket.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### Fig. 195: Locating Oil Pan Gasket Bolts & Stud Bolts Courtesy of FORD MOTOR CO.

41. Remove the bolts, nut and the oil pump screen and pickup tube.



#### **Fig. 196: Locating Oil Pump Screen & Pickup Tube Bolts** Courtesy of FORD MOTOR CO.

42. Remove and discard the O-ring seal.



A0011413

**Fig. 197: Locating O-Ring Seal** Courtesy of FORD MOTOR CO.

43. Remove the nuts and the oil pan baffle.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 198: Locating Oil Pan Baffle Nuts** Courtesy of FORD MOTOR CO.

44. Remove the oil pressure sender and, if equipped, the block heater.



**Fig. 199: Locating Oil Pressure Sender** Courtesy of FORD MOTOR CO.

45. Remove the bolt and the KS.



Fig. 200: Locating Knock Sensor (KS) & Bolt Courtesy of FORD MOTOR CO.

46. Use the special tool to hold the crankshaft damper and remove the bolt.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### <u>Fig. 201: Locating Special Tool (303-D055) And Crankshaft Pulley Bolt</u> Courtesy of FORD MOTOR CO.

47. Using the special tool, remove the crankshaft damper.



<u>Fig. 202: Removing Crankshaft Pulley Using Special Tool (303-009)</u> Courtesy of FORD MOTOR CO.

48. Remove and discard the crankshaft front seal from the front cover.



**Fig. 203: Removing Crankshaft Front Seal Using Special Tool (303-409)** Courtesy of FORD MOTOR CO.

49. Remove the bolt and the idler pulley.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 204: Locating Idler Pulley & Bolt Courtesy of FORD MOTOR CO.**

50. Remove the bolt and the belt tensioner.



**Fig. 205: Locating Belt Tensioner & Bolt** Courtesy of FORD MOTOR CO.

> CAUTION: Do not use metal scrapers, wire brushes, power abrasive discs or other abrasive means to clean the sealing surface. These tools cause scratches and gouges, which make leak paths. Use a plastic scraping tool to remove all traces of sealant.

- 51. Remove the bolts, studs and the front cover.
  - Discard the gaskets.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



A0090759

**Fig. 206: Locating Engine Front Cover Bolts Courtesy of FORD MOTOR CO.** 

CAUTION: This pulse wheel is used in several different engines. Install the pulse wheel with the keyway in the slot stamped "30" or "30RFF" (orange in color).

52. Remove the ignition pulse wheel.



#### **Fig. 207: Identifying Ignition Pulse Wheel Courtesy of FORD MOTOR CO.**

53. Install the damper bolt.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



A0011064

**Fig. 208: Identifying Damper Bolt** Courtesy of FORD MOTOR CO.

CAUTION: Only use hand tools when removing or installing the spark plugs, damage can occur to the cylinder head or spark plug.

#### NOTE: LH shown, RH similar.

54. Remove the LH and RH spark plugs.



<u>Fig. 209: Spark Plugs</u> Courtesy of FORD MOTOR CO.

- 55. Rotate the crankshaft clockwise to position the crankshaft keyway in the 11 o'clock position and position the camshafts in the correct position. This will position the number one cylinder at top dead center (TDC).
  - Verify that the camshafts are correctly located. If not, rotate the crankshaft one additional turn and recheck.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 210: Identifying Crankshaft Keyway In 11 O'Clock Position** Courtesy of FORD MOTOR CO.

56. Rotate the crankshaft clockwise 120 degrees to the 3 o'clock position to position the RH camshafts in the neutral position.



A0011067

#### **Fig. 211: Identifying Crankshaft Keyway** Courtesy of FORD MOTOR CO.

57. Verify that the RH camshafts are in the neutral position.



**Fig. 212: Locating Camshafts Align Marks** Courtesy of FORD MOTOR CO.

- 58. Remove the RH timing chain tensioner arm.
  - 1. Remove the bolts.
  - 2. Remove the tensioner.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

3. Remove the tensioner arm.



**Fig. 213: Identifying RH Timing Chain Tensioner Arm & Bolts** Courtesy of FORD MOTOR CO.

59. Remove the bolts, RH timing chain guide and the timing chain.



**Fig. 214: Locating Timing Chain Guide & Bolts Courtesy of FORD MOTOR CO.** 

60. Rotate the crankcase clockwise 600 degrees (1-2/3 turns) to position the crankcase keyway in the 11 o'clock position. This will position the LH camshafts in the neutral position.



A0011072

#### **Fig. 215: Positioning Crankcase Key Way In 11 O'Clock Position** Courtesy of FORD MOTOR CO.

61. Verify the LH camshafts are in the neutral position.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 216: Locating Camshafts Aligning Marks** Courtesy of FORD MOTOR CO.

- 62. Remove the LH timing chain and tensioner arm.
  - 1. Remove the bolts.
  - 2. Remove the tensioner.
  - 3. Remove the tensioner arm.



#### <u>Fig. 217: Locating LH Timing Chain & Tensioner Arm</u> Courtesy of FORD MOTOR CO.

63. Remove the LH timing chain and timing chain guide.



#### **Fig. 218: Locating Timing Chain & Timing Chain Guide** Courtesy of FORD MOTOR CO.

64. Remove the damper bolt and the crankshaft sprockets.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



**Fig. 219: Locating Damper Bolt & Crankshaft Sprockets Courtesy of FORD MOTOR CO.** 

## CAUTION: Failure to use the correct special tools, assembled as shown in the illustration, will result in damage to the coolant pump pulley and/or special tools.

65. Using the special tools, remove the coolant pump pulley.



**Fig. 220: Removing Coolant Pump Pulley** Courtesy of FORD MOTOR CO.



66. Using the special tools, remove the camshaft oil seal and discard.

sábado 31 de agosto de 2019 08·14·47 a m	Page 132	© 2011 Mitchell Repair Information Company 11 C
cabado, or de agooto de zorio corrirri armi	1 490 102	2011 Miller opan mermater oompany, 220.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### **Fig. 221: Identifying Special Tools (303-409)** Courtesy of FORD MOTOR CO.

- 67. Remove the 2 bolts and the camshaft oil seal retainer.
  - Discard the press-in-place gasket.



**Fig. 222: Locating Camshaft Oil Seal Retainer And Bolts** Courtesy of FORD MOTOR CO.

> CAUTION: Cylinder head camshaft bearing caps must be assembled in their original positions. Some engines have factory markings on the camshaft bearing caps (as shown in illustration). Engines that do not have the factory markings must be marked for correct position and orientation prior to removal. Failure to install the camshaft bearing caps in their original position may result in severe engine damage.

68. If necessary, mark the camshaft bearing cap position and orientation as shown in the illustration.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



```
N0071872
```

CAUTION: After loosening all of the camshaft bearing cap bolts, remove the camshaft bearing thrust caps (1L and 6L) first, or damage to the thrust caps may occur.

## NOTE: Make sure the camshaft bearing caps are marked as instructed in the previous step.

- 69. Loosen the bolts evenly in the sequence shown.
  - 1. Remove the camshaft bearing thrust caps (1L and 6L).
  - 2. Remove the remaining camshaft bearing caps.
  - 3. Remove the camshafts from the cylinder head.

**Fig. 223: Marking Camshaft Bearing Caps** Courtesy of FORD MOTOR CO.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0042361

**Fig. 224: Camshaft Bearing Cap Bolts Loosening Sequence** Courtesy of FORD MOTOR CO.

- CAUTION: Cylinder head camshaft bearing caps must be assembled in their original positions. Some engines have factory markings on the camshaft bearing caps (as shown in illustration). Engines that do not have the factory markings must be marked for correct position and orientation prior to removal. Failure to install the camshaft bearing caps in their original position may result in severe engine damage.
- 70. If necessary, mark the camshaft bearing cap position and orientation as shown in the illustration.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0071873

**Fig. 225: Marking Camshaft Bearing Cap Positions** Courtesy of FORD MOTOR CO.

## CAUTION: After loosening all of the camshaft bearing cap bolts, remove the camshaft bearing thrust caps (5R and 1R) first, or damage to the thrust caps may occur.

### NOTE: Make sure the camshaft bearing caps are marked as instructed in the previous step.

- 71. Loosen the bolts evenly in the sequence shown.
  - 1. Remove the camshaft bearing thrust caps (5R and 1R).
  - 2. Remove the remaining camshaft bearing caps.
  - 3. Remove the camshafts from the cylinder head.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0042362

<u>Fig. 226: Camshaft Bearing Cap Bolts Loosening Sequence</u> Courtesy of FORD MOTOR CO.

## CAUTION: The camshaft roller followers must be installed in their original positions.

#### NOTE: RH shown, LH similar.

- 72. Remove the LH and RH camshaft roller followers.
  - Mark the location of the roller followers, using a permanent-type marker.



**Fig. 227: Locating Camshaft Roller Followers** Courtesy of FORD MOTOR CO.

#### NOTE: RH shown, LH similar.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 73. Loosen the bolts in the indicated sequence and remove the LH and RH cylinder heads.
  - Discard the bolts and the gaskets.



#### **Fig. 228: Identifying Cylinder Heads Bolts Loosening Sequence** Courtesy of FORD MOTOR CO.

74. Support the cylinder head on a bench with the head gasket side up.

### NOTE: The straightedge used must be flat within 0.0051 mm (0.0002 in) per foot of tool length.

- 75. Inspect all areas of the deck face with a straightedge and feeler gauge. The cylinder head must not have depressions deeper than 0.0254 mm (0.001 in) across a 38.1 mm (1.5 in) square area, or scratches more than 0.0254 mm (0.001 in).
- 76. Remove the bolts and the oil separator cover.
  - Discard the gasket.



#### Fig. 229: Locating Oil Separator Cover Bolts Courtesy of FORD MOTOR CO.

77. Remove the crankshaft key.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



A0011186

**Fig. 230: Locating Crankshaft Key Courtesy of FORD MOTOR CO.** 

#### DISASSEMBLY AND ASSEMBLY OF SUBASSEMBLIES

#### **CYLINDER HEAD**

Special Tools			
Illustration	Tool Name	Tool Number	
ST1981-4	Compressor, Valve Spring	303-300 (T87C-6565-A)	
ST1907-A	Compressor, Valve Spring	303-350 (T89P-6565-A)	
ST1906-A	Installer, Valve Stem Oil Seal	303-470 (T94P-6510-CH)	

#### Material

Item	Specification
Motorcraft SAE 5W-20 Premium Synthetic Blend	
Motor Oil	
XO-5W20-QSP (US); Motorcraft SAE 5W-20	WSS-M2C930-A
Super Premium Motor Oil CXO-5W20-LSP12	
(Canada); or equivalent	

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0063020

#### **Fig. 231: Exploded View Of Valve Components Courtesy of FORD MOTOR CO.**

Item	Part Number	Description
1	6518	Valve spring retainer key (24 required)
2	6514	Valve spring retainer (12 required)
3	6513	Valve spring (12 required)
4	6A517	Valve stem seal (12 required)
5	6505	Intake valve (6 required)
6	6507	Exhaust valve (6 required)

#### DISASSEMBLY

CAUTION: If the components are to be reinstalled, they must be installed in the same positions. Mark the components removed for locations. If not reassembled in their original positions, severe engine damage may occur.

1. Using the special tool, remove the keys, retainer and spring.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



A0087958

#### <u>Fig. 232: Identifying Special Tools (303-300 And 303-350)</u> Courtesy of FORD MOTOR CO.

- 2. Remove the valve from the cylinder head.
- 3. Remove the valve stem seal.

#### ASSEMBLY

1. Using the special tool, install the valve stem seal.



**Fig. 233: Installing Valve Stem Seal Courtesy of FORD MOTOR CO.** 

- 2. Install the valve.
- 3. Using the special tool, install the valve spring, retainer and key.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



A0087958

**Fig. 234: Identifying Special Tools (303-300 And 303-350)** Courtesy of FORD MOTOR CO.

#### ASSEMBLY

#### ENGINE

#### **Special Tools**

Illustration	Tool Name	Tool Number
ST1970-A	Installer, Camshaft Oil Seal	303-464 (T94P-6256-BH)
ST3042-A	Installer, Camshaft Pulley	303-458 (T94P-6312-AH3), part of 303-S455
5T1327-A	Installer, Crankshaft Rear Main Oil Seal	303-178 (T82L-6701-A)

sábado, 31 de agosto de 2019 08:14:47 a.m. Page 142 © 2011 Mitchell Repair Information Company, LLC.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

ST1287-A	Installer, Crankshaft Vibration Damper	303-102 (T74P-6316-B)
ST2296-A	Installer, Front Cover Oil Seal	303-335 (T88T-6701-A)
ST1586-A	Installer, Power Steering Pump Pulley	211-185 (T91P-3A733-A)
ST1333-A	Installer Bolts, Crankshaft Rear Main Oil Seal	303-384 (T91P-6701-A)
ST1595-A	Lifting Brackets, Engine	303-050 (T70P-6000)
ST2060-A	Protector, Camshaft Oil Seal	303-463 (T94P-6256-AH)
ST3043-A	Spacer, Water Pump Pulley	303-459 (T94P-6312-AH4), part of 303-S455
ST1602-A	Spreader Bar	303-D089 (D93P-6001-A3) or equivalent

#### Material

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

Item	Specification
Silicone Brake Caliper Grease and Dielectric	
Compound	ESE-M1C171-A
XG-3-A	
Motorcraft Metal Surface Prep	
ZC-31	-
Motorcraft SAE 5W-20 Premium Synthetic Blend	
Motor Oil	
XO-5W20-QSP (US); Motorcraft SAE 5W-20	WSS-M2C930-A
Super Premium Motor Oil CXO-5W20-LSP12	
(Canada); or equivalent	
Silicone Gasket and Sealant	WSE MAC222 AA
TA-30	W SE-140525-A4
### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0037903

# **Fig. 235: Exploded View Of Engine (1 Of 2) Courtesy of FORD MOTOR CO.**

Item	Part Number	Description
1	12A227	Ignition pulse wheel
2	6L266	RH timing chain tensioner
3	6K255	RH timing chain tensioner arm

sábado, 31 de agosto de 2019 08:14:47 a.m. Pag

Page 145 © 2011 Mitchell Repair Information Company, LLC.

### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

4	6268	RH timing chain
5	6M256	RH timing chain guide
6	6306	Crankshaft sprocket
7	6L266	LH timing chain tensioner
8	6K255	LH timing chain tensioner arm
9	6268	LH timing chain
10	6B297	LH timing chain guide
11	6621	Oil pump
12	W701923	Cup plug
13	6B752	Oil separator gasket
14	-	Cover
15	8A505	Water inlet tube
16	6701	Crankshaft rear oil seal
17	-	Spacer plate
18	6375	Flexplate
19	-	Oil pressure sender
20	W705934	Woodruff key
21	6622	Oil pickup tube and screen
22	6687	Oil pan baffle
23	6714	Oil filter
24	6675	Oil pan
25	3A674	Power steering pump and pulley
26	6B209	Accessory drive belt tensioner
27	6700	Crankshaft front seal
28	6316	Crankshaft vibration damper
29	W701511	Crankshaft vibration damper washer
30	W701512	Crankshaft vibration damper bolt
31	6B288	Crankshaft position (CKP) sensor
32	6C315	Camshaft position (CMP) sensor
33	-	Accessory drive belt idler pulley
34	6019	Front cover

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0050545

# **Fig. 236: Exploded View Of Engine (2 Of 2) Courtesy of FORD MOTOR CO.**

Item	Part Number		Description	
1	6582		RH valve cover	
2	18801		Radio ignition interference capacitor	
3	12B637		Engine control sensor and fuel charging	
sábado, 31 de	e agosto de 2019 08:14:47 a.m.	Page 147	© 2011 Mitchell Repair Information Company, L	LC.

### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

		wiring harness
4		Positive crankcase ventilation (PCV)
4	-	valve
5	-	PCV tube
6	9424	Upper intake manifold
7	9J472	Exhaust gas recirculation (EGR) vacuum regulator
8	9D460	EGR valve
9	9E498	Vacuum harness
10	9F715	Idle air control (IAC) valve
11	9E926	Throttle body
12	4682	Fuel rail pressure and temperature sensor
13	9F792	Fuel rail
14	9J477	Lower intake manifold
15	12A366	Coil-on-plug (6 required)
16	6A505	LH valve cover
17	6A359	Coolant pump drive pulley
18	6B293	Rear seal retainer
19	6A258	Camshaft journal cap
20	6B280	Camshaft bearing cap
21	6A269	LH exhaust camshaft
22	8548	Coolant bypass tube
23	6A267	LH intake camshaft
24	12405	Spark plug
25	6C501	Hydraulic lash adjuster
26	6514	Valve spring retainer
27	6529	Camshaft follower
28	6518	Valve spring retainer key
29	6513	Valve spring
30	6A517	Valve stem seal
31	8501	Coolant pump
32	8K543	Coolant pump belt
33	-	LH engine lifting eye
34	-	Oil level indicator
35	6754	Oil level indicator tube
36	6083	LH cylinder head gasket
37	6507	Intake valve
38	6505	Exhaust valve
39	6049	LH cylinder head
40	6051	RH cylinder head gasket
41	6050	RH cylinder head

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

42	6A266	RH intake camshaft
43	6A268	RH exhaust camshaft
44	6B280	Camshaft bearing cap
45	6A258	Camshaft journal cap

CAUTION: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, can cause engine failure.

CAUTION: If the oil pan was removed during engine disassembly, it must be installed after the engine and transaxle are assembled and the transaxle-to-engine bolts are installed. Failure to follow this assembly sequence can result in engine oil leaks.

### All vehicles

1. If removed, install the crankshaft key into the keyway on the crankshaft.



**Fig. 237: Locating Crankshaft Key Courtesy of FORD MOTOR CO.** 

- 2. Install the crankcase cover, a new gasket and the bolts.
  - Tighten to 10 Nm (89 lb-in).



Fig. 238: Locating Oil Separator Cover Bolts

### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

### **Courtesy of FORD MOTOR CO.**

# NOTE: LH shown, RH similar.

- 3. Position the new LH and RH cylinder heads and gaskets. Install new bolts and tighten in the sequence shown in 6 stages.
  - Stage 1: Tighten to 40 Nm (30 lb-ft).
  - Stage 2: Tighten to 90 Nm (66 lb-ft).
  - Stage 3: Loosen one full turn.
  - Stage 4: Tighten to 40 Nm (30 lb-ft).
  - Stage 5: Tighten 90 degrees.
  - Stage 6: Tighten 90 degrees.



### **Fig. 239: Identifying Cylinder Heads Bolts Tightening Sequence** Courtesy of FORD MOTOR CO.

4. Install the crankshaft damper bolt and rotate the crankshaft keyway to the 11 o'clock position to locate top dead center (TDC).



Fig. 240: Locating Crankshaft Damper Bolt Courtesy of FORD MOTOR CO.

5. Apply clean engine oil to the LH and RH camshaft roller followers.

# CAUTION: The camshaft roller followers must be installed in their original

### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

### positions.

# NOTE: RH shown, LH similar.

6. Install the LH and RH camshaft roller followers.



### **Fig. 241: Locating Camshaft Roller Followers Courtesy of FORD MOTOR CO.**

- 7. Apply clean engine oil to the LH and RH camshafts.
- 8. Install the LH and RH camshafts.
  - Locate the camshafts as shown.



**Fig. 242: Locating Camshafts Matching Marks** Courtesy of FORD MOTOR CO.

CAUTION: The camshaft caps must be installed in their original positions or damage to the engine may occur.

# CAUTION: Do not install the camshaft journal thrust caps until all of the camshaft bearing caps have been installed, or damage to the thrust caps can occur.

9. Lubricate the bearing surfaces of the LH camshaft bearing caps with clean engine oil and install the bearing caps.

### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

• Loosely install the bolts.



### **Fig. 243: Locating Camshaft Bearing Caps Installing Sequence** Courtesy of FORD MOTOR CO.

- 10. Lubricate the bearing surfaces of the LH camshaft bearing thrust caps with clean engine oil and install the bearing thrust caps.
  - Loosely install the bolts.



### **Fig. 244: Locating Camshaft Bearing Thrust Caps Courtesy of FORD MOTOR CO.**

- 11. Install the bolts.
  - Tighten in the sequence shown to 8 Nm (71 lb-in).

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



**Fig. 245: Identifying Tightening Sequence Of Bolts Courtesy of FORD MOTOR CO.** 

CAUTION: The camshaft caps must be installed in their original positions or damage to the engine may occur.

# CAUTION: Do not install the camshaft journal thrust caps until all of the camshaft bearing caps have been installed, or damage to the thrust caps can occur.

- 12. Lubricate the bearing surfaces of the RH camshaft bearing caps with clean engine oil and install the bearing caps.
  - Loosely install the bolts.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



#### N0045737

### **Fig. 246: Locating Camshaft Bearing Caps Installing Sequence** Courtesy of FORD MOTOR CO.

- 13. Lubricate the bearing surfaces of the RH camshaft bearing thrust caps with clean engine oil and install the bearing thrust caps.
  - Loosely install the bolts.



### **Fig. 247: Locating Camshaft Bearing Thrust Caps Courtesy of FORD MOTOR CO.**

- 14. Install the bolts.
  - Tighten in the sequence shown to 8 Nm (71 lb-in).

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0000342

**Fig. 248: Identifying Tightening Sequence Of Bolts** Courtesy of FORD MOTOR CO.

# NOTE: Clean the sealing surface with metal surface prep before installing a new press-in-place gasket.

- 15. Install the camshaft oil seal retainer and the 2 bolts.
  - Tighten to 10 Nm (89 lb-in).



**Fig. 249: Locating Camshaft Oil Seal Retainer And Bolts** Courtesy of FORD MOTOR CO.

# NOTE: Apply clean engine oil to the seal lip and seal bore before installing the seal.

16. Using the special tools, install a new camshaft oil seal.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



**Fig. 250: Identifying Special Tools (303-463, 303-464 And 211-185)** Courtesy of FORD MOTOR CO.

# CAUTION: Failure to use the correct special tools, assembled as shown in the illustration, will result in damage to the coolant pump pulley and/or special tools.

- 17. Install the special tool in the camshaft as shown in the illustration.
  - Adjust the collar on the special tool screw to get the best thread engagement in the rear of the camshaft.



**Fig. 251: Installing Special Tool On Camshaft** Courtesy of FORD MOTOR CO.

# CAUTION: Failure to use the correct special tools, assembled as shown in the illustration, will result in damage to the coolant pump pulley and/or special tools.

# NOTE: Only the roller collared nut from the Power Steering Pump Pulley Installer (211-185) is used on Camshaft Pulley Installer (303-458).

- 18. Position the coolant pump pulley over the previously installed special tool and on the end of the camshaft. Install the special tools as shown in the illustration.
  - Using the special tools, install a new service coolant pump pulley flush with the end of the camshaft.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### Fig. 252: Installing Coolant Pump Pulley **Courtesy of FORD MOTOR CO.**

19. Remove the crankshaft damper bolt.



### Fig. 253: Locating Crankshaft Damper Bolt **Courtesy of FORD MOTOR CO.**

20. Install the crankshaft sprockets with the timing marks out.



A0041259

Fig. 254: Locating Crankshaft Sprockets With Timing Marks Out **Courtesy of FORD MOTOR CO.** 

#### NOTE: LH shown, RH similar.

21. Position the chain tensioner in a soft-jawed vise.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



**Fig. 255: Identifying Chain Tensioner In Soft-Jawed Vise** Courtesy of FORD MOTOR CO.

### NOTE: LH shown, RH similar.

22. Hold the chain tensioner ratchet lock mechanism away from the ratchet stem with a small pick.



**Fig. 256: Holding Chain Tensioner Ratchet Lock Mechanism Away From Ratchet Stem Courtesy of FORD MOTOR CO.** 

> CAUTION: During tensioner compression, do not release the ratchet stem until the tensioner piston is fully bottomed in its bore or damage to the ratchet stem will result.

- 23. Slowly compress the timing chain tensioner.
- 24. Retain the tensioner piston with a 1.5 mm (0.06 in) wire or paper clip.



2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

# Fig. 257: Retaining Tensioner Piston With 1.5-mm (0.06-in) Wire Or Paper Clip Courtesy of FORD MOTOR CO.

- 25. If timing marks in the timing chains are not evident, use a permanent-type marker to mark the crankshaft and camshaft timing marks on the LH and RH timing chains.
  - 1. Mark any link to use as the crankshaft timing mark.
  - 2. Starting with the crankshaft timing mark, count 29 links and mark the link.
  - 3. Continue counting to link 42 and mark the link.



### Fig. 258: Locating Crankshaft & Camshaft Timing Marks On LH & RH Timing Chains Courtesy of FORD MOTOR CO.

- 26. Position the LH timing chain and guide and install the bolts.
  - Tighten to 25 Nm (18 lb-ft).
  - Align the marks on the timing chain with the marks on the camshaft and crankshaft sprockets.



N0000344

# Fig. 259: Aligning Marks On Timing Chain With Marks On Camshaft And Crankshaft Sprockets Courtesy of FORD MOTOR CO.

- 27. Install the LH timing chain tensioner arm and the LH timing chain tensioner.
  - 1. Install the tensioner arm.
  - 2. Position the tensioner.
  - 3. Install the bolts.
  - 4. Tighten to 25 Nm (18 lb-ft).

### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### <u>Fig. 260: Identifying Timing Chain Tensioner Arm & Bolts</u> Courtesy of FORD MOTOR CO.

28. Install the crankshaft damper bolt and rotate the crankshaft clockwise 120 degrees until the crankshaft keyway is in the 3 o'clock position.



**Fig. 261: Locating Crankshaft Keyway** Courtesy of FORD MOTOR CO.

29. Verify that the RH camshafts are correctly positioned.



### **Fig. 262: Aligning Marks RH Camshafts** Courtesy of FORD MOTOR CO.

- 30. Install the RH timing chain and chain guide and install the bolts.
  - Tighten to 25 Nm (18 lb-ft).
  - Align the marks on the timing chain with the marks on the camshaft and crankshaft sprockets.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### <u>Fig. 263: Aligning Marks On Timing Chain With Marks On Camshaft And Crankshaft Sprockets</u> Courtesy of FORD MOTOR CO.

- 31. Install the RH timing chain tensioner and tensioner arm.
  - 1. Install the tensioner arm.
  - 2. Position the tensioner.
  - 3. Install the bolts.
  - 4. Tighten to 25 Nm (18 lb-ft).



### <u>Fig. 264: Identifying Tensioner Arm, Tensioner And Bolts</u> Courtesy of FORD MOTOR CO.

- 32. Remove the LH and RH timing chain tensioner piston retaining wires.
- 33. Rotate the crankshaft counterclockwise 120 degrees to top dead center (TDC).

# CAUTION: Failure to verify correct timing drive component alignment will result in severe engine damage.

- 34. Verify the timing with the following steps.
  - 1. There should be 12 chain links between the camshaft timing marks.
  - 2. There should be 27 chain links between the camshaft and the crankshaft timing marks.
  - 3. There should be 30 chain links between the camshaft and the crankshaft timing marks.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0031782

### **Fig. 265: Checking Chain Links Timing Marks** Courtesy of FORD MOTOR CO.

35. Remove the crankshaft damper bolt.



A0011064

**Fig. 266: Identifying Damper Bolt Courtesy of FORD MOTOR CO.** 

# CAUTION: This pulse wheel is used in several different engines. Install the pulse wheel with the keyway in the slot stamped "30" or "30RFF" only (orange in color).

36. Install the ignition pulse wheel.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### **Fig. 267: Identifying Ignition Pulse Wheel Courtesy of FORD MOTOR CO.**

37. Install 3 new gaskets in the front cover.

NOTE: Clean and degrease the sealing surfaces with metal surface prep before applying gasket and sealant.

# NOTE: The front cover must be installed and the bolts tightened within 4 minutes of sealant application.

38. Apply a 6 mm (0.24 in) dot of silicone gasket and sealant to the cylinder block to lower cylinder block and cylinder head mating surfaces.



**Fig. 268: Applying Sealant To Cylinder Block** Courtesy of FORD MOTOR CO.

# NOTE: Fasteners 1, 8, 13 and 16 are stud bolts.

- 39. Position the front cover and install the bolts and stud bolts.
  - Tighten in the sequence shown to 25 Nm (18 lb-ft).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



N0000340

### **Fig. 269: Identifying Tightening Sequence Of Front Cover Bolts** Courtesy of FORD MOTOR CO.

- 40. Install the belt tensioner and the bolt.
  - Tighten to 45 Nm (33 lb-ft).



**Fig. 270: Locating Belt Tensioner & Bolt Courtesy of FORD MOTOR CO.** 

- 41. Install the idler pulley and the bolt.
  - Tighten to 25 Nm (18 lb-ft).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



**Fig. 271: Locating Idler Pulley & Bolt** Courtesy of FORD MOTOR CO.

NOTE: Apply clean engine oil to the seal lip and seal bore before installing the seal.

42. Using the special tools, install the crankshaft front oil seal.



**Fig. 272: Installing Crankshaft Seal Using Special Tools (303-335 And 303-102)** Courtesy of FORD MOTOR CO.

- NOTE: Clean the keyway and slot using metal surface prep before applying silicone gasket and sealant.
- NOTE: Sealing surfaces must be free of dirt and oil.
- NOTE: The crankshaft damper must be installed and the bolt tightened within 4 minutes of sealant application.
- 43. Apply silicone gasket and sealant to the end of the crankshaft damper keyway slot.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



Fig. 273: Applying Silicone Gasket And Sealant **Courtesy of FORD MOTOR CO.** 

#### NOTE: Lubricate the outside diameter sealing surface with clean engine oil.

44. Using the special tool, install the crankshaft vibration damper.



### Fig. 274: Installing Crankshaft Pulley Using Special Tools (303-102, 303-335) **Courtesy of FORD MOTOR CO.**

- 45. Install the crankshaft vibration damper washer and tighten the bolt in 4 stages.
  - Stage 1: Tighten to 120 Nm (89 lb-ft).
  - Stage 2: Loosen one full turn (360 degrees).
  - Stage 3: Tighten to 50 Nm (37 lb-ft).
  - Stage 4: Tighten to 90 Nm (66 lb-ft).



2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

### **Fig. 275: Locating Crankshaft Vibration Damper Washer & Bolt** Courtesy of FORD MOTOR CO.

- 46. Install the knock sensor (KS) and the bolt.
  - Tighten to 25 Nm (18 lb-ft).



**Fig. 276: Locating Knock Sensor (KS) & Bolt** Courtesy of FORD MOTOR CO.

- 47. Install the oil pressure sender and, if equipped, the block heater.
  - Tighten to 14 Nm (10 lb-ft).



**Fig. 277: Locating Oil Pressure Sender** Courtesy of FORD MOTOR CO.

- 48. Position the oil pan baffle. Install the nuts and tighten in 2 stages.
  - Stage 1: Tighten to 5 Nm (44 lb-in).
  - Stage 2: Tighten 45 degrees.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### **Fig. 278: Locating Oil Pan Baffle And Nuts** Courtesy of FORD MOTOR CO.

49. Install a new O-ring seal on the oil pump screen and pickup tube. Lubricate with clean engine oil.



A0011413

# Fig. 279: Locating O-Ring Seal Courtesy of FORD MOTOR CO.

- 50. Install the oil pump screen and pickup tube.
  - 1. Position the oil pump screen and pickup tube.
  - 2. Install the bolts.
  - 3. Install the nut and tighten in 2 stages.
    - Stage 1: Tighten to 5 Nm (44 lb-in).
    - Stage 2: Tighten 45 degrees.



### **Fig. 280: Identifying Oil Pump Screen, Pickup Tube & Bolts Courtesy of FORD MOTOR CO.**

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

51. Install a new O-ring on the oil level indicator tube. Apply clean engine oil to the O-ring.



A0011038

# **Fig. 281: Locating O-Ring On Oil Level Indicator Tube** Courtesy of FORD MOTOR CO.

- 52. Position the oil level indicator and tube and install the stud bolt.
  - Tighten to 10 Nm (89 lb-in).



### Fig. 282: Oil Level Indicator Tube & Nut Courtesy of FORD MOTOR CO.

- 53. Install the bypass tube and the nut and bolt.
  - Tighten to 10 Nm (89 lb-in).



**Fig. 283: Locating Coolant Bypass Tube Bolts Courtesy of FORD MOTOR CO.** 

### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

54. Position the coolant tube and connect the hoses.



**Fig. 284: Locating Coolant Tube Courtesy of FORD MOTOR CO.** 

- 55. Install the coolant pump and the bolts.
  - Tighten to 10 Nm (89 lb-in).



Fig. 285: Locating Coolant Pump & Bolts Courtesy of FORD MOTOR CO.

56. Connect the hoses.



**<u>Fig. 286: Locating Hoses</u>** Courtesy of FORD MOTOR CO.

57. Install the coolant pump belt on the coolant pump pulley and position it on the camshaft pulley.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



**Fig. 287: Locating Coolant Pump Belt On Coolant Pump Pulley** Courtesy of FORD MOTOR CO.

# CAUTION: Do not use any screwdrivers, pliers or other metal objects that could cause damage to the belt or camshaft pulley while installing the belt.

- 58. Rotate the crankshaft clockwise to seat the water pump belt on the camshaft pulley.
- 59. Lubricate the O-ring seal and install the oil filter.
  - Tighten the oil filter 3/4 of a turn after the filter gasket makes contact with the oil filter adapter.



A0018485

### **Fig. 288: Locating Oil Filter** Courtesy of FORD MOTOR CO.

### Front wheel drive (FWD) vehicles

- 60. Install the halfshaft support bracket and the bolts.
  - Tighten to 48 Nm (35 lb-ft).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### **Fig. 289: Locating Halfshaft Support Bracket & Bolts** Courtesy of FORD MOTOR CO.

- 61. Install 6 new RH exhaust manifold studs.
  - Tighten to 12 Nm (9 lb-ft).



**Fig. 290: Locating Exhaust Manifold Studs** Courtesy of FORD MOTOR CO.

- 62. Install a new gasket and the RH exhaust manifold and new nuts.
  - Tighten in the sequence shown to 20 Nm (15 lb-ft).



**Fig. 291: Right Exhaust Manifold Nuts Tightening Sequence** Courtesy of FORD MOTOR CO.

### All vehicles

### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 63. Install 6 new LH exhaust manifold studs.
  - Tighten to 12 Nm (9 lb-ft).



**Fig. 292: Locating Exhaust Manifold Studs** Courtesy of FORD MOTOR CO.

- 64. Install a new gasket and the LH exhaust manifold and new nuts.
  - Tighten in the sequence shown to 20 Nm (15 lb-ft).



**Fig. 293: Left Exhaust Manifold Nuts Tightening Sequence** Courtesy of FORD MOTOR CO.

# CAUTION: Only use hand tools when removing or installing the spark plugs, damage can occur to the cylinder head or spark plug.

- 65. Install the LH and RH spark plugs.
  - Tighten to 15 Nm (11 lb-ft).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



<u>Fig. 294: Spark Plugs</u> Courtesy of FORD MOTOR CO.

- NOTE: LH shown, RH similar.
- NOTE: The valve cover must be installed and the bolts and studs tightened within 4 minutes of sealant application.
- NOTE: Clean cylinder head and front cover surface using metal surface prep before applying silicone gasket and sealant.
- 66. Apply an 8 mm (0.31 in) dot of silicone gasket and sealant at the cylinder block to front cover mating surface of the LH and RH valve covers.



Fig. 295: Applying Silicone Gasket And Sealant At Cylinder Head To Front Cover Mating Surface Courtesy of FORD MOTOR CO.

### NOTE: Install a new valve cover gasket.

- 67. Position the LH valve cover and install the bolts and stud bolts.
  - Tighten in the sequence shown to 10 Nm (89 lb-in).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### Fig. 296: Identifying Tightening Sequence Of Valve Cover Bolts & Studs Courtesy of FORD MOTOR CO.

- 68. Install the engine lift bracket and the bolt.
  - Tighten to 118 Nm (87 lb-ft).



Fig. 297: Locating Lift Bracket & Bolt Courtesy of FORD MOTOR CO.

### NOTE: Install a new valve cover gasket.

- 69. Position the RH valve cover and install the bolts and stud bolts.
  - Tighten in the sequence shown to 10 Nm (89 lb-in).



### **Fig. 298: Identifying Tightening Sequence Of Valve Cover Stud Bolts** Courtesy of FORD MOTOR CO.

### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 70. Install the radio interference capacitor and the nut.
  - Tighten to 6 Nm (53 lb-in).



**Fig. 299: Locating Radio Interference Capacitor Nut** Courtesy of FORD MOTOR CO.

# NOTE: LH shown, RH similar.

# Apply a light film of silicone brake caliper grease and dielectric compound to the interior of the spark plug boot prior to installation.

- 71. Install the 6 coil-on-plugs and the bolts.
  - Tighten to 6 Nm (53 lb-in).



**<u>Fig. 300: Coil-On-Plug Bolts</u>** Courtesy of FORD MOTOR CO.

72. Install new gaskets in the lower intake manifold.

# NOTE: Install new gaskets.

- 73. Install the lower intake manifold and the bolts.
  - Tighten in the sequence shown to 10 Nm (89 lb-in).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### **Fig. 301: Identifying Tightening Sequence Of Lower Intake Manifold Bolts Courtesy of FORD MOTOR CO.**

74. Position the fuel charging wiring harness and connect the fuel injector electrical connectors.



### **Fig. 302: Locating Fuel Injector Electrical Connectors Courtesy of FORD MOTOR CO.**

75. Connect the fuel rail pressure and temperature sensor electrical connector and vacuum tube.



### **Fig. 303: Locating Fuel Rail Pressure & Temperature Sensor Electrical Connector Courtesy of FORD MOTOR CO.**

76. Connect the crankshaft position (CKP) sensor electrical connector and attach the wiring retainers.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### **Fig. 304: Locating Crankshaft Position (CKP) Sensor Electrical Connector Courtesy of FORD MOTOR CO.**

77. Connect the camshaft position sensor (CMP) and oil pressure sensor electrical connectors and attach the wiring retainers.



### Fig. 305: Locating Camshaft Position Sensor (CMP) & Oil Pressure Sensor Electrical Connectors & Wiring Retainers Courtesy of FORD MOTOR CO.

78. Connect the LH coil-on-plug electrical connectors and attach the 2 wiring retainers.



### **Fig. 306: Coil-On-Plug Electrical Connectors & Wiring Retainers Courtesy of FORD MOTOR CO.**

79. Connect the radio interference capacitor electrical connector and attach the wiring retainers.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### <u>Fig. 307: Locating Radio Interference Capacitor Electrical Connector</u> Courtesy of FORD MOTOR CO.

80. Connect the RH coil-on-plug electrical connectors and attach the wiring retainer.



### **Fig. 308: Locating Coil-On-Plug Electrical Connectors & Wiring Retainers** Courtesy of FORD MOTOR CO.

81. Connect the engine coolant temperature (ECT) sensor electrical connector.



<u>Fig. 309: Locating Engine Coolant Temperature (ECT) Sensor Electrical Connector</u> Courtesy of FORD MOTOR CO.

# NOTE: Install new gaskets.

- 82. Install the upper intake manifold and the bolts.
  - Tighten in the sequence shown to 10 Nm (89 lb-in).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### **Fig. 310: Identifying Tightening Sequence Of Upper Intake Manifold Bolts Courtesy of FORD MOTOR CO.**

83. Connect the throttle body coolant hose.



**Fig. 311: Locating Throttle Body Coolant Hose Courtesy of FORD MOTOR CO.** 

84. Connect the vacuum tube fittings to the EGR valve, EGR vacuum regulator and the intake manifold.



### **Fig. 312: Vacuum Tube Fittings At EGR Valve, EGR Vacuum Regulator & Intake Manifold** Courtesy of FORD MOTOR CO.

85. Install the PCV tube.
2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## **Fig. 313: Locating Positive Crankcase Ventilation (PCV) Tube** Courtesy of FORD MOTOR CO.

86. Connect the idle air control (IAC) valve and the throttle position (TP) sensor electrical connectors and attach the wiring retainer.



## **Fig. 314: Idle Air Control Valve & Throttle Position Sensor Electrical Connectors Courtesy of FORD MOTOR CO.**

- 87. Position the engine control wiring harness and install the nuts.
  - Tighten to 6 Nm (53 lb-in).



**Fig. 315: Locating Engine Control Wiring Harness & Nuts** Courtesy of FORD MOTOR CO.

88. Connect the KS electrical connector.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



### **Fig. 316: Locating Knock Sensor (KS) Electrical Connector Courtesy of FORD MOTOR CO.**

- 89. Connect the exhaust gas recirculation (EGR) vacuum regulator electrical connector. Attach the wiring harness retainer and install the nut.
  - Tighten to 10 Nm (89 lb-in).



# Fig. 317: Locating Exhaust Gas Recirculation (EGR) Vacuum Regulator Electrical Connector Courtesy of FORD MOTOR CO.

- 90. Position the heated oxygen sensor (HO2S) electrical connector bracket. Install the nut and attach the wiring retainer.
  - Tighten to 10 Nm (89 lb-in).



## **Fig. 318: Locating Heated Oxygen Sensor (HO2S) Electrical Connector Bracket** Courtesy of FORD MOTOR CO.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

91. Attach the engine control sensor wiring connectors to the upper intake manifold.



**Fig. 319: Locating Engine Control Sensor Wiring Connectors Courtesy of FORD MOTOR CO.** 

92. Using the special tools, remove the engine from the engine stand.



**Fig. 320: Removing Engine From Engine Stand Courtesy of FORD MOTOR CO.** 

## **NOTE:** Lubricate the seal lips and seal bore with clean engine oil before installing.

93. Using the special tools, install the crankshaft rear oil seal.



**Fig. 321: Identifying Special Tools (303-384 And 303-178)** Courtesy of FORD MOTOR CO.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 94. Position the flexplate and install the bolts.
  - Tighten to 80 Nm (59 lb-ft).



**Fig. 322: Locating Flexplate & Bolts Courtesy of FORD MOTOR CO.** 

# **INSTALLATION**

## ENGINE

#### **Special Tools**

Illustration	Tool Name	Tool Number
<b>ST1595-A</b>	Lifting Bracket, Engine	303-050 (T70P-6000)
ST1293-A	Powertrain Lift with Tilting Plate	014-00765
ST1602-A	Spreader Bar	303-D089 (D93P-6001-A3) or equivalent
ST2743A	Universal Adapter Brackets	014-0001

#### Material

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

Item	Specification
Motorcraft SAE 5W-20 Premium Synthetic Blend Motor Oil XO-5W20-QSP (US); Motorcraft SAE 5W-20 Super Premium Motor Oil CXO-5W20-LSP12 (Canada); or equivalent	WSS-M2C930-A
Silicone Gasket and Sealant TA-30	WSE-M4G323-A4

#### INSTALLATION

## CAUTION: If the oil pan was removed during engine disassembly, it must be installed after the engine and transaxle are assembled and the transaxle-to-engine bolts are installed. Failure to follow this assembly sequence can result in engine oil leaks.

#### All vehicles

1. Using the special tools, align the engine with the transaxle.



### **Fig. 323: Aligning Engine With Transaxle Courtesy of FORD MOTOR CO.**

- 2. Install the 7 transaxle bolts.
  - Tighten to 40 Nm (30 lb-ft).



## Fig. 324: Locating Transaxle-To-Engine Bolts

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

## **Courtesy of FORD MOTOR CO.**

3. Using the special tools, secure the engine to the powertrain lift.



## <u>Fig. 325: Securing Engine & Transaxle To Powertrain Lift Using Special Tool (014-0001)</u> Courtesy of FORD MOTOR CO.

## All wheel drive (AWD) vehicles

- 4. Position the power take off, attach the pin-type retainer and install the bolt.
  - Tighten to 14 Nm (10 lb-ft).



**Fig. 326: Locating Pin-Type Retainer & Bolts** Courtesy of FORD MOTOR CO.

- 5. Install the halfshaft support bracket and the bolts.
  - Tighten to 48 Nm (35 lb-ft).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## Fig. 327: Locating Half Shaft Support Bracket & Bolts Courtesy of FORD MOTOR CO.

- 6. Install 6 new RH exhaust manifold studs.
  - Tighten to 12 Nm (9 lb-ft).



Fig. 328: Locating Exhaust Manifold Studs Courtesy of FORD MOTOR CO.

- 7. Install a new gasket and the RH exhaust manifold and new nuts.
  - Tighten in the sequence shown to 20 Nm (15 lb-ft).



**Fig. 329: Identifying Tightening Sequence Of RH Exhaust Manifold Nuts** Courtesy of FORD MOTOR CO.

## All vehicles

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

8. Connect the turbine speed sensor (TSS) electrical connector.



**Fig. 330: Locating Turbine Speed Sensor (TSS) Electrical Connector Courtesy of FORD MOTOR CO.** 

9. Attach the transaxle control harness to the brackets.



**Fig. 331: Locating Transaxle Control Harness Courtesy of FORD MOTOR CO.** 

10. Connect the transaxle wiring harness electronic control switch electrical connector.



**Fig. 332: Locating Transaxle Wiring Harness Electronic Control Switch Electrical Connector Courtesy of FORD MOTOR CO.** 

11. Connect the transmission range (TR) sensor electrical connector.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## **Fig. 333: Locating Transmission Range (TR) Sensor Electrical Connector Courtesy of FORD MOTOR CO.**

12. Attach the pin-type retainers to the transaxle support bracket and connect the heated oxygen sensor (HO2S) and catalyst monitor sensor electrical connectors.



## <u>Fig. 334: Locating Heated Oxygen & Catalyst Monitor Sensor Electrical Connectors</u> Courtesy of FORD MOTOR CO.

13. Position the powertrain into the vehicle.



## **Fig. 335: Positioning Powertrain Into Vehicle Courtesy of FORD MOTOR CO.**

- 14. Install the front engine support nuts.
  - Tighten to 55 Nm (41 lb-ft).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## **Fig. 336: Locating Front Engine Support Bolts & Nut** Courtesy of FORD MOTOR CO.

- 15. Install the rear transaxle support bolt.
  - Tighten to 103 Nm (76 lb-ft).



**Fig. 337: Locating Transaxle Mount Bolt Courtesy of FORD MOTOR CO.** 

- 16. Position the RH transaxle support insulator and install the bolt and nuts.
  - Tighten to 80 Nm (59 lb-ft).



**Fig. 338: Locating Transaxle Support Insulator Bolt & Nuts** Courtesy of FORD MOTOR CO.

- 17. Install the RH transaxle support insulator bolt.
  - Tighten to 115 Nm (85 lb-ft).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



**Fig. 339: Locating RH Transaxle Support Insulator Bolt** Courtesy of FORD MOTOR CO.

**NOTE:** Clean and degrease all sealing surfaces with metal surface cleaner.

# NOTE: The oil pan must be installed and the bolts tightened within 4 minutes of the sealant application.

18. Apply a 10 mm (0.39 in) dot of silicone gasket and sealant to the front cover-to-cylinder block sealing surface.



### **Fig. 340:** Applying Silicone Gasket And Sealant To Front Cover-To-Cylinder Block Courtesy of FORD MOTOR CO.

## NOTE: Install a new oil pan gasket.

19. Position the oil pan and gasket and loosely install the bolts and stud bolts.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## Fig. 341: Locating Oil Pan Gasket Bolts & Stud Bolts Courtesy of FORD MOTOR CO.

- 20. Install the 2 oil pan-to-transaxle bolts.
  - Tighten to 40 Nm (30 lb-ft).



## **Fig. 342: Locating Oil Pan-To-Transaxle Bolts** Courtesy of FORD MOTOR CO.

21. Tighten the oil pan bolts in the sequence shown to 25 Nm (18 lb-ft).



## **Fig. 343: Identifying Tightening Sequence Of Oil Pan-To-Engine Bolts And Stud Bolts** Courtesy of FORD MOTOR CO.

- 22. Install the 4 torque converter nuts.
  - Tighten to 40 Nm (30 lb-ft).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## **Fig. 344: Locating Torque Converter Nuts Courtesy of FORD MOTOR CO.**

23. Install the torque converter inspection cover.



### **Fig. 345: Locating Torque Converter Inspection Cover Courtesy of FORD MOTOR CO.**

- 24. Install the output shaft speed (OSS) sensor and the bolt and connect the electrical connector.
  - Tighten to 13 Nm (10 lb-ft).



### **Fig. 346: Locating Output Shaft Speed (OSS) Sensor Electrical Connector Courtesy of FORD MOTOR CO.**

25. Attach the HO2S wiring retainer to the radiator center support.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## <u>Fig. 347: Locating Heated Oxygen Sensor (HO2S) Wiring Retainer</u> Courtesy of FORD MOTOR CO.

26. If equipped, connect the engine block heater electrical connector.



### **Fig. 348: Locating Engine Block Heater Electrical Connector Courtesy of FORD MOTOR CO.**

27. Attach the wiring harness retainers from the battery tray bracket.



**Fig. 349: Wiring Harness Retainers** Courtesy of FORD MOTOR CO.

- 28. Position the ground strap and the electrical connector and install the bolts.
  - Tighten to 10 Nm (89 lb-in).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## **Fig. 350: Locating Ground Strap & Electrical Connector Courtesy of FORD MOTOR CO.**

- 29. Install the cables and the nuts.
  - Tighten to 12 Nm (9 lb-ft).



Fig. 351: Locating Cables & Nuts Courtesy of FORD MOTOR CO.

30. Install the power distribution box cover.



### **Fig. 352: Locating Power Distribution Box Cover Courtesy of FORD MOTOR CO.**

- 31. Attach the ground wire and install the bolt.
  - Tighten to 10 Nm (89 lb-in).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## **Fig. 353: Locating Ground Wire & Bolt** Courtesy of FORD MOTOR CO.

- 32. Position the wiring and install the nut. Connect the powertrain control module (PCM) electrical connectors.
  - Tighten to 8 Nm (71 lb-in).



### **Fig. 354: Locating Powertrain Control Module (PCM) Electrical Connectors Courtesy of FORD MOTOR CO.**

33. Connect the manifold absolute pressure (MAP) sensor electrical connector and vacuum tube.



## Fig. 355: Locating Manifold Absolute Pressure (MAP) Sensor Vacuum Tube & Electrical Connector Courtesy of FORD MOTOR CO.

34. Connect the brake booster vacuum tube and the vacuum reservoir tube.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## Fig. 356: Locating Brake Booster Vacuum Tube & Vacuum Reservoir Tube Courtesy of FORD MOTOR CO.

- 35. Connect the evaporative emissions purge valve vacuum tube to the intake manifold.
  - Attach the vacuum tube retainer to the transmission fill tube.



**Fig. 357: Locating Vacuum Tube Retainer Courtesy of FORD MOTOR CO.** 

- 36. Position the exhaust gas recirculation (EGR) tube and loosely install the fittings.
  - Tighten the EGR tube-to-EGR valve fitting to 40 Nm (30 lb-ft).



**Fig. 358: Locating Exhaust Gas Recirculation (EGR) Tube** Courtesy of FORD MOTOR CO.

37. Connect the differential pressure feedback EGR sensor electrical connector and attach the pin-type retainer.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## **Fig. 359: Locating EGR Sensor Electrical Connector Courtesy of FORD MOTOR CO.**

- 38. Position the gearshift cable bracket and install the bolts.
  - Tighten to 19 Nm (14 lb-ft).



## **Fig. 360: Locating Gearshift Cable Bracket Bolts Courtesy of FORD MOTOR CO.**

39. Attach the wiring harness pin-type retainer to the gearshift cable bracket.



**Fig. 361: Locating Pin-Type Retainer** Courtesy of FORD MOTOR CO.

- 40. Connect the fuel supply tube quick connect coupling at the fuel rail. For additional information, refer to **FUEL SYSTEM GENERAL INFORMATION** article.
- 41. Connect the heater hoses and the throttle body coolant hose.

sábado, 31 de agosto de 2019 08:14:48 a.m. Page 198 © 2011 Mitchell Repair Information Company, LLC.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## Fig. 362: Locating Heater Hoses & Throttle Body Coolant Hose Courtesy of FORD MOTOR CO.

42. Connect the hoses.



Fig. 363: Locating Hoses Courtesy of FORD MOTOR CO.

- 43. Position the accelerator and speed control cables and bracket. Install the nut.
  - Tighten to 10 Nm (89 lb-in).



## **Fig. 364: Locating Cable Bracket Bolts (2 Of 2)** Courtesy of FORD MOTOR CO.

- 44. Position the bracket and install the bolts.
  - Tighten to 10 Nm (89 lb-in).
  - Connect the accelerator cable and the speed control actuator cable.

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## Fig. 365: Accelerator Cable, Speed Control Actuator Cable & Cable Bracket Bolts Courtesy of FORD MOTOR CO.

- 45. Position the accelerator cable snow shield and install the bolts.
  - Tighten to 10 Nm (89 lb-in).



## **Fig. 366: Locating Accelerator Cable Snow Shield Bolts Courtesy of FORD MOTOR CO.**

46. Tighten the EGR tube-to-RH catalytic converter fitting to 40 Nm (30 lb-ft).



A0041035

## **Fig. 367: Locating EGR Tube-To-RH Catalytic Converter Fitting** Courtesy of FORD MOTOR CO.

47. Connect the 2 transmission cooler tubes.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## **Fig. 368: Locating Transmission Cooler Tubes Courtesy of FORD MOTOR CO.**

- 48. Install the crossbrace and the new nut.
  - Tighten to 175 Nm (129 lb-ft).



### **Fig. 369: Identifying Cross Brace And Rear Nut** Courtesy of FORD MOTOR CO.

- 49. Install the bolt for the transaxle mount and install the 2 bolts for the crossbrace.
  - Tighten the transaxle mount bolt to 115 Nm (85 lb-ft).
  - Tighten the crossbrace bolts to 90 Nm (66 lb-ft).



### **Fig. 370: Identifying Front Roll Restrictor Bolt & Bolts For Engine Support Crossmember** Courtesy of FORD MOTOR CO.

50. Install the lateral support crossmember and the 4 bolts.

#### 2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

• Tighten to 115 Nm (85 lb-ft).



A0087403

## **Fig. 371: Identifying Lateral Support Crossmember And Bolts Courtesy of FORD MOTOR CO.**

- 51. Position the power steering pump and install the bolts.
  - Tighten to 25 Nm (18 lb-ft).



### **Fig. 372: Locating Power Steering Pump Bolts Courtesy of FORD MOTOR CO.**

- 52. Install the power steering pump pulley and the nut.
  - Tighten to 49 Nm (36 lb-ft).

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner



## **Fig. 373: Locating Power Steering Pump Pulley & Nut** Courtesy of FORD MOTOR CO.

- 53. Install the A/C compressor and the bolts.
  - Tighten to 25 Nm (18 lb-ft).



## **Fig. 374: Locating A/C Compressor & Bolts Courtesy of FORD MOTOR CO.**

54. Connect the A/C clutch field coil electrical connector.



**Fig. 375: Locating A/C Clutch Field Coil Electrical Connector Courtesy of FORD MOTOR CO.** 

## **AWD** vehicles

CAUTION: Do not reuse the bolts and straps for the center U-joint. Install new

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

bolts and straps or damage to the vehicle may occur.

## NOTE: There is a difference in the length of the head of the replacement yoke strap bolts from the production bolts. The longer head pinion bolts can be used in either location.

### 55. Install the driveshaft.

- 1. Align the driveshaft with the index marks.
- 2. Install the new straps and bolts.
- 3. Tighten to 23 Nm (17 lb-ft).



Fig. 376: Locating Straps & Bolts Courtesy of FORD MOTOR CO.

# CAUTION: Do not reuse the CV joint bolts and washers. Install new bolts and washers or damage to the vehicle may occur.

- 56. Install the 6 front driveshaft-to-power take off bolts and washers.
  - Tighten to 37 Nm (27 lb-ft).



A0090352

**Fig. 377: Locating Driveshaft-To-Power Take Off Bolts & Washers** Courtesy of FORD MOTOR CO.

## All vehicles

2007 ENGINE Engine - 3.0L (4V) - Escape & Mariner

- 57. Install the LH halfshaft. For additional information, refer to **FRONT DRIVE HALFSHAFTS** article.
- 58. Position the accessory drive belt on all pulleys except the generator pulley.
- 59. Install the generator. For additional information, refer to **<u>GENERATOR AND REGULATOR</u>** article.
- 60. Install the exhaust system flexpipe. For additional information, refer to **EXHAUST SYSTEM** article.
- 61. Install the lower radiator air deflectors.



A0019937

## Fig. 378: Splash Shields Courtesy of FORD MOTOR CO.

- 62. Position the power steering hose bracket and install the nut.
  - Tighten to 25 Nm (18 lb-ft).
  - Connect the power steering pressure (PSP) switch electrical connector.



## **Fig. 379: Locating Power Steering Pressure (PSP) Switch Electrical Connector Courtesy of FORD MOTOR CO.**

- 63. Install the air cleaner outlet pipe and air cleaner. For additional information, refer to <u>INTAKE AIR</u> <u>DISTRIBUTION AND FILTERING 3.0L (4V)</u> article.
- 64. Install the battery tray. For additional information, refer to **<u>BATTERY, MOUNTING AND CABLES</u>** article.
- 65. Fill and bleed the cooling system. For additional information refer to **ENGINE COOLING** article.
- 66. Fill the engine with clean engine oil.