








No. 5 Injector
No. 6 Injector
High Pressure Fuel Pump
Knock Sensor (Bank 1)
Knock Sensor (Bank 2)
Intake Air Temperature (Mass Flow) Sensor
Rocker Arm Oil Pressure Sensor
ATF Temperature Sensor
ECT Sensor 1
MAF Sensor (Mass Flow) Sensor
CKP Sensor
CMP Sensor
Rocker Arm Oil Pressure Switch A (Bank 1)
Rocker Arm Oil Pressure Switch A (Bank 2)
Park/Neutral Position (PNP) Switch
Brake Pedal Position Switch
Horn Relay
Engine Room Relay Box
Underhood Fuse/Relay Box
Data Link Connector (DLC)
Washer Fluid Level Switch
APP Sensor
Throttle Body
Throttle Actuator
Throttle Cont Sensor
Cable Reel
Alternator
CAN H
CAN L


Brake Pedal Position Switch
Horn Relay
Under-Hood Fuse/Relay Box
Data Link Connector (DLC)
Driver's Junction Box B
Engine Mount Control Unit
VSA Modulator-Control Unit
SRS Unit
Keyless Access Control Unit
Front Passenger's Seat Belt Sensor
Gauge Control Module
Steering Angle Sensor
ANC/ Active Sound Control Unit
Radio/ Navi/ Entry-Navigation Unit
EPS Control Unit
LKAS Camera Control Unit
Driver's Seat Heater
ACC Unit