




(+)
1
12 Volt Battery
[EO] BLK
T4 1
Starter
T101 1
120A A1-6
30A A3-3
33
[EA] WHT
D 4
[BD] WHT
A 1
Under-Dash Fuse/Relay Box
[BD] RED
A 3
15A B4
C 13
7.5A B7
C 5
A 1
C 3
+B IG1 MAIN1
IG1-A
Under-Dash Subrelay Box
IG1-A:HOT IN ON AND START MODE
15A A23
60
[EA] BLU
D 9
L5
PGM-FI Main Relay 1
D 26
C001
2
1
[EC] YEL/BLK
[EC] YEL/BLK
8
C403
8 7
3
CKP Sensor
[EA] BRN
C 9
15A A22
59
[EA] LT_GRN
D 5
20A A12
49
L4
ETCS Control Relay
Under-Hood Fuse/Relay Box
[EA] RED
[EA] BRN
5
7
Injector Relay
6
8
C 34
D 12
[EA] PUR
[EA] GRY
[EA] GRY
[EA] BLU
[EA] BLU
[EA] RED
[EA] RED
C403
2
2
[EC] YEL/GRN
A 6
A 7
A 15
A 5
A 19
C 2
A 3
A 11
A 14
PCM
C 1
C 8
B 11
B 12
B 9
B 10
[EC] BLK
[EC] BLK
[EC] BLK
[EC] BLK
[EC] BRN
Thermal Joint 1
Thermal Joint 2
Thermal Joint 3
Thermal Joint 4
2
No. 1 Ignition Coil
No. 2 Ignition Coil
No. 3 Ignition Coil
No. 4 Ignition Coil
CMP Sensor A
CMP Sensor B
[EC] BLK
[EC] BRN
[EC] BLK
[EC] BLK
G101
G101
G101
G101
G102
G102