



ws = white
sw = black
ro = red
br = brown
gn = green
bl = blue
gr = grey
li = violet
ge = yellow

A – Battery
B – Starter
C – Generator (GEN)
C1 – Voltage Regulator (VR)
D – Ignition/Starter Switch
F95 – After–Run Coolant Thermal Switch
G – Fuel Level Sensor
G6 – Fuel Pump (FP)
J151 – Coolant Circulation Pump Relay
J226 – Park/Neutral Position (PNP) Relay
T1b – Single Connector, near starter
T2 – Double Connector
T9 – 9-Pin Connector

(216) – Ground connection -2-, in Motronic Multiport Fuel Injection (MFI) wiring harness

– – – automatic transmission only
* – manual transmission only