


BLK
A1 B1 C1 D1
B2 D2
A3 B3 C3 D3
A4 B4 C4 D4
B5 D5
A6 B6 C6 D6
A7 B7 D7 E7
B8 E8
A8 B9 D9 E9
F1 G2 H1 J2 K1 L2
F3 G4 H3 J4 K3 L4
F5 G6 H6 J6 K5 L5
F7 G8 H7 J8 K7 L8
F9 G10 H9 J10 K9 L10
F11 G12 H11 J12 K11 L12
N1 N2 N3 N4 N5 N6 N7 N8
M1 M2 M3 M4 M5 M6 M7 M8
R7 R8 P7 P8
B A


AUX B
AUX A
A/C RELAY
IGN RELAY
STARTER ENABLE RELAY
A/C ENABLE RELAY
ABS T/T RELAY EXPORT
FUEL PUMP RELAY
30 A
UPFIT - BATT
30 A
UPFIT - ACCY
10
20
20
10 A
SPARE
20 A
ECM - B
20 A
HORN
10 A
A/C COMP
20 A
ATC
20 A
ENG - 1
10 A
IGN - E
20 A
ECM - 1
DIODE I
DIODE II
40 A
LIGHTING
50 A
BATT
40 A
IGN A
40 A
IGN B
60 A
ABS
30 A
A/C
30 A
RR HTR/AC
40 A
HTD MIR/RR DEFOG

Name	Cavity Number	Size	Circuit	Loads
RR DEFOG	M1-N1	40A Maxi Fuse	1440	RR DEFOG
RR HEAT/A/C	M2-N2	30A Maxi Fuse	742	A/C Relay (Rear)
A/C	M3-N3	30A Maxi Fuse	542	Blower Motor Resistor and High Blower Relay
ABS	M4-N4	60A Maxi Fuse	442	Electronic Brake Control Module (EBCM)
IGN-B	M5-N5	40A Maxi Fuse	342	IGN-B Switch to IP Fuse Block Bus Bars
IGN-A	M6-N6	40A Maxi Fuse	242	IGN-A Switch to IP Fuse Block Bus Bar, Park/Neutral Position and Back-up Lamp Switch, Underhood Fuse-Relay Center Bus Bar
BATT	M7-N7	50A Maxi Fuse	142	IP Fuse Block Bus Bar, Lock/Seats Circuit Breaker
LIGHTING	M8-N8	40A Maxi Fuse	42	Headlamp and Panel Dimmer Switch, IP Fuse Block Bus Bar
A/C COMP	K11-L12	10A Fuse	1240	A/C Enable Relay
HORN	H11-J12	20A Fuse	740	Horn Relay
ECM-B	F11-G12	20A Fuse	440	Fuel Pump Relay, VCM, Oil Pressure Switch and Sender
ECM-I	K7-L8	20A Fuse	439	Fuel Injectors, VCM, Crankshaft Position Sensor, Distributor Ignition Control Module
IGN-E	H7-J8	10A Fuse	639	A/C Enable Relay
ENG-I	F7-G8	20A Fuse	539	All Oxygen Sensor, VCM, MAF Sensor, Camshaft Position Sensor, Linear EGR Valve Solenoid, EVAP Emission Canister Purge Solenoid Valve
A/C CLUTCH	L4-K3	Diode-I	850 - 59(2)	A/C Enable Relay, A/C Compressor Clutch
—	L2-K1	—	—	—
—	Stud "A"	30A	1842	Upfitter Ignition Power Stud
—	Stud "B"	30A	1742	Upfitter Battery Power Stud
UPFIT-BATT	P8-R8	30A Maxi Fuse	1742	Portable/Installed By Upfitter
UPFIT-IGN	P7-R7	30A Maxi Fuse	1842	Portable/Installed by Upfitter
Starter Enable Relay	B4	Mini Relay	6	Starter Solenoid Feed
A/C Relay (Rear)	B7	Mini Relay	1923	Auxiliary HVAC Switch Feed
Fuel Pump Relay	D1	Micro Relay	440	Fuse Output - Battery - Type III Fuse
A/C Enable Relay	D4	Micro Relay	59	Air Conditioning Compressor Clutch Solenoid Feed
IGN Relay	E7	Mini Relay	1839	Fuse Output - Ignition 1 - Type III Fuse
ATC	H9-J10	20A Maxi Fuse	1540	ACTIVE TRANSFER CASE