

Note: Setup MAP-ECU to 4-Cylinder.

Note: Non-catalytic converter vehicles have an additional VAF signal (LLCO) on pin 76 of DME. Not connected on catalytic converter vehicles.

Note: In MAF Eliminate mode, connect IAT Resistor to pins 4 & 5 of Air Flow Meter Connector OR 14 & 77 of DME.