



Hot at all times
BODY CONTROL MODULE (BCM)
F23 15A
F24 15A
9
11
C2280A
S250
S231
SBP23
WH-RD
SBP24
VT-RD
10
C226A
8
C226B
VBATT
VBATT
STEERING COLUMN CONTROL MODULE (SCCM)
HS CAN +
HS CAN -
C226A
14
15
VDB04
WH-BU
VDB05
WH
MODULE COMMUNICATIONS NETWORK
PWR GND
LOGIC GND
5
C226B
13
C226A
S255
GD138
BK-WH
GD133
BK
38
C238
Expedition
S216
25
C238
GD138
BK-WH
GD133
BK
S347
G204
G205


POWERTRAIN CONTROL MODULE (PCM)
THROTTLE CONTROL UNIT
TACM+
TACM-
ETCRTN
TP1
ETCREF
TP2
C175E
86
91
31
68
7
52
CE412 YE-VT
CE426 BU-GN
RE134 BU-OG
VE818 BN
LE134 YE
VE819 GN-VT
C1449
1
2
4
3
5
6
M
APPRTN1
APPVREF1
APP1
APP2
APPRTN2
APPVREF2
C175B
36
12
55
54
35
10
RE136 VT-GN
LE136 GN-OG
VE701 YE-OG
VE702 BU-WH
RE137 YE-GN
LE137 BU-GY
C2040
1
3
2
5
4
6
ACCELERATOR PEDAL POSITION (APP) SENSOR
VT-GN
Navigator


Hot at all times
BATTERY JUNCTION BOX (BJB)
F43 10A
SBB43
BU-RD
POWERTRAIN CONTROL MODULE (PCM)
CES09 VT-OG
S145
CES09 VT-OG
C175B
65
BPS
4
3
C278
BRAKE PEDAL POSITION (BPP) SWITCH
1) Brake non-applied
2) Brake applied
1
2
1
2
REMOTE FUNCTION ACTUATOR (RFA) MODULE
BPP
C4392D
18
C465
28
CCB08 VT-WH
C215
2
1
CCB08
VT-WH
2
C278
Navigator
GD113
BK-YE
GD120
BK-GN
S108
S137
S134
G104
G106
BODY CONTROL MODULE (BCM)
MICRO
STOP LIGHT SWITCH
C2280B
28
CCB08 VT-WH
C213
13
S132
CCB08 VT-WH
66
BPP