

Hot At All Times
Hot In RUN
Power Distribution
B6
STOP/HAZ Fuse 1 20 A
C7
M4
BRAKE Fuse 15 10 A
N3
M8
CRUISE Fuse 6 10 A
N7
IP Fuse Block
0.8 ORN 140
S221
0.5 BRN 441
0.5 BRN 41
A13
C201
Brake Pedal Position (BPP) Switch
(Shown with brakes off)
Cruise Control Switch
On/Off
S/C
R/A
0.8 BRN 41
0.5 PPL 420
Engine Controls
Antilock Brakes
Exterior Lights
0.8 WHT 17
S200
A12
A14
A15
C201
0.5 DK BLU 84
0.5 GRY 397
0.5 GRY/BLK 87
P100
Cruise Control Release Switch
Brake Switch Input
Ignition Voltage
Cruise On/Off
Set/ Coast
Resume/ Accel
Cruise Control Module
Cruise Engaged
VSS Signal
Ground
0.5 DK GRN/WHT 817
0.5 LT BLU/BLK 396
S130
S326
CHMSL Resistor 510 OHMS
S325
0.8 WHT 750
S206
3 BLK 750
B7
C7
C100
24
3
C4
Radio
Ground Distribution
CONN ID
C1 = BLU
C2 = RED
C3 = CLR
C4 = BLK
Vehicle Control Module (VCM)
0.8 BLK 550
S204
C2
S117
2 TAN/WHT 550
G105
G110